

TEXT LISTING

068-000442-05

PROGRAM

6038/6039 FLOPPY RELIABILITY

TEXT TAPE

097-000442-05

ABSTRACT

THIS IS A PROGRAM DESIGNED TO TEST THE 6038/6039 FLOPPY DISK. THE PROGRAM IS SET UP TO HANDLE A MAXMIUM OF EIGHT ADAPTERS FOR A TOTAL OF 16 DRIVES (2/ADAPTER).

COPYRIGHT © DATA GENERAL CORPORATION, 1976, 1977, 1978, 1979
ALL RIGHTS RESERVED. PRINTED IN U.S.A.

ONLY FOR OPERATION AND MAINTENANCE PURPOSES
ON DATA GENERAL CORPORATION MANUFACTURED
EQUIPMENT.

THE AFFIXATION OF A COPYRIGHT NOTICE ON THIS
DIAGNOSTIC MATERIAL IS NOT INTENDED BY ITSELF
TO RENDER THE DISTRIBUTION OF THIS DIAGNOSTIC
MATERIAL A PUBLICATION.

NOTICE

DATA GENERAL CORPORATION (DGC) HAS PREPARED
THIS DIAGNOSTIC MATERIAL FOR USE BY DGC
PERSONNEL AND CUSTOMERS AS A GUIDE TO THE
PROPER MAINTENANCE OF DGC EQUIPMENT AND
SOFTWARE. THE DIAGNOSTIC MATERIALS CONTAINED
HEREIN ARE THE PROPERTY OF DGC AND SHALL
NEITHER BE REPRODUCED IN WHOLE OR IN PART WITHOUT
DGC'S PRIOR WRITTEN APPROVAL NOR BE IMPLIED TO
GRANT ANY LICENSE TO MAKE, USE, OR SELL EQUIPMENT
OR SOFTWARE MANUFACTURED IN ACCORDANCE HEREWITH.

```

0001 .MAIN      AUS ASSEMBLER REV 02.05      12102126 09/28/79
01
02
03
04
05
06
07
08
09
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48

;*****
; NAME: FPYRL.TX      PART NUMBER: 097-000442
; DESCRIPTION: 6038/6039 FLOPPY DISK RELIABILITY
; REVISION HISTORY:
;   REV.      DATE
;   00      12/03/76
;   01      06/24/77
;   02      10/14/77
;   03      04/28/78
;   04      01/05/79
;   05      09/13/79
;
; DATA GENERAL CORPORATION, 1976,1978,1979
; ALL RIGHTS RESERVED
; FOR MAINTENANCE PURPOSES ONLY
;
; THE AFFIXATION OF A COPYRIGHT NOTICE ON THIS
; DIAGNOSTIC MATERIAL IS NOT INTENDED BY ITSELF
; TO RENDER THE DISTRIBUTION OF THIS DIAGNOSTIC
; MATERIAL A PUBLICATION.
;
; NOTICE
;
; DATA GENERAL CORPORATION (DGC) HAS PREPARED
; THIS DIAGNOSTIC MATERIAL FOR USE BY DGC PER-
; SONNEL AND CUSTOMERS AS A GUIDE TO THE PROPER
; MAINTENANCE OF DGC EQUIPMENT AND SOFTWARE.
; THE DIAGNOSTIC MATERIALS CONTAINED HEREIN ARE
; THE PROPERTY OF DGC AND SHALL NEITHER BE RE-
; PRODUCED IN WHOLE OR IN PART WITHOUT DGC'S
; PRIOR WRITTEN APPROVAL NOR BE IMPLIED TO GRANT
; ANY LICENSE TO MAKE, USE, OR SELL EQUIPMENT OR
; SOFTWARE MANUFACTURED IN ACCORDANCE HERewith.
;*****

10002 .MAIN
01
02
03
04
05
06
07
08
09
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48

; 6038/6039 DISKETTE RELIABILITY
;-----
; FPYRL.SR
;
; REVISION HISTORY:
;-----
; REV      DATE
;   00      12/03/76
;   01      06/24/77
;   02      09/23/77
;   03      04/28/78
;   04      01/05/79
;   05      09/13/79
;
; DTR #95
; CLEAR DTR'S 160,
; 177,202, AND 211
; INCLUDE IOMOD TO ENABLE
; RUNNING ON MBC, CLEAR
; DTR'S 437 AND 468
;
; 1.0 ABSTRACT:
;-----
; THIS IS A PROGRAM DESIGNED TO TEST THE 6038/6039 FLOPPY DISK.
; THE PROGRAM IS SET UP TO HANDLE A MAXIMUM OF EIGHT ADAPTERS
; FOR A TOTAL OF SIXTEEN DRIVES(2/ADAPTER).
; THE DESIRED DEVICE CODE OR CODES SHOULD BE TYPED
; SEPARATED BY A SPACE AND TERMINATED BY A CARRIAGE RETURN.
; THE PROGRAM CONSISTS OF EIGHT BASIC TESTS,AND COMMAND
; STRING INTERPRETER.
;
; 1.1 INPUTS:
;-----
; ALL INPUTS TO THE PROGRAM ARE DONE VIA THE TERMINAL
; KEYBOARD.THE PROGRAM ASSUMES TURKEY SYSTEM WITH NO SWITCHES.
; THE SWITCH REGISTER IS INTERNAL TO THE PROGRAM AND
; SIMULATES THE SWITCH CONSOLE.
; THE SETTING AND CLEARING OF BITS WILL BE EXPLAINED LATER.
;
; 2.0 HARDWARE REQUIREMENTS:
;-----
; HARDWARE REQUIRED TO RUN THIS PROGRAM IS:
; SINGLE OR DUAL DRIVE FLOPPY(6038/6039).
; ANY MICRO-NOVA CPU
; A TERMINAL(TTY OR CRT&KEYBOARD).
; HIGH SPEED PTR IS OPTIONAL DEPENDING ON SET UP.

```

```

10003 .MAIN
01
02
03
04
05
06
07
08
09
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60

; 3.0 OPERATION:
;-----
;
; THE PROGRAM HAS TWO STARTING ADDRESSES (2 OR 200).
; WHEN STARTED, THE PROGRAM SIZES AND REPORTS MEMORY
; LIMIT. IT THEN REQUESTS FLOPPY DEVICE CODES, AT THIS
; TIME UP TO EIGHT(8) DEVICE CODES MAY BE ENTERED
; SEPARATED BY A SPACE AND TERMINATED BY A CARRIAGE
; RETURN.
; THE PROGRAM NOW REQUESTS THE UNITS TO BE TESTED.
; AFTER THESE HAVE BEEN SELECTED SWITCH SETTINGS
; ARE REQUESTED. THIS WILL BE DISCUSSED LATER.
; AFTER THE SWITCH SETTINGS HAVE BEEN SELECTED THE
; PROGRAM REQUESTS THE LOADING OF SCRATCH DISKETTES.
; WHEN THE DISKETTES HAVE BEEN LOADED THE OPERATOR
; TYPES A CR AND THE PROGRAM CONTINUES.
; THE PROGRAM NOW REQUESTS THE TESTS TO BE RUN.
; A CARRIAGE RETURN WILL SELECT TESTS (1 - 8) AND
; UNIT SWITCHING TEST TO BE RUN
; IN SEQUENCE ON EACH DEVICE. WHEN DONE DISK COPY IS RUN.
; TYPING A NUMERIC CHARACTER 1-8 WILL SELECT AND
; LOCK ON THAT TEST.
; WHEN LOCKED ON A TEST UNITS DO NOT CHANGE.
; AN ALPHA "I" WILL SELECT THE INTERCHANGABILITY
; TEST, AN ALPHA "U" WILL SELECT UNIT SWITCHING
; TEST. ANY OTHER ALPHA CHARACTER WILL
; PUT YOU IN COMMAND STRING.
; BELOW IS A LIST OF THE TESTS AND THE TYPE OF DATA:
; TEST 1 ALL ZEROS
; TEST 2 ALL ONES
; TEST 3 ALTERNATE ONES AN ZEROS
; TEST 4 ALTERNATE ZEROS AN ONES
; TEST 5 ALL SIXS
; TEST 6 SEVEN ZERO PATTERN
; TEST 7 RANDOM DATA
; TEST 8 RANDOMLY ORGANIZED ONES AND ZEROS
; TEST 9 INTERCHANGABILITY
; UNIT SWITCHING TEST
;
; THE PROGRAM IS COMPLETELY RE-ENTERANT. IF AT
; ANY TIME WHILE RUNNING THE FIRST EIGHT TESTS YOU
; WANT TO RESTART: TYPE A CNL R (THIS RESTARTS WITH
; THE CURRENT SWITCH SETTINGS) OR A CNL D (THIS
; RESTARTS WITH THE SWITCHS SET TO ZERO).
; INTERCHANGE TEST RESTARTS AUTOMATICALLY WHEN
; COMPLETED.
;
; 4.0 LOGICAL DISK UNITS
;-----
; LOGICAL DISKS WILL BE OF THE FORMAT DDU DD=DEVICE CODE
; U=UNIT NO.
; S=MPD 5
;
; SWITCH SETTINGS
;
; LOCATION "SWREG" IS USED TO SELECT THE PROGRAM OPTIONS
; (NOT SYSTEM CONFIGURATION). WHILE RUNNING UNDER DTOS,
0004 .MAIN
01
02
03
04
05
06
07
08
09
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42
43
44
45
46
47
48
49
50
51
52
53
54
55
56
57
58
59
60

; THIS LOCATION WILL BE LOADED BY THE MONITOR.
; UNDER STAND ALONE AND PROGRAM LOAD MODES THIS
; LOCATION WILL BE SET ACCORDING TO THE ANSWERS SUPPLIED
; BY THE OPERATOR. IN ANY CASE, THE OPTIONS CAN BE CHANGED
; OR VERIFIED BY USING ONE OF THE COMMANDS GIVEN IN SEC.
; 5.2
;
; 5.1 SWITCH OPTIONS
; DIFFERENT BITS AND THEIR INTERPRETATION AT LOCATION
; "SWREG" IS AS FOLLOWS:
;
; BIT OCTAL BINARY INTERPRETATION
; VALUE VALUE
;
; 1 40000 0 LOOP ON ERROR
; 1 40000 1 SKIP LOOPING ON ERROR
;
; 2 20000 0 PRINT TO CONSOLE
; 2 20000 1 ABORT PRINT OUT TO CONSOLE
;
; 3 10000 0 DO NOT PRINT % FAILURE
; 3 10000 1 PRINT % FAILURE
;
; 4 04000 0 ALLOW END OF PASS PRINT OUT
; 4 04000 1 SUPPRESS END OF PASS PRINT OUT
;
; 5 02000 0 DO NOT PRINT ON THE LINE PRINTER
; 5 02000 1 PRINT ON THE LINE PRINTER
;
; 6 01000 0 DO NOT HALT ON ERROR
; 6 01000 1 HALT ON ERROR
;
; 7 00400 0 DON'T PRINT SUBTEST SUMMARY OR PASS
; 7 00400 1 PRINT SUMMARY AND/OR
; PASSING OF EACH SUBTEST
;
; 8 00200 0 PRINT ONLY THE FIRST ERROR
; 8 00200 1 PRINT EVERY ERROR
;
; 5.2 SWITCH COMMANDS
; ONCE THE PROGRAM STARTS EXECUTION THE STATE OF ANY OF
; THE BITS CAN BE CHANGED BY HITTING KEYS 1-9, A-F. THE
; PROGRAM WILL CONTINUE RUNNING AFTER UPDATING THE OPTIONS.
; EACH KEY WILL COMPLEMENT THE STATE OF THE BIT AFFILIAT-
; ED WITH IT, THUS BIT 4 CAN BE ALTERED BY HITTING KEY 4.
; SETTING OF ANY BIT OF LOCATION "SWREG" WILL SET BIT 0.
; (DEFAULT MODE IS DEFINED AS ALL BITS OF SWREG SET TO 0)
; THE PROGRAM CAN BE LOCKED INTO SWITCH MODIFICATION MODE
; BY TYPING A 0, IN WHICH CASE MORE THAN ONE BIT CAN BE
; CHANGED BEFORE CONTROL IS ALLOWED TO RETURN TO THE
; MAIN PROGRAM.
;
; 5.2.1 OTHER COMMANDS
;
; "CR" A "RETURN" CAN BE TYPED TO CONTINUE THE PROGRAM
; AFTER ITS LOCKED IN A SWITCH MODIFICATION MODE
;
; "D" THIS COMMAND GIVEN AT ANY TIME WILL RESET "SWREG"
; TO DEFAULT MODE AND RESTART THE PROGRAM.

```


10007 .MAIN

**00000 TOTAL ERKUNS, 00000 FIRST PASS ERRORS

0008 .MAIN

S?MPD 006770 MC 3/54