

SDS 901090A
\$.75

DIAGNOSTIC PROGRAM MANUAL

SIGMA 5 AND 7
MEDIUM SPEED
RAPID ACCESS DATA (RAD)
SYSTEM TEST

March 1967

SCIENTIFIC DATA SYSTEMS • 1649 Seventeenth Street • Santa Monica, Calif. • (213) 871-0960

©1967, Scientific Data Systems, Inc.

LIST OF EFFECTIVE PAGES

Total number of pages is 20, as follows:

Page No.	Issue	Page No.	Issue
Title	Original		
A	Original		
i thru ii	Original		
1-1 thru 1-2	Original		
2-1 thru 2-4	Original		
3-1 thru 3-2	Original		
4-1 thru 4-8	Original		

TABLE OF CONTENTS

Section	Title	Page
I	INTRODUCTION	1-1
	1-1 Scope of Manual.	1-1
	1-3 Program Objectives.	1-1
	1-5 General Specifications.	1-1
II	OPERATING INSTRUCTIONS	2-1
	2-1 Program Loading Procedure	2-1
	2-3 Program Operating Procedure.	2-1
	2-4 Operator Control	2-1
	2-6 Operator Input: Selection of Parameters	2-1
	2-8 Assigning Parameters	2-1
	2-9 Selecting Standard Parameters	2-1
	2-10 Changing Parameters	2-1
	2-11 Operator Input: Selection of the Medium Speed RAD Program.	2-1
	2-14 Request for Error Table	2-1
	2-16 Program Printouts	2-2
	2-18 Error Statistics	2-2
	2-20 Error Reporting.	2-2
	2-23 Profile Printout.	2-2
III	PROGRAM DESCRIPTION.	3-1
	3-1 General	3-1
	3-3 Functional Description.	3-1
IV	PROGRAM LISTING	4-1
	4-1 General	4-1

LIST OF TABLES

Table	Title	Page
1-1	General Specifications.	1-1
2-1	Variables of the Input Line	2-1
2-2	Error Messages	2-3
3-1	Sequence of Events	3-1

LIST OF RELATED PUBLICATIONS

<u>Publication Title</u>	<u>Publication No.</u>
Sigma 5 and 7 Systems Test Monitor, Diagnostic Program Manual	901076
Sigma 5 and 7 Relocatable Diagnostic Program Loader, Diagnostic Program Manual	900972
Symbol and Metasymbol, Reference Manual	900952
SDS Sigma Rapid Access Data (RAD) Storage System, Models 7201/7202/7203/7204, Reference Manual	900979

SECTION I
INTRODUCTION

1-1 SCOPE OF MANUAL

1-2 This document gives a description of the medium speed rapid access data (RAD) system test, describes the parameter input to the systems test monitor for this program, and explains the error printouts and profile identifications.

1-3 PROGRAM OBJECTIVES

1-4 This program provides a multiprogrammed exerciser for the medium speed RAD which can only be run under control of the systems test monitor (Catalog No. 704138). Since this program is not a diagnostic, the RAD should be thoroughly checked out before running this exerciser.

1-5 GENERAL SPECIFICATIONS

1-6 General specifications for this program are found in table 1-1.

Table 1-1. General Specifications

Computer Configuration	As specified by the Sigma 5 and 7 Systems Test Monitor Diagnostic Program Manual, No. 901076
Required Equipment	Medium speed RAD

Table 1-1. General Specifications (Cont.)

Optional Equipment	As specified by Sigma 5 and 7 systems test monitor diagnostic program manual
Prerequisites	Sigma 5/7 systems test monitor must be resident in memory. The medium speed RAD system test is loaded via the systems test monitor as outlined in the systems test monitor program manual. The RAD and device controller must conform to their respective design specifications
Storage	The medium speed RAD system test is relocatable and requires 522 ₁₀ memory locations
Source Language	Sigma Metasymbol (see Sigma Symbol and Metasymbol Reference Manual, No. 900952)
Program Media	80-column punched cards and 8-level punched paper tape

SECTION II
OPERATING INSTRUCTIONS

2-1 PROGRAM LOADING PROCEDURE

2-2 To load the program, place the object deck or paper tape behind the systems test monitor card deck or paper tape. Other system test device programs may precede or follow this deck. The monitor loads the program as described in the systems test monitor documentation (No. 901076).

2-3 PROGRAM OPERATING PROCEDURE

2-4 OPERATOR CONTROL

2-5 The following paragraphs, 2-6 through 2-13, describe how the operator controls the operation of this program.

2-6 Operator Input: Selection of Parameters

2-7 These inputs via the keyboard have to be made through the system test monitor.

2-8 Assigning Parameters. There is only one test available in this program. The parameters for the program are typed in the following format:

P NNNN, UA, X₁, YYYYY, ZZZZ, X₂, X₃ EOM

The input line contains a number of variables: X₁, X₂, and X₃. An explanation of what they represent are explained in table 2-1.

Table 2-1. Variables of the Input Line

Value or Meaning	Explanation
If X ₁ = W	Only writing and check writing occurs
= R	Only reading occurs
= WR	Writing of one sector and reading back and verifying this sector takes place. Check writing also is performed
If X ₂ = 0	X ₃ is the seed for random numbers
= 1, 2, 3, or 4	The number represents the number of bytes in X ₃

Table 2-1. Variables of the Input Line (Cont.)

Value or Meaning	Explanation
X ₃	The random number seed if X ₂ = 0 A pattern to be spread, up to 4 bytes, if X ₂ ≠ 0
YYYY	The beginning sector and track address for reading and writing which must be 4-hexadecimal characters long. These two bytes are sent to the RAD in the seek operation
ZZZZ	The last sector and track address to be used. (The format is the same as for YYYY)

2-9 Selecting Standard Parameters. There is no standard assignment statement for the RAD.

2-10 Changing Parameters. The parameters can be changed any time as soon as the program becomes aware that parameters have been changed, it operates under the new parameter input.

2-11 Operator Input: Selection of the Medium Speed RAD Program

2-12 The RAD program is called for in the monitor under the name that was assigned to it at load time. The input statement is:

R NNNN + . . . EOM

2-13 The program can also be added or deleted from the run list by using the name NNNN (see Systems Test Monitor Diagnostic Program Manual, No. 901076, for the method by which this is done).

2-14 Request for Error Table

2-15 The RAD program keeps track of the number of passes made through the program. Rewrites, and rereads are also recorded. To obtain this information, the operator inputs:

P NAME, UA, ER EOM

This causes a typeout of the above mentioned information.

2-16 PROGRAM PRINTOUTS

2-17 The following paragraphs describe the printouts generated by this program.

2-18 Error Statistics

2-19 The program keeps a record of the number of times the program is executed and the rewrites and rereads (on error correction) made. As described in paragraph 2-15, this information can be obtained by a parameter input. After this input, the program will respond by typing:

```
* ERROR NAME + 000000099 AAAAAAAA
      BBBBBBBB CCCCCCCC
```

Word 1 (A) shows the number of passes made, word 2 (B) shows the number of rewrites attempted, and word 3 (C) shows the number of rereads attempted. The three numbers are in hexadecimal format. After this printout, all words are reset to zero. The program will not continue until a new parameter input has been made.

2-20 Error Reporting

2-21 Any error conditions detected by the program are reported via the typewriter. Before Selecting the RAD program, the file must be ready to accept read/write commands. Any sectors which are not to be used for writing should be write protected. Any "unusual end" conditions are reported with the appropriate status information. Data errors are also reported.

2-22 Table 2-2 contains the error messages which can be reported; the error number in the table follows the error page.

2-23 Profile Printout

2-24 Following is a list of the identifications provided by the RAD exerciser to the profile table:

<u>Identification</u>	<u>Explanation</u>
NAME = RD	Read a Sector
NAME = CW	Check Write a Sector
NAME = WR	Write a Sector

Table 2-2. Error Messages

Item No.	Error Message	Explanation and Recovery Procedure
1	* ERROR NAME + 000000001	Command was not W, WR, or R. Repeat parameter input
2	* ERROR NAME + 000000002 AAAAAAAA BBBBBBBB CCCCCCCC DDDDDDDD EEEEEEEE	A rate error occurred during a write operation. Word 1 (A) shows the AIO response, words 2 (B) and 3 (C) shows the two words of the TIO response, and word 4 (D) shows the second word of the TDV response. Word 5 (E) shows the track and sector address used during this operation. No operator intervention is required
3	* ERROR NAME + 000000003 AAAAAAAA BBBBBBBB CCCCCCCC DDDDDDDD EEEEEEEE	An unusual end interrupt occurred three times in a row while attempting to write. Words 1 through 5 have the same meaning as for error 2. No operator intervention is required
4	* ERROR NAME + 000000004 AAAAAAAA BBBBBBBB CCCCCCCC DDDDDDDD EEEEEEEE	A rate error occurred during a read operation. Words 1 through 5 have the same meaning as for error 2. No operator intervention is required
5	* ERROR NAME + 000000005 AAAAAAAA BBBBBBBB CCCCCCCC DDDDDDDD EEEEEEEE	Three successive read commands produced unusual end interrupts. Words 1 through 5 have the same meaning as for error 2. No operator intervention is required
6	* ERROR NAME + 000000006 AAAAAAAA BBBBBBBB CCCCCCCC DDDDDDDD EEEEEEEE + FFFFFFFF GGGGGGGG HHHHHHHH	The data read was incorrect. Words 1 through 5 have the same meaning as for error 2. Word 6 (F) gives the word in error. Word 7 (G) shows what it should have been, and word 9 (H) shows what was actually received. No operator intervention is required
7	* ERROR NAME + 000000007 AAAAAAAA BBBBBBBB CCCCCCCC DDDDDDDD EEEEEEEE	An unusual end occurred during a check write operation. Words 1 (A) through 5 (E) have the same meaning as for error 2. No operator intervention is required

SECTION III
PROGRAM DESCRIPTION

3-1 GENERAL

3-2 This medium speed RAD exerciser only runs devices on one device controller. If more than one RAD device controller is present, load the program once for each controller and assign different names each time the program is loaded.

3-3 FUNCTIONAL DESCRIPTION

3-4 The program reads, writes, and checkwrites all 90 words of a sector. The information written depends upon the parameter input. The data written is the same for all sectors. If more than one sector is to be used by the program, one RAD operation is completed on all sectors before

the next operation is started. Table 3-1 shows the sequence of events for the various parameters.

Table 3-1. Sequence of Events

Parameter	Sequence of Operations
W	Writes all sectors, checkwrites all sectors
R	Reads all sectors
WR	Writes all sectors, reads all sectors, and checkwrites all sectors

SECTION IV
PROGRAM LISTING

4-1 GENERAL

4-2 The program listing which follows details the content of this program. It contains a list of memory locations, the contents of the register at each location, and an explanation of the directive called forth by each register code.

4-3 Below is a sample printout of a line from a program listing, with an explanation of what is contained in each column. There can be as many as nine columns in the medium speed system test program listing, but not every column will appear in every listing.

EXAMPLE:

94 1 00036 22200000 A DK2A LI,2 0 SPREAD PATTERN
a b c d e f g h i

- a. Line number
- b. Indication of memory protection key (applies only to Sigma 5 and 7)
- c. Memory address
- d. Routine instruction and data
- e. Indication whether of absolute origin or not
- f. Field label
- g. Operation
- h. Operand
- i. Comments

+CATALOG NO 704351 MEDIUM SPEED RAD SYSTEM TEST
SYSTEM S167FDP

*
* EQU TABLE

1				
2				
3				
4				
5				
6	0000092	ERROR	EQU	X*92*
7	0000090	THREE	EQU	X*8C*
8	0000090	ONES	EQU	X*80*
9	0000096	ZERO	EQU	X*E6*
10	00000E7	B31	EQU	X*E7*
11	00000E8	B30	EQU	B31+1
12	00000E9	B29	EQU	B31+2
13	00000EA	B28	EQU	B31+3
14	00000EB	B27	EQU	B31+4
15	00000EC	B26	EQU	B31+5
16	00000ED	B25	EQU	B31+6
17	00000EE	B24	EQU	B31+7
18	00000EF	B23	EQU	B31+8
19	00000F0	B22	EQU	B31+9
20	00000F1	B21	EQU	B31+10
21	00000F2	B20	EQU	B31+11
22	00000F3	B19	EQU	B31+12
23	00000F4	B18	EQU	B31+13
24	00000F5	B17	EQU	B31+14
25	00000F6	B16	EQU	B31+15
26	00000F7	B15	EQU	B31+16
27	00000F8	B14	EQU	B31+17
28	00000F9	B13	EQU	B31+18
29	00000FA	B12	EQU	B31+19
30	00000FB	B11	EQU	B31+20
31	00000FC	B10	EQU	B31+21
32	00000FD	B9	EQU	B31+22
33	00000FE	B8	EQU	B31+23
34	00000FF	B7	EQU	B31+24
35	0000100	B6	EQU	B31+25
36	0000101	B5	EQU	B31+26
37	0000102	B4	EQU	B31+27

2

38	0000103	B3	EQU	B31+28
39	0000104	B2	EQU	B31+29
40	0000105	B1	EQU	B31+30
41	0000106	B0	EQU	B31+31
42	00000E7	ONE	EQU	B31
43	00000E8	TWO	EQU	B31+1
44	00000E9	THREE	EQU	B31+2

45				PAGE		
46			*			
47			*		SEVA DISK TEST	
48			*			
49	1 00000	C4E2D2F1 A	PST	TEXT	*DSK1*	PST TABLE
50	1 00001	C00002CA		DATA	LLOC	PROGRAM LOCATIONS
51	1 00002	C00300CC A		DATA	0	UA
52	1 00003			RES	10	
53	1 00000	C0000066		GEN,32	REST	
54	1 0000E	C0G00C12	PST1	DATA	DK1,0,0,-1	
	1 0000F	C00000CC A				
	1 00010	C00000CC A				
	1 00011	FFFFFFFF A				
55			*			
56			*			
57			*			
58	1 00012	045000CC A	DK1	CAL,5	0	TEST DELAY
59	1 00013	00000066		GEN,32	DK1A	
60	1 00014	221FFFFFF A		L1,1	-1	TEST FOR CHANGE OF UA
61	1 00015	31100CC2		CW,1	PST+2	
62	1 00016	68300C1A		BCR,3	DK1B	
63	1 00017	32200CC2		LW,2	PST+2	
64	1 00018	3520C1FC		STW,2	UA	SAVE UNIT ADDRESS
65	1 00019	35100CC2		STW,1	PST+2	
66	1 0001A	32100CC3	DK1B	LW,1	PST+3	
67	1 0001B	25100070 A		SLS,1	-16	
68	1 0701C	351001EC		STW,1	COMMAND	SAVE COMMAND
69	1 0001D	2110C5E9 A		CI,1	X*CS09*	TEST FOR ER
70	1 0001E	68300C4A		RCR,3	DKEA	
71	1 0001F	3310005A		MTW,1	PASS	
72	1 00020	324000C4		LW,4	PST+4	
73	1 00021	6AE0005D		BAL,14	CONV	FIND STARTING AND ENDING ADDRESS
74	1 00022	35400137		STW,4	DKSECT	* FOR SECTORS
75	1 00023	354001EF		STW,4	DKSECT1	
76	1 00024	32400CC5		LW,4	PST+5	
77	1 00025	6AE0005D		BAL,14	CONV	
78	1 00026	3540C136		STW,4	DKLAST	

79	1 00027	321000C6		LW,1	PST+6	
80	1 00028	251000C4 A		SLS,1	4	
81	1 00029	251000E4 A		SLS,1	-28	TEST FOR PATTERN TO SPREAD
82	1 0002A	211000CC A		CI,1	0	
83	1 0002B	69200036		BCS,2	DK2A	BRANCH IF NOT RANDOM,BIGGER THAN 0
84	1 0002C	3510C1F1		STW,1	RANDOM	
85	1 0002D	321000C7		LW,1	PST+7	
86	1 0002E	222FFFFA6 A		L1,2	-90	
87	1 0002F	3510G1ED	DK2B	STW,1	SEED	GENERATE RANDOM PATTERN
88	1 00030	25100011 A		SLS,1	17	
89	1 00031	3010C1ED		AW,1	SEED	
90	1 00032	3010C1EE		AW,1	CONST	
91	1 00033	3514C192		STW,1	DK0B+90,2	STORE IN OUTPUT BUFFER
92	1 00034	6520002F		BIR,2	DK2E	
93	1 00035	6800006C		B	DK2C	
94	1 00036	222000CC A	DK2A	L1,2	0	SPREAD PATTERN
95	1 00037	211000C5 A		CI,1	5	
96	1 00038	6910003A		BCS,1	\$+2	
97	1 00039	221000C4 A		L1,1	4	MAKE COUNT
98	1 0003A	351001F1		STW,1	RANDOM	SAVE NO OF BYTES
99	1 0003B	324000C8		LW,4	PST+8	
100	1 0003C	6AF00061		BAL,15	GEN	
101	1 0003D	324000C7		LW,4	PST+7	GENERATE 4 BYTES
102	1 0003E	6AF00061		BAL,15	GEN	
103	1 0003F	3550C1ED		STW,5	SEED	
104	1 00040	222FFFE9A A		L1,2	-36C	
105	1 00041	221000CC A		L1,1	0	
106	1 00042	723201ED	DK3A	LB,3	SEED,1	GENERATE PATTERN
107	1 00043	75340192		STB,3	DK0B+90,2	
108	1 00044	331000C1 A		MTW,1	1	
109	1 00045	311001F1		CW,1	RANDOM	
110	1 00046	6930004A		BCS,3	\$+2	
111	1 00047	221000CC A		L1,1	0	
112	1 00048	65200042		BIR,2	DK3A	STORE ALL BYTES
113	1 00049	6800006C		B	DK2C	
114			*			
115	1 0004A	3210005A	DKEA	LW,1	PASS	

116	1 0004B	351001F4		STW,1	ER+1	TYPE BUI ERROR
117	1 0004C	3210005C		LW,1	REWRITE	
118	1 0004D	351001F5		STW,1	ER+2	
119	1 0004E	3210005B		LW,1	REREAD	
120	1 0004F	351001F6		STW,1	ER+3	
121	1 00050	22100063 A		LI,1	99	ERROR 99
122	1 00051	351001F3		STW,1	ER	
123	1 00052	221000C4 A		LI,1	4	
124	1 00053	351000B7		STW,1	REPI	
125	1 00054	6AF000B1		BAL,15	REPER	
126	1 00055	221000C0 A		LI,1	0	INIT. ERROR STATUS
127	1 00056	3510005A		STW,1	PASS	
128	1 00057	3510005B		STW,1	REREAD	
129	1 00058	3510005C		STW,1	REWRITE	
130	1 00059	68000077		B	DKWX	
131			*			
132	1 0005A	00000000 A	PASS	DATA	0	
133	1 0005B	00000000 A	REREAD	DATA	0	
134	1 0005C	00000000 A	REWRITE	DATA	0	
135			*			
136	1 0005D	6AF00061	CONV	BAL,15	GEN	
137	1 0005E	22400000 A		LI,4	0	CONVERT FIRST AND LAST SECTOR
138	1 0005F	25400110 A		SLD,4	16	
139	1 00060	E800000E A		B	*14	
140			*			
141	1 00061	64000107	GEN	BAL,13	GEN1	
142	1 00062	64000107		BAL,13	GEN1	GENERATE ACTUAL 16 BITS IN
143	1 00063	64000107		BAL,13	GEN1	* REGISTER FIVE
144	1 00064	64000107		BAL,13	GEN1	
145	1 00065	E800000F A		B	*15	
146			*			
147	1 00066	22100012	REST	LI,1	DK1	
148	1 00067	3510000F		STW,1	PST1	
149	1 00068	22000000 A		LI,0	0	
150	1 00069	3500000F		STW,0	PST1+1	
151	1 0006A	34000010		STW,0	PST1+2	
152	1 0006B	04000000 A		CAL,0	0	

153			*			
154		1 00065	DK1A	EDG	REST	
155	1 0006C	321001E0	DK2C	LW,1	COMMAND	
156	1 0006D	2110E900 A		CI,1	X*0900*	TEST FOR K
157	1 0006E	68300000		BCR,3	WR00M	
158	1 0006F	2110E600 A		CI,1	X*E600*	TEST FOR K
159	1 00070	6830007F		BCR,3	WR00M	
160	1 00071	2110E619 A		CI,1	X*E6D9*	TEST FOR WR
161	1 00072	6830007A		BCR,3	WR00M	
162	1 00073	22100001 A		LI,1	1	
163	1 00074	351001F3		STW,1	EK	
164	1 00075	351000B7		STW,1	REPI	REPORT ERROR 1
165	1 00076	6AF000B1		BAL,15	REPER	
166	1 00077	6AF000ED	DKWX	BAL,15	CHANGE	
167	1 00078	22100077		LI,1	DKAX	
168	1 00079	3510000E		STW,1	PST1	RETURN TO MONITOR
169	1 0007A	04000000 A		CAL,0	0	
170			*			
171	1 0007B	22100000 A	ARC0M	LI,1	0	
172	1 0007C	351001F2		STW,1	TRY	
173	1 0007D	6AF00098	ARC0M2	BAL,15	WRITE	WRITE A SECTOR
174	1 0007E	6AF000ED		BAL,15	CHANGE	TEST FOR CHANGE OF JA
175	1 0007F	321001F4		LW,1	DA10	
176	1 00080	48100106 A		AND,1	BU	TEST FOR RATE ERROR
177	1 00081	68300086		BCR,3	WR00M1	
178	1 00082	22100002 A		LI,1	2	ERROR2,RATE ERROR ON WRITE
179	1 00083	352001F3		STW,2	ER	
180	1 00084	6AF000A9		BAL,15	REPER5	
181	1 00085	6800007D		B	WR00M2	
182			*			
183	1 00086	321001F4	ARC0M1	LW,1	DA10	TEST FOR OTHER ERROR
184	1 00087	481000FA A		AND,1	B12	
185	1 00088	68300091		BCR,3	WR00M3	
186	1 00089	331001F2		MTW,1	TRY	YES
187	1 0008A	321001F2		LW,1	TRY	
188	1 0008B	3310005C		MTW,1	REWRITE	
189	1 0008C	21100003 A		CI,1	3	TRY WRITING 3 TIMES

190	1 0008D	6930007E		BOS,3	WRCOM2	
191	1 0008E	221000C3 A		LI,1	3	
192	1 0008F	351001F3		STW,1	ER	REPORT ER3 IF MORE THAN 3 TRIES
193	1 00090	6AF000A9		BAL,15	REPER5	
194	1 00091	32100136	*RCCM3	LW,1	DKLAST	
195	1 00092	31100137		OW,1	DKSECT	TEST FOR LAST SECTOR
196	1 00093	683000CC		BCR,3	RDCOM	
197	1 00094	221000CC A		LI,1	0	
198	1 00095	351001F2		STW,1	TRY	GO TO NEXT SECTOR
199	1 00096	33100137		MTW,1	DKSECT	
200	1 00097	6600007E		B	WRCOM2	
201			*			
202			*			WRITE A SECTOR
203	1 00098	35F001FF	*WRITE	STW,15	RETURN	
204	1 00099	221000FF		LI,1	DA(EKWR)	
205	1 0009A	351000A5		STW,1	I02	CALL ON SID RT
206	1 0009B	046000CC A		CAL,1,0	0	
207	1 0009C	000000CC		DATA	PST	
208	1 0009D	4040E6E9 A		TEXT	* WR*	
209	1 0009E	6800009F		B	I0R1	
210			*			
211			*			
212			*			
213			*			
214			*			
215			*			I0 ROUTINE
216	1 0009F	041000CC A	I0R1	CAL,1,1	0	CALL SID
217	1 000A0	000001FC		GEN,32	UA	
218	1 000A1	000000A6		GEN,32	I04	BUSY RETURN
219	1 000A2	000000A8		GEN,32	I05	NOT BUSY RETURN
220	1 000A3	000000A6		GEN,32	I04	NOT ACCEPTED RETURN
221	1 000A4	0000012C		GEN,32	INT	INTERRUPT ADDRESS
222	1 000A5	000000CC A	I02	GEN,32	0	COMMAND DOUBLE WORD
223			*			
224	1 000A6	2210009F	I04	LI,1	I0R1	
225	1 000A7	351000CE		STW,1	PST1	
226	1 000A8	040000CC A	I05	CAL,1,0	0	RETURN TO MONITOR

227			*			
228	1 000A9	35F0009C	REPER5	STW,15	REPS1	
229	1 000AA	32100137		LW,1	DKSECT	
230	1 000AB	351001F2		STW,1	EXWD	
231	1 000AC	221000CC A		LI,1	6	
232	1 000AD	351000E7		STW,1	REP1	
233	1 000AE	6AF000E1		BAL,15	REPER	
234	1 000AF	E800009C		B	*REPS1	
235			*			
236	1 000F0	000000CC A	REPS1	DATA	0	
237			*			REPORT ERROR
238	1 000E1	35F000E8	REPER	STW,15	REP3	
239	1 000E2	321000CC		LW,1	PS1	
240	1 000E3	351000E9		STW,1	REP2	
241	1 000E4	EA100092 A	REPR	BAL,1	*ERROR	BRANCH TO ERROR ROUTINE
242	1 000E5	000000CC		GEN,32	REP6	BUSY RETURN
243	1 000E6	000000E9		GEN,32	REP7	ONLY BUSY RETURN
244	1 000E7	000000CC A	REP1	DATA	0	
245	1 000E8	820000CC A		DATA	*82000000*	
246	1 000E9	000000CC A	REP2	DATA	0	
247	1 000EA	000001F3		GEN,32	EX	
248			*			
249	1 000EA	000000CC A	REP3	DATA	0	
250			*			
251	1 000EB	221000E4	REPE	LI,1	REP8	
252	1 000EC	351000CF		STW,1	PST1	
253	1 000ED	040000CC A		CAL,1,0	0	
254			*			
255	1 000EF	E800008B	REP7	B	*REP3	
256			*			
257	1 000F0	321001EC	RDCOM	LW,1	COMMAND	
258	1 000F1	2110E600 A		CI,1	*E600*	TEST FOR * ONLY
259	1 000F2	683001CF		BCR,3	CAW*	
260	1 000F3	221000CC A	RDCOM1	LI,1	0	
261	1 000F4	351001F2		STW,1	TRY	
262	1 000F5	321001EF		LW,1	DKSECT1	RESTORE FIRST SECTOR
263	1 000F6	35100137		STW,1	DKSECT	

```

264 1 000C7 6AF000F2 RDC0M4 BAL,15 RDSEC READ SECTOR
265 1 000C8 6AF000ED BAL,15 CHANGE TEST FOR CHANGE OF PARAMETERS
266 1 000C9 321001F4 LW,1 DA10
267 1 000CA 491001C6 A AND,1 B0 TEST FOR RATE ERROR
268 1 000CB 693000CF BCR,3 RDC0M2
269 1 000CC 221000C4 A LI,1 4
270 1 000CD 351001F3 STW,1 ER
271 1 000CE 6AF000A9 BAL,15 REPER5 REPORT ERROR 4
272 1 000CF 321001F4 LW,1 DA10
273 1 000D0 481000FA A AND,1 B12 TEST FOR UNUSUAL END
274 1 000D1 683000DA BCR,3 RDC0M3
275 1 000D2 331001F2 MTR,1 TRY TRY = TRY +1
276 1 000D3 321001F2 LW,1 TRY
277 1 000D4 33100056 MTR,1 REREAD
278 1 000D5 211000C3 A CI,1 3
279 1 000D6 693000C7 BCR,3 RDC0M4 TRY AGAIN
280 1 000D7 221000C5 A LI,1 5
281 1 000DA 351001F3 STW,1 ER
282 1 000D9 6AF000A9 BAL,15 REPER5 REPORT ERROR 5
283 1 000DA 6AF000F1 RDC0M3 BAL,15 VERBI VERIFY BUFFER
284 1 000DB 221000C0 A LI,1 0
285 1 000DC 351001F2 STW,1 TRY
286 1 000DD 32100137 LW,1 DKSECT
287 1 000DE 31100136 CW,1 DKLAST TEST FOR LAST SECTOR
288 1 000DF 693001CF BCR,3 CKWR
289 1 000E0 33100137 MTR,1 DKSECT GO TO CHECK WRITE
290 1 000E1 680000C7 B RDC0M4
291
292
293
294 1 000E2 35F001FD RDSEC STW,15 READ SECTOR
295 1 000E3 22F000CC A LI,15 RETURN
296 1 000E4 221FFFAC A LI,1 0
297 1 000E5 35F2C1EC RDSECK STW,15 DKIB+90,1 CLEAR INPUT BUFFER
298 1 000E6 651000E5 BIR,1 RDSECK
299 1 000E7 22F0C1C1 LI,15 DA(LKRD) SET UP DOUBLE WORD ADDRESS
300 1 000E8 35F000A5 STW,15 I02
    
```

```

301 1 000E9 04600000 A CAL,6 0
302 1 000EA 00000000 DATA PST
303 1 000EB 4040F9C4 A TEXT ? RDP
304 1 000EC 6800009F B IUNT
305
306 1 000ED 321000C2 CHANGE LW,1 PST+2 TEST FOR CHANGE OF PARAMETERS
307 1 000EE 211FFFFFF A CI,1 -1
308 1 000EF E83000CF A BCR,3 *15
309 1 000F0 680000A6 B REST
310
311 1 000F1 34F000FA VERBI STW,15 VB1 VERIFY INPUT BUFFER
312 1 000F2 221FFFAC A LI,1 -90 SAVE RETURN
313 1 000F3 32220192 VB2 LW,2 DKIB+90,1 COMPARE INPUT AND OUTPUT BUFFERS
314 1 000F4 3122C1EC CW,2 DKIB+90,1
315 1 000F5 693000F9 BCR,3 VB3
316 1 000F6 651000F3 BIR,1 VB2
317 1 000F7 E80000F8 B *VB1 RETURN
318
319 1 000F8 00000000 A VR1 DATA 0
320
321 1 000F9 2230005B A VR3 LI,3 91
322 1 000FA 303000C1 A AW,3 1
323 1 000FB 353001F9 STW,3 ERN0+1 SET UP WORD IN ERROR
324 1 000FC 352001FA STW,2 ERN0+2 SET UP WORD EXP.
325 1 000FD 3222C1EC LW,2 DKIB+90,1
326 1 000FE 352001FB STW,2 ERN0+3 SET UP WORD RECEIVED
327 1 000FF 32200137 LW,2 DKSECT
328 1 00100 352001FA STW,2 ERN0
329 1 00101 222000C9 A LI,2 9
330 1 00102 35200057 STW,2 REPI
331 1 00103 222000CA A LI,2 6
332 1 00104 352001F3 STW,2 ER REPORT ERROR 6
333 1 00105 6AF000E1 BAL,15 REPER
334 1 00106 E80000FA B *VR1
335
336 1 00107 2540017C A GEN1 SLD,4 -4
337 1 00108 2540027F A SCS,4 -1 SHIFT BYTES INTO REGISTER 5
    
```

338	1	00109	33000004 A		MTW,0	4		* AND ADD 9 IF C1-C6
339	1	0010A	69100100		B,CS,1	\$+2		
340	1	0010B	3050010E		AW,5	GEN2		ADD 9
341	1	0010C	2540007D A		SLS,4	-3		
342	1	0010D	E800000D A		B	+13		
343								
344	1	0010E	90000000 A	GEN2	DATA	X*90000000*		
345				*				
346				*				
347				*				
348	1	0010F	32100100	CKWR	LW,1	CHECK WRITE		
349	1	00110	2110D900 A		CI,1	COMMAND		
350	1	00111	6830006F		BCR,3	X*D900*		
351	1	00112	32100100		LW,1	REST		RETURN TO MON IF R ONLY
352	1	00113	35100137		STW,1	DKSECT1		
353	1	00114	22100110	CKWR2	LI,1	DKSECT		
354	1	00115	35100100		STW,1	CKWR1		
355	1	00116	22100103		LI,1	RETURN		CHECK WRITE
356	1	00117	351000A5		STW,1	DA(DKCKAR)		
357	1	00118	04630000 A		CAL,6	102		
358	1	00119	00020000		DATA	0		
359	1	0011A	404003E6 A		TEXT	PST		
360	1	0011B	6800009F		H	* CW*		
361						IORT		
362	1	0011C	6AF000ED	CKWR1	BAL,15	CHANGE		TEST FOR CHANGE OF PARAMETERS
363	1	0011D	321001F4		LW,1	DA10		
364	1	0011E	4H1000FA A		AND,1	B12		
365	1	0011F	68300127		BCR,3	CKWR3		TEST FOR UNUSUAL END
366	1	00120	32100137		LW,1	DKSECT		
367	1	00121	35100100		STW,1	ERRD		STORE SECTOR ADDRESS
368	1	00122	22100006 A		LI,1	6		
369	1	00123	35100007		STW,1	REP1		
370	1	00124	22100007 A		LI,1	7		ERROR 7 ON CHECK WRITE
371	1	00125	35100103		STW,1	ER		
372	1	00126	6AF000E1		BAL,15	REPER		REPORT ERROR
373	1	00127	32100137	CKWR3	LW,1	DKSECT		
374	1	00128	31100136		CW,1	DKLAST		

375	1	00129	68300012		BCR,3	DK1		TEST FOR LAST SECTOR
376	1	0012A	33100137		MTW,1	DKSECT		
377	1	0012B	68000114		B	CKWR2		CHECK WRITE NEXT SECTOR
378								
379	1	0012C	34E001F4	INT	STW,14	DA10		SAVE AID STATUS
380	1	0012D	0D0001FC		IT0,12	*UA		
381	1	0012E	35000100		STW,12	DT10		SAVE I10 STATUS
382	1	0012F	35000100		STW,13	DT10+1		
383	1	00130	0E000100		IDV,13	*UA		
384	1	00131	35000100		STW,13	DT0V		
385	1	00132	32100100		LW,1	RETURN		GET PROGRAM ENTRY
386	1	00133	35100000		STW,1	PST1+1		
387	1	00134	22DFFFFF A		LI,13	-1		
388	1	00135	E8000000 A		H	+15		RETURN
389								
390								

391				PAGE	
392	1 00136	00000000	A	DKLAST	DATA 0
393	1 00137	00000000	A	DKSECT	DATA 0
394	1 00138			DK08	RES 90
395	1 00192			DK18	RES 90
396	1 001EC	00000000	A	COMMAND	DATA 0
397	1 001ED	00000000	A	SEED	DATA 0
398	1 001EE	5A6B7C8D	A	CONST	DATA X*5A6B7C8D*
399	1 001EF	00000000	A	DKSECT1	DATA 0
400	1 001F0	00000000	A	TEMP	DATA 0
401	1 001F1	00000000	A	RANDOM	DATA 0
402	1 001F2	00000000	A	TRY	DATA 0
403	1 001F3	00000000	A	ER	DATA 0
404	1 001F4	00000000	A	DA10	DATA 0
405	1 001F5	00000000	A	DT10	DATA 0.0
	1 001F6	00000000	A		
406	1 001F7	00000000	A	DTDV	DATA 0
407	1 001F8			ERWD	RES 4
408	1 001FC	00000000	A	UA	DATA 0
409	1 001FD	00000000	A	RETURN	DATA 0
410	1 001FE			BOUND	8
411	1 001FE	C300041E		DKWR	GEN,8,24 X*03*,BA(DKSECT)+2 WRITE
412	1 001FF	2C000002	A		GEN,8,24 X*2C*,2
413	1 00200	C1000410		DKWRC	GEN,8,24 X*01*,BA(DK08)
414	1 00201	1C000168	A		GEN,8,24 X*1C*,360
415	1 00202	C300041E		DKRC	GEN,8,24 X*03*,BA(DKSECT)+2 REAL
416	1 00203	2C000002	A		GEN,8,24 X*2C*,2
417	1 00204	C2000648		DKRDC	GEN,8,24 X*02*,BA(DK18)
418	1 00205	1C000168	A		GEN,8,24 X*1C*,360
419	1 00206	C300041E		DKCKWR	GEN,8,24 X*03*,BA(DKSECT)+2 CHECK WRITE
420	1 00207	2C000002	A		GEN,8,24 X*2C*,2
421	1 00208	C5000410		DKCKWRC	GEN,8,24 X*05*,BA(DK08)
422	1 00209	1C000168	A		GEN,8,24 X*1C*,360
423				*	
424				*	
425	1 002CA			LL0C	EGU 5
426				END	