

**REMEMBER TO ADD THE COMAND LINE AND FLASH.BAT ENTRY FOR SAVING THE OLD BIOS FILE**

**NOTE: Unless you are experiencing difficulties which you believe may be motherboard-BIOS-related, you probably do NOT need to update the BIOS.**

If you decide to flash the BIOS, please proceed as follows:

1. You will need to flash using a floppy under DOS. Please do **NOT** attempt to flash using the SuperUpdate, SuperLogo, or Winflash utility.  
NOTE: If you do not have a floppy drive, please build a bootable CD. See instructions at [www.bootdisk.com](http://www.bootdisk.com).  
NOTE: If you use SuperUpdate, SuperLogo or Winflash to flash the BIOS, the motherboard MAY not recover upon reboot and the BIOS MAY need to be reprogrammed or replaced.
2. Extract the BIOS from within the provided zip file into a temporary directory. You will need to enter “**Fullerton**” (without quotation marks) as the password.
3. Create a bootable floppy disk and add the flash utility and BIOS binary files. See [http://global.foxconnchannel.com/en-us/service/FAQ\\_read.aspx?id=en-gb0000010](http://global.foxconnchannel.com/en-us/service/FAQ_read.aspx?id=en-gb0000010) for instructions.
4. Boot to the bootable floppy. Then execute the FLASH.BAT or type this command line:  
AFU860H x.bin /py/sy/cc/cd/cp/wb (where “x” represents the portion of the BIOS file name preceding the “dot”).