

## INTEGRATED DI/DO

### AUTO MODE MAP

A000 – Tests basic instructions and data paths on card.  
Does not test customer connection points.

### MANUAL MODE MAP

A001 – Manual Wrap Test – allows testing with wrap of  
DI/DO at attachment card. Wrap Connector  
P/N 1633813.

A002 – Manual wrap of Customer Interface Panel  
Feature. Wrap Connector P/N 1633840.

*NOTE:* When any map is loaded, it executes against all four  
addresses used by the IDIDO card.

*NOTE:* If using the 'Request Device Address' option always re-  
quest the base address. Requesting any of the other three  
addresses will cause map failures.

Additional information located in A000 Prolog.

Sequence		Part	EC 374831				
18A0AA	1 of 2	6826710	7-1-78				

Sequence		Part	EC 374831				
18A0AA	2 of 2	6826710	7-1-78				

COPYRIGHT IBM CORPORATION 1976