

PAPER ONLY MAP

PAGE 1 OF 2

ENTRY POINTS

FROM ENTER THIS MAP			
MAP NUMBER	ENTRY POINT	PAGE NUMBER	STEP NUMBER
2570	A	1	001
2575	E	1	008

EXIT POINTS

EXIT THIS MAP		TO	
PAGE NUMBER	STEP NUMBER	MAP NUMBER	ENTRY POINT
1	003	1071	A
1	004	1071	A
1	006	1071	A
1	009	2570	C
2	013	2570	C
1	003	2570	D
1	004	2570	D
1	006	2570	D
1	012	2572	A
1	010	2573	F

001
(ENTRY POINT A)
LISTEN TO THE CONSOLE.
- PRESS THE RESET KEY.
IS THE RESET KEY AUDIBLE ?
Y N
N

002
IS THE CONSOLE DATA '0000' ?
Y N
N

003
- INSPECT CONSOLE COLUMN 0 AND ROW C FOR AN OPEN.
GO TO MAP 1071, ENTRY POINT A.

IF NO PROBLEM IS FOUND
GO TO MAP 2570, ENTRY POINT D.

004
- INSPECT THE CONSOLE AUDIBLE DEVICE.
GO TO MAP 1071, ENTRY POINT A.

IF THE CONSOLE IS GOOD
GO TO MAP 2570, ENTRY POINT D.

005
SEE IF THE AUDIBLE DEVICE STOPPED GENERATING SOUND, WHEN YOUR FINGER WAS REMOVED FROM THE CONSOLE RESET KEY.
DID THE AUDIBLE DEVICE STOP GENERATING SOUND?
Y N
N

006
- INSPECT THE FOLLOWING:
THE INTERRUPT KEY.
THE STORE KEY.
GO TO MAP 1071, ENTRY POINT A.

IF THE CONSOLE IS GOOD,
GO TO MAP 2570, ENTRY POINT D.

007
- SEE IF THE DATA LAMPS EQUAL 0000.
DO THE DATA LAMP(S) EQUAL 0000 ?
Y N
N

008
(ENTRY POINT E)
- SEE IF THE DATA LAMPS EQUAL 00E0 OR 00E5.
DO THE DATA LAMPS EQUAL 00E0 OR 00E5 ?
Y N
N

009
GO TO MAP 2570, ENTRY POINT C.

010
- POWER OFF THE PROCESSING UNIT.
- INSPECT THE RESET KEY FOR A SHORT CIRCUIT.
- INSPECT THE LOAD KEY FOR A SHORT CIRCUIT.
(ROW C TO ROW D)
GO TO MAP 2573, ENTRY POINT F.

A 4955 PROCESSING UNIT LOAD
I PAPER ONLY MAP
PAGE 2 OF 2

MAP 2574-2

011
- SEE IF THE FOLLOWING LEDS ARE ON.

STOP LED.
LEVEL ZERO (0) LED.
POWER 'ON' LED.
ALL OTHERS OFF.

ARE THESE THE ONLY LEDS ON ?

Y
N

012
GO TO MAP 2572, ENTRY POINT A.

013
GO TO MAP 2570, ENTRY POINT C.

15JAN81 PN6838180
EC869422 PEC375475
MAP 2574-2