



HP Cluster Configuration Support Matrix For Microsoft Windows Server 2003 EE & HP StorageWorks EVA3000

Config	Supported Servers*	Server Software	Host Bus Adapters (HBAs)**	Multi Path Software	Storage Information	Interconnects (Switches)	Other
#1 Windows Server 2003, EE	Max supported nodes = 4 DELL <ul style="list-style-type: none"> • PowerEdge 1650 • PowerEdge 1750 • PowerEdge 2650 • PowerEdge 6650 * Note: Servers can be used homogeneously or heterogeneously within a cluster.	DELL OpenManage Server Assistant 7.3.3 & Systems Mgmt 3.3.3	FCA2404 Driver: 5-4.82.a16 FW: 1.01a2 BIOS: 1.63a1 ** Note: HBAs must be used homogeneously within a cluster.	Secure Path Ver: 4.0c Raidisk.sys ver: 3.7.2.240	StorageWorks Enterprise Virtual Array 3000 Virtual Controller Software (VCS) FW: V3.010 OpenView Storage Management Appliance: OSM v2.1 CommandView EVA: Version 3.10 Build 21	HP 2GB SAN Switches 8/16 ports FW: 3.1.1 <ul style="list-style-type: none"> •SAN Switch 2/8 EL •SAN Switch 2/16 EL •SAN Switch 2/16 	March 2004