

**DETACH(a)**

**DETACH(a)**

**NAME**

detach – detach process from interrupt vector

**SYNOPSIS**

(detach = 36.)

**detach(process, vector)**

**DESCRIPTION**

*Detach* detaches the process *process* from the interrupt vector at address *vector*. The entry point for the process is cleared and the device control register is also cleared. This system function is normally only invoked by the process manager in the process of taking down a device driver. A value of 1 is returned from C.

**SEE ALSO**

attach(a).

**DIAGNOSTICS**

An error is returned if the process does not exist or if the interrupt vector is invalid (-1 in C).