

1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
32
33
34
35
36
37
38
39
40
41
42

.NLIST TOC
.REM @

IDENTIFICATION

PRODUCT CODE: AC-1842A MC
PRODUCT NAME: CNKMDAO KMV11A/B LOGIC DIAG
PRODUCT DATE: APRIL 1984
MAINTAINER: ISS DIAGNOSTICS
AUTHOR: MICHELET GUY
MODIFIED BY: JAKI BERG 9-APR-1984

THE INFORMATION IN THIS DOCUMENT IS SUBJECT TO CHANGE WITHOUT NOTICE AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT CORPORATION. DIGITAL EQUIPMENT CORPORATION ASSUMES NO RESPONSIBILITY FOR ANY ERRORS THAT MAY APPEAR IN THIS DOCUMENT.

NO RESPONSIBILITY IS ASSUMED FOR THE USE OR RELIABILITY OF SOFTWARE ON EQUIPMENT THAT IS NOT SUPPLIED BY DIGITAL OR ITS AFFILIATED COMPANIES.

COPYRIGHT (C) 1982,1984 BY DIGITAL EQUIPMENT CORPORATION

THE FOLLOWING ARE TRADEMARKS OF DIGITAL EQUIPMENT CORPORATION:

DIGITAL	PDP	UNIBUS	MASSBUS
DEC	DECUS	DECTAPE	

44
45
46
47
48
49
50
51
52
53
54
55
56

***** MODIFICATION HISTORY *****

REV A: ORIGINAL RELEASE GUY MICHELET 14 JAN 81

CVKMAA -> CNKMDA JAKI BERG 9 APR 84

CHANGES WERE MADE TO CVKMAA TO PRODUCE CNKMDA FOR THE FALCON-PLUS PROJECT
(SBC 11/21*). CHANGES, MARKED BY "JOB REV A-0", ARE:

- SET THE ODT BREAK VECTOR (LOCATION 140) TO THE STARTING ADDRESS OF
FALCON'S ODT ROM (170000-OCTAL).
- CHANGE PRIORITY LEVEL 7 TO LEVEL 6 TO ALLOW THE BREAK KEY TO INTERRUPT.

58
59
60
61
62
63
64
65
66
67
68
69
70
71
72
73
74
75
76
77
78
79
80
81
82
83
84
85
86
87
88
89
90
91
92
93
94
95
96
97
98
99
100
101
102
103
104
105
106
107
108
109

TABLE OF CONTENTS

- 1.0 INTRODUCTION
 - 1.1 PROGRAM ABSTRACT
 - 1.2 HARDWARE INTRODUCTION
- 2.0 HARDWARE REQUIREMENTS
- 3.0 PRELIMINARY PROGRAM REQUIREMENTS
- 4.0 GENERAL PROGRAM CONSIDERATIONS
 - 4.1 DIAGNOSTIC SUPERVISOR
 - 4.2 EXECUTION TIME
- 5.0 PROGRAM LOAD MEDIA
- 6.0 OPERATING INSTRUCTIONS
 - 6.1 LOADING AND STARTING PROCEDURES
 - 6.1.1 LOADING PROCEDURES
 - 6.1.2 STARTING PROCEDURES
 - 6.1.3 STEPS FOR QUICK AND SIMPLE EXECUTION
 - 6.2 INITIAL DIALOGUE
 - 6.3 PROGRAM OPTIONS
 - 6.3.1 START COMMAND
 - 6.3.2 RESTART COMMAND
 - 6.3.3 CONTINUE COMMAND
 - 6.3.4 PROCEED COMMAND
 - 6.3.5 ADD COMMAND
 - 6.3.6 DROP COMMAND
 - 6.3.7 PRINT COMMAND
 - 6.3.8 DISPLAY COMMAND
 - 6.3.9 FLAGS COMMAND
 - 6.3.10 ZFLAGS COMMAND
 - 6.3.11 CONTROL CHARACTERS
 - 6.3.12 HARDWARE PARAMETERS
 - 6.3.13 SOFTWARE PARAMETERS
 - 6.3.14 EXTENDED DISCUSSION OF P-TABLE DIALOGUE
- 7.0 TEST DESCRIPTIONS
- 8.0 ERROR INFORMATION
 - 8.1 ERROR REPORTING

111
112
113
114
115
116
117
118
119
120
121
122
123
124
125
126
127
128
129
130
131
132
133
134
135
136
137
138
139
140
141
142
143
144
145
146
147
148
149
150
151
152
153
154
155
156
157
158
159
160
161
162
163
164
165
166
167

1.0 INTRODUCTION

1.1 PROGRAM ABSTRACT

THIS DIAGNOSTIC WAS DESIGNED TO TEST OUT THE KMV11 MODULE.
THE PROGRAM WAS IMPLEMENTED USING THE DIAGNOSTIC SUPERVISOR.

THROUGH DIALOGUE WITH THE OPERATOR, THE PROGRAM WILL ALLOW
MODIFICATION OF DEVICE PARAMETERS, SUCH AS UNIBUS ADDRESS,
VECTOR ADDRESS, AND PRIORITY LEVEL.

1.2 HARDWARE INTRODUCTION

HARDWARE DESCRIPTION:

M7500 = KMV11-A MODULE
M7501 = KMV11-B MODULE

KMV11-A IS A SINGLE LINE COMMUNICATION CONTROLLER FOR QBUS SYSTEMS
KMV11-B IS A DUAL LINE COMMUNICATION CONTROLLER FOR QBUS SYSTEMS

DIAGNOSTIC DESCRIPTION:

THE KMV11 STATIC DIAGNOSTIC IS COMPATIBLE WITH BOTH KMV11 A/B
IT WILL RUN IN STAND ALONE WITHOUT ANY OPERATOR INTERVENTIONS

THE PURPOSE OF THIS DIAGNOSTIC IS TO TEST ALL THE HARDWARE OF
THE QBUS PART OF THE INTERFACE AND THE RAM PART OF THE KMV11.

THIS DIAGNOSTIC WILL FIRST TEST QBUS ACCESS ON KMV11A(M7500) AND
KMV11B(M7501) CSR'S REGISTERS, THEN DATA TRANSFER FROM QBUS
TO DCT11 MICROPROCESSOR.

AFTER THAT IT WILL TEST KMV11 RAM MEMORY, DMA TRANSFERS IN/OUT
KMV11 AND INTERRUPT CAPABILITY.

2.0 HARDWARE REQUIREMENTS

THE FOLLOWING HARDWARE IS REQUIRED TO RUN THE STATIC LOGIC
TESTS ON MODULES M7500 OR M7501:

SBC 11/21 +
16K MEMORY
CONSOLE TERMINAL
REAL TIME CLOCK

3.0 PRELIMINARY PROGRAM REQUIREMENTS

168
169
170
171
172
173
174
175
176
177
178
179
180
181
182
183
184
185
186
187
188
189
190
191
192
193
194
195
196
197
198
199
200
201
202
203
204
205
206
207
208
209
210
211
212
213
214
215
216
217
218
219
220
221
222
223
224

THE PROCESSOR AND MEMORY SHOULD BE THOROUGHLY TESTED PRIOR
TO RUNNING THIS DIAGNOSTIC.

```
*****  
*  
*       NOTE: THE KMV11 DIAGNOSTICS NKMDA AND NKMBA SHOULD BE  
*       BEFORE RUNNING NKMCA.  
*  
*****
```

4.0 GENERAL PROGRAM CONSIDERATIONS

4.1 DIAGNOSTIC SUPERVISOR

THIS PROGRAM IS COMPATIBLE WITH THE STANDALONE DIAGNOSTIC
SUPERVISOR, AND MUST BE LOADED TO BE CO-RESIDENT WITH THE
SUPERVISOR, OR BE PREVIOUSLY COMBINED WITH THE SUPERVISOR
AND LOADED AS A SINGLE FILE. IN EITHER CASE, THE COMBINED
PROGRAM WILL NOT EXCEED 16K OF MEMORY.

4.2 EXECUTION TIME

THE TOTAL TIME REQUIRED TO RUN THE M7500 OR M7501 STATIC
DIAGNOSTIC IS ABOUT 210 SECONDS PER PASS FOR EACH UNIT.

4.3 XXDP+

THIS PROGRAM MAY BE LOADED UNDER XXDP+, AND MAY BE RUN IN
DUMP MODE OR CHAIN MODE.

4.4 ACT/SLIDE

THIS PROGRAM MAY BE LOADED UNDER ACT OR SLIDE AND MAY BE RUN
IN DUMP MODE (FOR THAT DIAGNOSTIC MUST BE SETUP FIRST).

CAUTION: UNDER SLIDE THE OPERATOR MUST ALWAYS ANSWER "YES"
(THE FIRST TIME) FOR HARDWARE PARAMETERS CHANGE.

4.5 APT

THIS PROGRAM MAY BE LOADED BY THE APT SYSTEM (INCLUDING
APT-RD) AND RUN IN PROGRAM MODE OR SCRIPT MODE.

4.6 MEMORY MANAGEMENT

MEMORY MANAGEMENT IS NOT UTILIZED IN THIS PROGRAM. IF IT IS
INSTALLED, IT IS DISABLED BY THE PROGRAM.

4.7 MEMORY PARITY OPTION

225
226
227
228
229
230
231
232
233
234
235
236
237
238
239
240
241
242
243
244
245
246
247
248
249
250
251
252
253
254
255
256
257
258
259
260
261
262
263
264
265
266
267
268
269
270
271
272
273
274
275
276
277
278
279
280
281

IF PARITY MEMORY IS INSTALLED, MEMORY PARITY TRAPS ARE DISABLED BY THE PROGRAM.

4.8 ERROR LOGGING

THE NUMBER OF ERRORS WHICH HAVE OCCURRED ON EACH DEVICE UNDER TEST SINCE THE LAST START OR RESTART COMMAND IS KEPT IN AN ERROR LOG. THIS LOG MAY BE PRINTED BY USING THE "PRINT" COMMAND (SEE SECTION 6.3.8).

5.0 PROGRAM LOAD MEDIA

THIS PROGRAM CAN BE LOADED FROM PAPER TAPE USING THE ABSOLUTE LOADER OR FROM ACT, SLIDE, OR APT SYSTEMS, OR FROM ANY MEDIA SUPPORTED BY XXDP+. WHEN USING THE PAPER TAPE ABSOLUTE LOADER, THE PROGRAM SHOULD BE LOADED FIRST, FOLLOWED BY THE DIAGNOSTIC SUPERVISOR. WHEN USING XXDP+, THE DIAGNOSTIC SUPERVISOR SHOULD BE LOADED FIRST, FOLLOWED BY THE DIAGNOSTIC PROGRAM.

6.0 OPERATING INSTRUCTIONS

6.1 LOADING AND STARTING PROCEDURES

6.1.1 LOADING PROCEDURES

THIS PROGRAM MAY BE LOADED FROM PAPER TAPE USING THE ABSOLUTE LOADER. IT MAY ALSO BE LOADED FROM ANY XXDP+ LOAD MEDIA. WHEN LOADED UNDER XXDP+, THE DIAGNOSTIC SUPERVISOR WILL BE LOADED AUTOMATICALLY.

6.1.2 STARTING PROCEDURES

THE PROGRAM STARTS AT LOCATION 200. USE STANDARD DEC PROCEDURES TO START THE PROGRAM.

6.1.3 STEPS FOR QUICK AND SIMPLE EXECUTION

THE DIAGNOSTIC CAN BE EXECUTED STANDALONE UNDER XXDP+ WITHOUT READING THE REMAINDER OF THIS DOCUMENT. AS FOLLOWS:

- A) LOAD AND START DIAGNOSTIC USING RUN COMMAND
- B) RECEIVE DIAGNOSTIC SUPERVISOR PROMPT (DR>)
- C) ENTER STA<CR>
- D) ANSWER HARDWARE QUESTIONS
- E) GET END OF PASS MESSAGES OR ERROR MESSAGES
- F) TO END EXECUTION, ENTER CONTROL/C

282
283
284
285
286
287
288
289
290
291

6.2 INITIAL DIALOGUE

AFTER THE PROGRAM AND THE SUPERVISOR ARE LOADED AND THE PROGRAM IS STARTED , THE FOLLOWING IDENTIFICATION IS TYPED:

DRS LOADED
DIAG. RUN-TIME SERVICES
NKMDAO-A-O
KMV11A/B LOGIC DIAGNOSTIC
DR>

293
294
295
296
297
298
299
300
301
302
303
304
305
306
307
308
309
310
311
312
313
314
315
316
317
318
319
320
321
322
323
324
325
326
327
328
329
330
331
332
333
334
335
336
337
338
339
340
341
342
343
344
345
346
347
348
349

THE OPERATOR THEN PROCEEDS BY TYPING ONE OR MORE OF THE
COMMANDS DESCRIBED IN THE FOLLOWING SECTION 6.3. (FOR MORE
DETAILED INFORMATION, REFER TO THE DIAGNOSTIC SUPERVISOR
FUNCTIONAL SPECIFICATION).

6.3 PROGRAM OPTIONS

6.3.1 START COMMAND

```
*****
STA(RT)/TESTS:<TEST-LIST>/PASS:<PASS CNT>/FLAGS:
<FLAG-LIST>/EOP:<INCR>
*****
```

6.3.1.1 TESTS SWITCH (/TESTS:<TEST-LIST>)

<TEST-LIST> IS A SEQUENCE OF DECIMAL NUMBERS (1:2 ETC.) OR
RANGES OF DECIMAL NUMBERS (1-5:8-10 ETC.) THAT SPECIFY THE
TESTS TO BE EXECUTED. THE NUMBERS ARE SEPARATED BY COLONS.
THE NUMBERS RANGE FROM 1 TO THE LARGEST TEST NUMBER IN THE
DIAGNOSTIC. THEY MAY BE SPECIFIED IN ANY ORDER. TESTS WILL
BE EXECUTED IN NUMERICAL ORDER REGARDLESS OF THE ORDER OF
SPECIFICATION. THE DEFAULT IS TO EXECUTE ALL TESTS. ON
THIS AND ALL SWITCHES, THE ANGLE BRACKETS <> ARE PUNCTUATION
USED IN THE DEFINITION ONLY, AND ARE NOT TO BE TYPED BY THE
OPERATOR. SEE EXAMPLE AT END OF 6.3.1.5.

6.3.1.2 PASS SWITCH (/PASS:<PASS-CNT>)

<PASS-CNT> IS A DECIMAL NUMBER INDICATING THE DESIRED NUMBER
OF PASSES. A PASS IS DEFINED AS THE EXECUTION OF THE FULL
DIAGNOSTIC (ALL SELECTED TESTS) AGAINST ALL UNITS SUBMITTED.
THE DEFAULT IS NON-ENDING EXECUTION. IN THIS CASE EXIT FROM
THE PROGRAM IS ACCOMPLISHED EITHER BY TYPING A CONTROL/C OR
BY OCCURENCE OF AN ERROR WITH THE HALT ON ERROR FLAG BEING
SET. THE EXIT IS A RETURN TO COMMAND MODE. SEE EXAMPLE AT
END OF 6.3.1.5.

6.3.1.3 FLAGS SWITCH (/FLAGS:<FLAG-LIST>)

<FLAG-LIST> IS A SEQUENCE OF ELEMENTS OF THE FORM <FLAG>,
<FLAG=1>, OR <FLAG=0>, SEPARATED BY COLONS, WHERE <FLAG> HAS
ONE OF THE FOLLOWING VALUES:

```
HOE  HALT ON ERROR, CAUSING COMMAND MODE TO BE
      ENTERED WHEN AN ERROR IS ENCOUNTERED
LOE  LOOP ON ERROR, CAUSING THE DIAGNOSTIC TO LOOP
```


351
352
353
354
355
356
357
358
359
360
361
362
363
364
365
366
367
368
369
370
371
372
373
374
375
376
377
378
379
380
381
382
383
384
385
386
387
388
389
390
391
392
393
394
395
396
397
398
399
400
401
402
403
404
405

CONTINUOUSLY WITHIN THE SMALLEST DEFINED BLOCK
OF CODING (SEGMENT, SUBTEST, OR TEST) CONTAIN-
ING THE ERROR

IER INHIBIT ERROR REPORTING
IBE INHIBIT BASIC ERROR REPORTS
IXE INHIBIT EXTENDED ERROR REPORTS
PRI DIRECT ALL MESSAGES TO A LINE PRINTER
PNT PRINT NUMBER OF TEST BEING EXECUTED
BOE BELL ON ERROR
UAM RUN IN UNATTENDED MODE, BYPASSING MANUAL
INTERVENTION TESTS
ISR INHIBIT STATISTICAL REPORTS
IDU INHIBIT DROPPING OF UNITS BY DIAGNOSTIC
LOT LOOP ON TEST

THE FLAGS NAMED OR EQUATED TO 1 ARE SET, THOSE EQUATED TO 0
ARE CLEARED. A FLAG NOT SPECIFIED IS CLEARED. IF THE FLAGS
SWITCH IS NOT GIVEN ALL FLAGS ARE CLEARED. SEE EXAMPLE AT
END OF 6.3.1.5.

6.3.1.4 END OF PASS SWITCH (/EOP:<INCR>)

<INCR> IS A DECIMAL NUMBER INDICATING HOW OFTEN (IN TERMS OF
PASSES) IT IS DESIRED THAT THE END OF PASS MESSAGE BE
PRINTED. THE DEFAULT IS AT THE END OF EVERY PASS. SEE
EXAMPLE AT END OF 6.3.1.5.

6.3.1.5 EFFECT OF START COMMAND

THE EFFECT OF THE START COMMAND IS TO INITIATE THE HARDWARE
PARAMETER DIALOGUE, THE SOFTWARE PARAMETER DIALOGUE, AND
THEN THE DIAGNOSTIC TESTS THEMSELVES.

THE HARDWARE PARAMETER DIALOGUE COMMENCES WITH THE QUESTION
"N UNITS?" TO WHICH THE OPERATOR REPLIES WITH A DECIMAL
NUMBER N FROM 1 TO 16. THE TERM "UNIT" REFERS TO THE DEVICE
TO WHICH THIS SERIES OF DIAGNOSTICS IS DEDICATED. FOLLOWING
THIS ARE THE QUESTIONS WHEREBY THE P-TABLES THEMSELVES WILL
BE BUILT. EACH P TABLE IS A CORE-RESIDENT TABLE CONTAINING
ALL THE HARDWARE INFORMATION FOR ONE UNIT. THE OPERATOR
MUST SUPPLY N (NUMBER OF UNITS) VALUES FOR EACH QUESTION.
HE MAY DO THIS BY GIVING ONE ANSWER TO EACH QUESTION (IN
WHICH CASE THE SERIES OF QUESTIONS WILL BE POSED N TIMES) OR
BY GIVING N VALUES, SEPARATED BY COMMAS, TO EACH QUESTION
(SERIES WILL BE POSED ONCE). EACH QUESTION IS FOLLOWED BY
THE RESPONSE RADIX (D FOR DECIMAL, B FOR BINARY, Q FOR
OCTAL, L FOR YES/NO) IN PARENTHESES AND THE DEFAULT VALUE
AFTER THE PARENTHESES.

407
408
409
410
411
412
413
414
415
416
417
418
419
420
421
422
423
424
425
426
427
428
429
430
431
432
433
434
435
436
437
438
439
440
441
442
443
444
445
446
447
448
449
450
451
452
453
454
455
456
457
458
459
460
461

FOLLOWING THE HARDWARE QUESTIONS ARE THE SOFTWARE QUESTIONS TO BUILD THE SOFTWARE TABLES, WHICH DEFINE THE MODE (QUICK VERIFY ETC.) THAT THE DIAGNOSTIC WILL EXECUTE IN.

WHEN THE QUESTION "# UNITS?" IS ANSWERED, MEMORY STORAGE IS ALLOCATED FOR THE P-TABLES, AND IF THERE IS NOT ENOUGH TO ACCOMMODATE THEM THE MESSAGE "TOO MANY UNITS" IS ISSUED. IN THIS CASE THE DIAGNOSTIC MUST BE EXECUTED MORE THAN ONCE TO TEST ALL UNITS.

EXAMPLE:

STA/TESTS:1:2-4:6:8-10/PASS:3/FLAGS:IER:HOE=1:UAM:L.OE

THIS COMMAND WILL CAUSE THREE PASSES TO BE MADE, EACH PASS CONSISTING OF TESTS 1,2,3,4,6,8,9, AND 10 EXECUTED AGAINST ALL UNITS. THERE IS NO DIFFERENCE BETWEEN SAYING <FLAG> AND SAYING <FLAG=1>. THE NOTATION <FLAG=0> IS MEANINGFUL ONLY ON A COMMAND OTHER THAN START TO CLEAR A FLAG THAT WAS PREVIOUSLY SET. NOTE THAT ON ALL COMMANDS ONLY THE FIRST THREE LETTERS ARE SCANNED.

6.3.2 RESTART COMMAND

```
*****  
RES(TART)/TESTS:<TEST-LIST>/PASS:<PASS-CNT>/FLAGS:  
  <FLAG-LIST>/UNITS.<UNIT-LIST>  
*****
```

6.3.2.1 TESTS, PASS, AND FLAGS SWITCHES

<TEST-LIST>, <PASS-CNT>, AND <FLAG-LIST> ARE AS IN THE START COMMAND.

6.3.2.2 UNITS SWITCH (/UNITS:<UNIT-LIST>)

<UNIT-LIST> IS A SEQUENCE OF DECIMAL NUMBERS (0,1 ETC.) OR RANGES OF DECIMAL NUMBERS (0-5, 8-10 ETC.) THAT SPECIFY THE UNITS TO BE TESTED. THE NUMBERS ARE SEPARATED BY COLONS. THE NUMBERS MAY RANGE FROM 0 THRU N-1 (N IS THE NUMBER OF UNITS SPECIFIED IN THE PREVIOUS START COMMAND). THE NUMBER INDICATES THE POSITION OF THE P-TABLE AS THE DATA WAS ENTERED DURING THE HARDWARE DIALOGUE. THE UNITS WHICH ARE SELECTED MUST NOT HAVE BEEN DROPPED BY THE DROP COMMAND. SEE THE DISCUSSION OF ADD AND DROP COMMANDS BELOW. DEFAULT IS TO TEST ALL UNITS WHICH HAVE NOT BEEN DROPPED BY A DROP COMMAND.

463
464
465
466
467
468
469
470
471
472
473
474
475
476
477
478
479
480
481
482
483
484
485
486
487
488
489
490
491
492
493
494
495
496
497
498
499
500
501
502
503
504
505
506
507
508
509
510
511
512
513
514
515
516

6.3.2.3 EFFECT OF RESTART COMMAND

THE RESTART COMMAND DIFFERS FROM THE START COMMAND IN THAT THE P-TABLES FROM THE PREVIOUS START COMMAND (THERE MUST HAVE BEEN ONE) ARE USED, INSTEAD OF NEW ONES BEING BUILT. THE UNITS SWITCH GIVES THE ABILITY TO SELECT A SUBSET OF THESE. THE SOFTWARE DIALOGUE MAY OPTIONALLY BE REEXECUTED (OPERATOR WILL BE ASKED). THE COMMAND CAN BE USED AFTER COMMAND MODE HAS BEEN REENTERED IN ANY OF THE THREE NORMAL WAYS: A) THE REQUESTED NUMBER OF PASSES HAVE BEEN MADE B) AN ERROR WAS ENCOUNTERED WITH THE HALT ON ERROR FLAG SET C) A CONTROL/C WAS ENTERED BY THE OPERATOR.

6.3.3 CONTINUE COMMAND

```
*****  
CON(TINUE)/PASS:<PASS-CNT/FLAGS:<FLAG-LIST>  
*****
```

6.3.3.1 PASS SWITCH (/PASS:<PASS-CNT>)

<PASS-CNT> IS SAME AS IN START COMMAND, BUT THE DEFAULT IS THE UNSATISFIED PASS-CNT FROM THE PREVIOUS START OR RESTART. IF NONE REMAINS, THE DEFAULT IS NON-ENDING EXECUTION.

6.3.3.2 FLAG SWITCH (/FLAGS:<FLAG-LIST>)

<FLAG-LIST> IS SAME AS IN START COMMAND, BUT UNSPECIFIED FLAGS RETAIN THEIR CURRENT VALUE.

6.3.3.3 EFFECT OF CONTINUE COMMAND

CONTINUE MUST FOLLOW A START OR RESTART, AND COMMAND MODE MUST HAVE BEEN ENTERED DUE TO A HALT ON ERROR OR A CONTROL/C. THE EFFECT OF THE COMMAND IS TO GO TO THE BEGINNING OF THE TEST THAT WAS BEING EXECUTED WHEN THE HALT OR CONTROL/C TOOK PLACE. SOFTWARE DIALOGUE MAY OPTIONALLY BE REEXECUTED. HARDWARE PARAMETERS MAY NOT BE CHANGED.

6.3.4 PROCEED COMMAND

```
*****  
PRO(CEED)/FLAGS:<FLAG-LIST>  
*****
```

518
519
520
521
522
523
524
525
526
527
528
529
530
531
532
533
534
535
536
537
538
539
540
541
542
543
544
545
546
547
548
549
550
551
552
553
554
555
556
557
558
559
560
561
562
563
564
565
566
567
568
569
570
571
572

6.3.4.1 FLAGS SWITCH (/FLAGS:<FLAG-LIST>)

<FLAG-LIST> IS AS IN THE START COMMAND, BUT UNSPECIFIED
FLAGS RETAIN THEIR CURRENT VALUE.

6.3.4.2 EFFECT OF PROCEED COMMAND

PROCEED MUST FOLLOW A START, RESTART, OR CONTINUE. COMMAND
MODE MUST HAVE BEEN ENTERED VIA A HALT ON ERROR. THE EFFECT
OF THE COMMAND IS TO BEGIN EXECUTION AT THE LOCATION
FOLLOWING THE ERROR CALL. NEITHER HARDWARE NOR SOFTWARE
PARAMETERS MAY BE ALTERED.

6.3.5 ADD COMMAND

ADD/UNITS:<UNIT-LIST>

6.3.5.1 UNITS SWITCH (/UNITS:<UNIT-LIST>)

<UNIT-LIST> IS AS IN THE RESTART COMMAND.

6.3.5.2 EFFECT OF ADD COMMAND

THE UNITS SPECIFIED ARE ADDED TO THE TEST SEQUENCE. EACH
UNIT MUST HAVE A P-TABLE IN MEMORY DUE TO AN EARLIER
HARDWARE DIALOGUE. THIS COMMAND MUST BE FOLLOWED BY A
RESTART OR CONTINUE. THE UNITS SWITCH MUST BE SPECIFIED.
THE ADD COMMAND IS MEANINGFUL ONLY FOR UNITS THAT WERE
PREVIOUSLY DROPPED.

6.3.6 DROP COMMAND

DRO(P)/UNITS:<UNIT-LIST>

6.3.6.1 UNITS SWITCH (/UNITS:<UNIT-LIST>)

<UNIT-LIST> IS AS IN THE RESTART COMMAND.

6.3.6.2 EFFECT OF DROP COMMAND

574
575
576
577
578
579
580
581
582
583
584
585
586
587
588
589
590
591
592
593
594
595
596
597
598
599
600
601
602
603
604
605
606
607
608
609
610
611
612
613
614
615
616
617
618
619
620
621
622
623
624
625
626
627
628

THE UNITS SPECIFIED WILL BE DROPPED FROM TESTING. THE UNITS WILL BE RESELECTED ONLY BY THE EXECUTION OF AN ADD OR START COMMAND. THE UNITS SWITCH MUST BE ENTERED. THIS COMMAND MUST BE FOLLOWED BY A RESTART OR A CONTINUE COMMAND.

6.3.7 PRINT COMMAND

```
*****
PRI(NT)
*****
```

6.3.7.1 EFFECT OF PRINT COMMAND

THE TOTAL NUMBER OF ERRORS FOR EACH UNIT SINCE THE LAST START OR RESTART COMMAND ARE PRINTED. THE ISR (INHIBIT STATISTICAL REPORTING) FLAG IS CLEARED.

6.3.8 DISPLAY COMMAND

```
*****
DIS(PLAY)/UNITS:<UNIT-LIST>
*****
```

6.3.8.1 UNITS SWITCH (/UNITS:<UNIT-LIST>)

<UNIT-LIST> IS AS IN THE RESTART COMMAND.

6.3.8.2 EFFECT OF DISPLAY COMMAND

THE HARDWARE P-TABLES FOR ALL UNITS UNDER TEST ARE PRINTED OUT IN THE FORMAT IN WHICH THEY WERE ENTERED. ANY UNITS THAT WERE DROPPED BY THE OPERATOR "DROP" COMMAND ARE SO DESIGNATED.

6.3.9 FLAGS COMMAND

```
*****
FLA(GS)
*****
```

6.3.9.1 EFFECT OF FLAGS COMMAND

THE CURRENT SETTINGS OF ALL FLAGS ARE PRINTED.

630
631
632
633
634
635
636
637
638
639
640
641
642
643
644
645
646
647
648
649
650
651
652
653
654
655
656
657
658
659
660
661
662
663
664
665
666
667
668
669
670
671
672
673
674
675
676
677
678
679
680
681

6.3.10 ZFLAGS COMMAND

ZFL(AGS)

6.3.10.1 EFFECT OF ZFLAGS COMMAND

ALL FLAGS ARE CLEARED.

6.3.11 CONTROL CHARACTERS

A CONTROL C (C) ENTERED DURING THE EXECUTION OF A DIAGNOSTIC CAUSES A RETURN TO COMMAND MODE.

A CONTROL Z (Z) ENTERED DURING ONE OF THE THREE OPERATOR DIALOGUES- INITIAL DIALOGUE (SEE 6.2), HARDWARE DIALOGUE (SEE 6.3.1.5), OR SOFTWARE DIALOGUE (SEE 6.3.1.5) CAUSES THE DEFAULTS TO BE TAKEN FOR THE REMAINDER OF THAT DIALOGUE.

A CONTROL O (O) ENTERED DURING THE EXECUTION OF A DIAGNOSTIC CAUSES ALL TELETYPE OUTPUT TO BE SUPPRESSED FOR THE REMAINDER OF THE DIAGNOSTIC OR UNTIL ANOTHER O IS TYPED, WHICH RESTORES NORMAL TELETYPE OUTPUT.

6.3.12 HARDWARE PARAMETERS

THE FOLLOWING QUESTIONS WILL BE ASKED ON A START COMMAND. THE VALUE LOCATED TO THE LEFT OF THE QUESTION MARK IS THE DEFAULT VALUE THAT WILL BE TAKEN ON A CARRIAGE RETURN RESPONSE.

2. MICRO-CPU CSR ADDRESS: (O) 177000?

THIS IS THE ADDRESS AT WHICH THE CSR REGISTERS (SELO) RESIDE ON THE UNIBUS. THE ALLOWABLE RANGE IS 160000-177776 (OCTAL), AND THE DEFAULT IS 177000.

3. MICRO CPU VECTOR ADDRESS: (O) 300?

THE ALLOWABLE RANGE IS 300-770, AND DEFAULT VALUE IS 300

683
684
685
686
687
688
689
690
691
692
693
694
695
696
697
698
699
700
701
702
703
704
705
706
707
708
709
710
711
712
713
714
715
716
717
718
719
720
721
722
723
724
725
726
727
728
729
730
731
732
733
734
735
736
737
738

4. MICRO CPU PRIORITY LEVEL; (4) ??

DEFFAULT VALYE IS 4

NOTE:

M7500 AND M7501 MODULE MOUNTED WITH UC003 CHIPS CAN ONLY
INTERUPT ON LEVEL 4

6.3.13 SOFTWARE PARAMETERS

NO SOFTWARE PARAMETER QUESTIONS ARE ASKED IN THAT
STATIC LOGIC TESTS.

6.3.14 EXTENDED DISCUSSION OF P-TABLE DIALOGUE

THE FULL CAPABILITY OF THE HARDWARE DIALOGUE IS REVEALED BY
THE FOLLOWING DISCUSSION OF WHAT HAPPENS INTERNALLY.

AS SOON AS THE QUESTION "N UNITS?" IS ANSWERED (WITH THE
NUMBER N, SAY) SPACE IN CORE IS ALLOCATED FOR N P-TABLES.
ALL OF THE P-TABLES ARE OF THE SAME FORMAT, AND THERE IS A
ONE-TO ONE CORRESPONDENCE BETWEEN THE HARDWARE PARAMETER
QUESTIONS AND THE SLOTS IN THE P-TABLE FORMAT.

ON THE FIRST TRIP THRU THE QUESTIONS, ALL OF THE SLOTS IN
ALL OF THE P-TABLES ARE FILLED. IF THE OPERATOR TYPES IN
LESS THAN N EXPLICIT VALUES IN RESPONSE TO A PARTICULAR
QUESTION, THESE VALUES ARE PLACED IN THE P-TABLES (ONE VALUE
GOING INTO THE PROPER SLOT OF EACH P-TABLE BEGINNING WITH
THE FIRST P-TABLE) UNTIL THE STRING OF VALUES IS EXHAUSTED.
THE LAST VALUE IN THE STRING BECOMES THE NEW DEFAULT AND IS
USED TO FILL THAT SLOT IN THE REMAINING P-TABLES.

ON SUBSEQUENT TRIPS THRU THE QUESTIONS, THE SAME PROCESS IS
CARRIED OUT, EXCEPT THAT THE EARLIEST P-TABLE NOT TO HAVE
RECEIVED AN EXPLICIT VALUE IN ANY OF ITS SLOTS NOW ASSUMES
THE ROLE THAT TABLE NUMBER ONE PLAYED IN THE FIRST TRIP.

THE SERIES OF QUESTIONS IS REISSUED UNTIL AT LEAST ONE
QUESTION HAS RECEIVED N EXPLICIT VALUES FROM THE OPERATOR.

IN GIVING A STRING OF VALUES, COMMAS WITHOUT INTERVENING
VALUES MAY BE USED TO INDICATE A REPETITION OF THE LAST
NAMED VALUE.

A STRING OF VALUES MAY BE GIVEN AS A RANGE (6-10 FOR
EXAMPLE). IF THE VALUES REPRESENT PURE NUMERICAL DATA, THIS
SAMPLE RANGE TRANSLATES TO THE STRING 6,7,8,9,10 (AN
INCREMENT OF 1). IF THE VALUES ARE ADDRESSES, THE SAMPLE
RANGE TRANSLATES TO THE STRING 6,8,10 (AN INCREMENT OF 2).

740
741
742
743
744
745
746
747
748
749
750
751
752
753
754
755
756
757
758
759
760
761
762
763
764
765
766
767
768
769
770
771
772
773
774
775
776
777
778
779
780
781
782
783
784
785
786
787
788

NOW LET US SEE HOW WE COULD USE THESE CAPABILITIES TO CONSTRUCT A SET OF P-TABLES. ASSUME THAT WE HAVE 16 UNITS, AND THAT THERE ARE THREE HARDWARE PARAMETERS FOR EACH (THREE SLOTS IN THE P-TABLE, THREE HARDWARE QUESTIONS IN THE DIALOGUE). LET THE DESIRED VALUE FOR THE FIRST PARAMETER BE THE NUMBER 75 FOR ALL 16 TABLES. LET THE DESIRED VALUE FOR THE SECOND PARAMETER BE EQUAL TO THE UNIT NUMBER (0,1,2,...,15) EXCEPT FOR UNIT 12, WHICH SHOULD RECEIVE THE VALUE 11. LET THE DESIRED VALUE FOR THE THIRD PARAMETER BE THE NUMBER 76 FOR THE FIRST 7 UNITS AND THE NUMBER 77 FOR THE LAST 9 UNITS.

THE FOLLOWING DIALOGUE WOULD ACCOMPLISH THIS GOAL:

♦ UNITS (D) ? 16

UNIT 1

<QUESTION 1> ? 75

<QUESTION 2> ? 0-6

<QUESTION 3> ? 76

UNIT 21

<QUESTION 1> ?

<QUESTION 2> ? 7-11..13-15

<QUESTION 3> ? 77

THE FIRST TIME THE SERIES IS ASKED, SLOT ONE RECEIVES A 75 IN ALL 16 TABLES. SLOT TWO RECEIVES THE VALUES 0,1,2,...,6 IN TABLES 0 THRU 6 AND A CONSTANT 6 IN TABLES 7 THRU 15. SLOT THREE RECEIVES A CONSTANT 76 IN ALL 16 TABLES.

THE SECOND TIME THRU THE SERIES, TABLES 16 THRU THE END ARE GOING TO BE AFFECTED (NOTE THAT THIS PIECE OF INFORMATION IS PRINTED OUT FOR THE THE OPERATOR IN THE FORM "UNIT XX" AT THE BEGINNING OF EACH SERIES). QUESTION 1 IS RESPONDED TO BY A <CR>, SO SLOT ONE STAYS AT CONSTANT 75 IN TABLES 7 THRU 15, SINCE NO NEW EXPLICIT VALUES ARE TYPED IN. SLOT TWO GETS THE VALUES 7,8,9,10,11 IN TABLES 7 THRU 11, AND GETS A 11 IN SLOT 12, AND GETS THE VALUES 13,14,15 IN TABLES 13 THRU 15. SLOT THREE GETS THE VALUE 77 IN TABLES 7 THRU 15.

THE DIALOGUE IS TERMINATED WHEN THE SOFTWARE RECOGNIZES THAT 16 EXPLICIT VALUES HAVE BEEN GIVEN FOR AT LEAST ONE QUESTION (NAMELY QUESTION 2).

790
791
792
793
794
795
796
797
798
799
800
801
802
803
804
805
806
807
808
809
810
811
812
813
814
815
816
817
818
819
820
821
822
823
824
825
826
827
828
829
830
831
832
833
834
835
836
837
838
839
840
841
842
843
844
845
846

7.0 TEST DESCRIPTIONS

***** TEST 1 *****
*VERIFY THAT REFERENCED QBUS DEVICE REGISTERS
*DO NOT CAUSE TIME OUT TRAP

***** TEST 2 *****
*
*CLEAR ALL KMV11 REGISTERS AND CHECK
*

***** TEST 3 *****
*
*CHECK QBUS ACCESS ON KMV11 REGISTERS (FROM SEL2 TO SEL16)
*

***** TEST 4 *****
*
*CHECK Q BUS ACCESS ON REGISTER SELO
*

***** TEST 5 *****
*
*CHECK Q BUS BYTE ACCESS ON ALL KMV11 REGISTERS
*

***** TEST 6 *****
*
*DATA TRANSFER TO REGISTER SEL. 2
*

***** TEST 7 *****
*
*DATA TRANSFER TO REGISTER SEL. 4
*

847
848
849
850
851
852
853
854
855
856
857
858
859
860
861
862
863
864
865
866
867
868
869
870
871
872
873
874
875
876
877
878
879
880
881
882
883
884
885
886
887
888
889
890
891
892
893
894
895
896
897
898
899
900
901
902
903

***** TEST 8 *****
*
*DATA TRANSFER TO REGISTER SEL 6
*

***** TEST 9 *****
*
*DATA TRANSFER TO REGISTER SEL 10
*

***** TEST 10 *****
*
*DATA TRANSFER TO REGISTER SEL 12
*

***** TEST 11 *****
*
*DATA TRANSFER TO REGISTER SEL 14
*

***** TEST 12 *****
*
*DATA TRANSFER TO REGISTER SEL 16
*

***** TEST 13 *****
*
*CHECK DATA TRASFERS USING ALL CSR'S REGISTERS
*

***** TEST 14 *****
*
*KMV11 RAM MEMORY TEST: MEMORY PATTERN TEST
*

***** TEST 15 *****
*
*KMV11 RAM MEMORY TEST: MEMORY ADDRESS TEST
*

904
905
906
907
908
909
910
911
912
913
914
915
916
917
918
919
920
921
922
923
924
925
926
927
928
929
930
931
932
933
934
935
936
937
938
939
940
941
942
943
944
945
946
947
948
949
950
951
952
953
954
955
956
957
958

```
***** TEST 16 *****
*
* KMV11 RAM MEMORY TEST: MEMORY ADDRESS COMPLEMENT TEST
*
*****

***** TEST 17 *****
*
* CHECK PROM REVISION
*
*****

***** TEST 18 *****
*
* PROM CHECKSUM TEST
*
*****

***** TEST 19 *****
*
* DMA TRANSFER INTO KMV11
*
*****

***** TEST 20 *****
*
* TEST DMA TRANSFERS OUT KMV11
*
*****

***** TEST 21 *****
*
* TEST DMA TRANSFERS IN BOTH DIRECTION
*
*****

***** TEST 22 *****
*
* TEST INTERRUPT CAPABILITY OF KMV11 MODULE ON QBUS
*
*****

***** TEST 23 *****
*
* TEST INTERRUPT ON DCT11 MICROPROCESSOR
*
*****
```

960
961
962
963
964
965
966
967
968
969
970
971
972
973
974
975
976
977
978
979
980
981
982
983
984
985
986
987
988
989
990
991
992
993
994
995
996
997
998
999
1000
1001
1002
1003
1004
1005
1006

8.0 ERROR INFORMATION

8.1 ERROR REPORTING

ERRORS ARE REPORTED BY THE PROGRAM AS THEY OCCUR (IF NOT INHIBITED). THE REPORT CONFORMS TO THE DIAGNOSTIC SUPERVISOR ERROR REPORT FORMAT, AND CONSISTS OF A DESCRIPTION OF THE ERROR, THE TEST NUMBER, SUBTEST NUMBER, PC OF THE ERROR CALL, DEVICE ADDRESS, AND BASIC AND EXTENDED ERROR INFORMATION.

THE FOLLOWING EXAMPLES PROVIDE TYPICAL ERROR REPORTS:

```
;CZDMQ DVC FTL ERR 00045 TST 027 SUB 000 PC:022572
;MASTER CLEAR FAILED TO CLEAR PC REG. CONTENTS=000624
;CZDMQ DVC FTL ERR 00015 TST 042 SUB 000 PC:027234
;UNIT=00, FAILING UNIT ADDRESS=160170
;JUMP TEST ERROR
;FROM ADDR      TO ADDR      BAD ADDR
;000402         000000        000114
```

FOR ALL OTHER ERRORS, THE REPORT MAY BE MORE EXTENSIVE AND REQUIRE ADDITIONAL DATA TO BE REPORTED.

9.0 HISTORY

- DESIGN STARTED ON JANUARY 82
- REVIEW ON DECEMBER 82

@

```

1008          .TITLE KMV11 A/B LOGIC DIAG
1016          002000          .*2000
1017
1018
1019
1020
1021
1022
1023          .MCALL  SVC
1024 002000          SVC          ; INITIALIZE SUPERVISOR MACROS
1025
1026
1027
1028
1029
1030 002000          BGNMOD  KMV11A.B
1031
1032
1033          000000          $LSTIN= 0
1034          000000          $LSTTAG= 0
1035          177777          SVCINS= -1      ; LIST INSTRUCTIONS, SHIFTED RIGHT
1036          177777          SVCTST= -1     ; LIST TEST TAGS, SHIFTED RIGHT
1037          177777          SVCSUB= -1    ; LIST SUBTEST TAGS, SHIFTED RIGHT
1038          177777          SVCGBL= -1   ; LIST GLOBAL TAGS, SHIFTED RIGHT
1039          177777          SVCTAG= -1   ; LIST OTHER TAGS, SHIFTED RIGHT
1040
1041          ;      CHANGE THE VALUES OF THE SVC... SYMBOLS TO BE ZERO IF YOU WISH
1042          ;      TO ALIGN THE MACRO CALLS AND THEIR EXPANSIONS.  CHANGE THE
1043          ;      SYMBOLS TO BE MINUS-ONE TO NOT LIST THE EXPANSIONS.  YOU MAY
1044          ;      CHANGE THE SYMBOLS AT ANY POINT IN YOUR PROGRAM.
1045
1046

```

```
1048      .SBTTL PROGRAM HEADER
1049      ;**
1050      ; THE PROGRAM HEADER IS THE INTERFACE BETWEEN
1051      ; THE DIAGNOSTIC PROGRAM AND THE SUPERVISOR.
1052      ;--
1053
1054 002000      POINTER BGNSW,BGNDU,BGNSETUP
1055
1056
1057
1075
1076 002000      HEADER NKMDAO,A,0,240.,0
1077
1078
1089
1090
1091
1092
1093      ;*****
1094
1095
1096
1097
1098
1099      ;**
1100      ; THIS TABLE IS USED BY THE RUNTIME SERVICES
1101      ; TO PROTECT THE LOAD MEDIA.
1102      ;--
1103
1104 002122      BGNPROT
1105
1106 002122 000000      0          ;OFFSET INTO P-TABLE FOR CSR ADDRESS
1107 002124 177777      -1        ;OFFSET INTO P-TABLE FOR MASSBUS ADDRESS
1108 002126 177777      -1        ;OFFSET INTO P-TABLE FOR DRIVE NUMBER
1109
1110
1124
1125
1126 002130      ENDPROT
1127
```

```
1129 .SBTTL DISPATCH TABLE
1130
1131 ;////////////////////////////////////
1132 ;// THE DISPATCH TABLE CONTAINS THE STARTING ADDRESS OF EACH TEST.
1133 ;// IT IS USED BY THE SUPERVISOR TO DISPATCH TO EACH TEST.
1134 ;////////////////////////////////////
1135
1136 002130 DISPATCH 23
1137
1144
1145
1146
1147
1148
1149
1150
1151 ;*****
1152
1153
1154
1155
1156
1157
1158
1159
1160 .SBTTL DEFAULT HARDWARE P-TABLE
1161
1162 ;////////////////////////////////////
1163 ;// THE DEFAULT HARDWARE P-TABLE CONTAINS DEFAULT VALUES OF
1164 ;// THE TEST-DEVICE PARAMETERS. THE STRUCTURE OF THIS TABLE
1165 ;// IS IDENTICAL TO THE STRUCTURE OF THE RUN-TIME P-TABLE.
1166 ;// AND IS USED AS A "TEMPLATE" FOR BUILDING THE P-TABLE.
1167 ;////////////////////////////////////
1168
1169 .ENABL AMA
1170 002210 BGNHW DFPTBL
1171
1181
1182
1183 002212 177000 .WORD 177000 ;KMV11,CSRS ADDRESS
1184 002214 000300 .WORD 300 ;KMV11, VECTOR ADDRESS
1185 002216 004000 .WORD 4000 ;INTERRUPT PRIORITY LEVEL (4)
1186 002220 000001 .WORD 1
1187
1188 002222 ENDPHW
```

1190
1191
1192
1193
1194
1195
1196
1197
1198
1199
1200
1201
1202
1212
1213
1228
1229 002222

.SBTTL GLOBAL EQUATES SECTION

;/;;;/
;/ THE GLOBAL EQUATES SECTION CONTAINS PROGRAM EQUATES THAT
;/ ARE USED IN MORE THAN ONE TEST.
;/;;;/

EQUALS

; BIT DEFINITIONS

100000	BIT15**	100000
040000	BIT14**	40000
020000	BIT13**	20000
010000	BIT12**	10000
004000	BIT11**	4000
002000	BIT10**	2000
001000	BIT09**	1000
000400	BIT08**	400
000200	BIT07**	200
000100	BIT06**	100
000040	BIT05**	40
000020	BIT04**	20
000010	BIT03**	10
000004	BIT02**	4
000002	BIT01**	2
000001	BIT00**	1

; BIT9** BIT09
BIT8** BIT08
BIT7** BIT07
BIT6** BIT06
BIT5** BIT05
BIT4** BIT04
BIT3** BIT03
BIT2** BIT02
BIT1** BIT01
BIT0** BIT00

; EVENT FLAG DEFINITIONS
; EF32:EF17 RESERVED FOR SUPERVISOR TO PROGRAM COMMUNICATION

000040	EF.START**	32.	; BIT POSITION IN SECOND STATUS WORD
000037	EF.RESTART**	31.	; (100000) START COMMAND WAS ISSUED
000036	EF.CONTINUE**	30.	; (040000) RESTART COMMAND WAS ISSUED
000035	EF.NEW**	29.	; (020000) CONTINUE COMMAND WAS ISSUED
000034	EF.PWR**	28.	; (010000) A NEW PASS HAS BEEN STARTED
			; (004000) A POWER-FAIL/POWER-UP OCCURRED


```

;
; PRIORITY LEVEL DEFINITIONS
;
000340      PRI07== 340
000300      PRI06== 300
000240      PRI05== 240
000200      PRI04== 200
000140      PRI03== 140
000100      PRI02== 100
000040      PRI01== 40
000000      PRI00== 0
;
; OPERATOR FLAG BITS
;
000004      EVL==      4
000010      LOT==     10
000020      ADR==     20
000040      IDU==     40
000100      ISR==    100
000200      UAM==    200
000400      BOE==    400
001000      PNT==   1000
002000      PRI==   2000
004000      IXE==   4000
010000      IBE==  10000
020000      IER==  20000
040000      LOE==  40000
100000      HOE== 100000
;
1230
1231
1232      ;MAXPRI==340
1233      000300      MAXPRI==300
1234
1235      054000      MAINT0==54000
1236      044000      MAINT1==44000
1237      040000      MCLR==40000
1238      052525      DATA1== 052525
1239      125252      DATA2== 125252
1240
1241
1242      ;*****
1243      ;* PROGRAM EVENT FLAG DEFINITIONS
1244      ;*****
1245
1246
1247
;MASTER CLEAR = 1,MODE = 1 ,MAINT 1 = 1 ,T11=HOLD
;MASTER CLEAR = 1,MODE = 0 ,MAINT 1 = 0 ,T11=NOT HOLD
;JB REV A-0
;JB REV A-0
```

N2

1249
1250
1251
1252
1253
1254
1255
1261
1262
1263
1264
1265
1266 002222
1267
1268
1269
1282
1283 002256
002256 000000
002260 000000
002262 000000
002264 000000
1284
1285
1286
1287
1288
1289
1290
1291 002266 000000
1292 002270 000015
1293 002272 000000
1294 002274 000000
1295 002276 000005
1296 002300 000000
1297 002302 000000
1298 002304 000000
1299 002306 000000
1300 002310 000000
1301 002312 000000
1302 002314 000000
1303 002316 000000

```
.SBTTL GLOBAL DATA SECTION
;////////////////////////////////////
; THE GLOBAL DATA SECTION CONTAINS DATA THAT ARE USED
; IN MORE THAN ONE TEST.
;////////////////////////////////////

;*****
;* STORAGE FOR DEVICE REGISTERS
;*****
DESCRIPT      <KMV11A.B LOGIC DIAGNOSTIC>

          ERRTBL
ERRTYP::      .WORD    0
ERRNBR::      .WORD    0
ERRMSG::      .WORD    0
ERRBLK::      .WORD    0

;*****
;* PROGRAM CONTROL PARAMETERS
;*****
L$SW:         .WORD    0
L$UIT:        .WORD    15
UNIT:         .WORD    0
LOCK:         .WORD    0          ;ADDRESS FOR LOCK CURRENT DATA
MAXERR:       .WORD    5          ;MAX ERROR CNT BEFORE DROPPING UNIT
ERRCNT:       .WORD    0          ;ERROR CNT
LOGDEV:       .WORD    0          ;LOGICAL DEVICE NUMBER
PSTACK:       .WORD    0          ;BASE LEVEL PROGRAM STACK POINTER
SAVSP:        .WORD    0          ;STACK POINTER STORAGE
SAVPC:        .WORD    0          ;PROGRAM COUNTER STORAGE
SAVE4:        .WORD    0
SAVE6:        .WORD    0
FTIME:        .WORD    0
```

```

1305 ;*****
1306 ;* MISCELLANEOUS STORAGE
1307 ;*****
1308 002320 000000 FLAG: .WORD 0
1309 002322 000000 OH1: .WORD 0
1310 002324 000000 DELCT1: .WORD 0
1311 002326 000000 DELCT2: .WORD 0
1312 002330 000000 GOOD: .WORD 0
1313 002332 000000 GOOD0: .WORD 0
1314 002334 000000 GOOD1: .WORD 0
1315 002336 000000 GOOD2: .WORD 0
1316 002340 000000 GOOD4: .WORD 0
1317 002342 000000 GOOD6: .WORD 0
1318 002344 000000 GOOD10: .WORD 0
1319 002346 000000 GOOD12: .WORD 0
1320 002350 000000 GOOD14: .WORD 0
1321 002352 000000 GOOD16: .WORD 0
1322 002354 000000 SEL0: .WORD 0
1323 002356 000000 SEL1: .WORD 0
1324 002360 000000 SEL2: .WORD 0
1325 002362 000000 SEL4: .WORD 0
1326 002364 000000 SEL6: .WORD 0
1327 002366 000000 SEL10: .WORD 0
1328 002370 000000 SEL12: .WORD 0
1329 002372 000000 SEL14: .WORD 0
1330 002374 000000 SEL16: .WORD 0
1331 002376 000000 BSEL1: .WORD 0
1332 002400 000000 RANST: .WORD 0
1333 002402 000000 RANSEL: .WORD 0
1334 002404 000000 RANMTA: .WORD 0
1335 002406 000000 RANDN: .WORD 0
1336 002410 000000 SAVPC1: .WORD 0
1337 002412 000000 SAVSTA: .WORD 0
1338 002414 000000 COUNT: .WORD 0
1339 002416 000000 NUMBER: .WORD 0
1340 002420 000000 ADDR: .WORD 0
1341 002422 000000 GDDAT: .WORD 0
1342 002424 000000 BDDAT: .WORD 0
1343
1344 002426 TTABLE: .BLKW 2000
1345 006426 RTABLE: .BLKW 2000
1346
1347 012426 000000 EXADDR: .WORD 0
1348 012430 000000 INTFLG: .WORD 0
1349 012432 000000 BAD: .WORD 0
1350 012434 000000 BSELO: .WORD 0
1351 012436 000000 DATA: .WORD 0
1352 012440 000000 VECT: .WORD 0
1353
1354 012442 000000 KIND: .WORD 0
1355 012444 000000 CHANEL: .WORD 0
1356
1357 012446 000000 TXDATA: .WORD 0
1358 012450 000000 RXDATA: .WORD 0
1359 012452 000000 TSPEED: .WORD 0
1360 012454 000000 LENGTH: .WORD 0
1361 012456 000000 NUB: .WORD 0

```

! = 0 IF KMV11A , = 1 IF KMV11B

KMY11 A LOGIC DIAG
GLOBAL DATA SECTION

MACRO M1200 05-APR 84 11:23 PAGE 22-1

03

040 28

1362 012460 000000
1363 012462 000000
1364

RXCNT: .WORD 0
MAXCNT: .WORD 0

D3

KMV11 A B LOGIC DIAG
GLOBAL DATA SECTION

MACRO M1200 05-APR 84 11:23 PAGE 23

SEQ 29

1366
1367
1368
1369
1370
1371
1372
1373
1374
1375
1376
1377
1378
1379
1380
1381
1382
1383
1384
1385
1386
1387
1388
1389
1390
1391
1392

012464 000001

```
*****  
;LOAD IN LOCATION "GDREV" THE PROM VERSION NUMBER THAT IS *  
;COMPATIBLE WITH THIS DIAGNOSTIC *  
; *  
;EACH PROM CONTAIN A REV LEVEL AND A ECO LEVEL; *  
;THE REV LEVEL IS MODIFIED EACH TIME A MODIFICATION IS DONE *  
;THE ECO LEVEL IS MODIFIED WHEN THE PROM MODIFICATION NEED *  
;A DIAGNOSTIC MODIFICATION *  
*****
```

GDREV: .WORD 1

```

1394 ;*****
1395 ;* PROGRAM CONTROL FLAGS
1396 ;*****
1397 012466 000 INIFLG: .BYTE 0 ;PROGRAM INITIALIZING FLAG
1398 .EVEN
1399 012470 000 LOKFLG: .BYTE 0 ;LOCK ON CURRENT TEST FLAG
1400 012471 000 QV.FLG: .BYTE 0 ;QUICK VERIFY FLAG
1401 .EVEN
1402 012472 000000 UUT: .WORD 0 ;CURRENT UNIT UNDER TEST
1403
1404
1405 ;*****
1406 ;* POINTERS TO KMV11 VECTORS AND REGISTERS
1407 ;*****
1408 012474 000000 KMVV00: 0 ;POINTER TO KMV11 INTRPT VECTOR 0
1409 012476 000000 KMVLVL: 0 ;POINTER TO KMV11 INTRPT SERVICE
1410 012500 000000 KMVV04: 0 ;POINTER TO KMV11 INTRPT VECTOR 04
1411 012502 000000 KMVV02: 0 ; " " " " 02
1412 012504 000000 KMVV06: 0 ; " " " " 06
1413 012506 000000 KMTLVL: 0 ;POINTER TO KMV11 TX INTRPT SERVICE PS
1414 012510 000000 KMVCSR: 0 ;POINTER TO KMV11 CONTROL STATUS REGISTER
1415 012512 000000 KMVP02: 0 ;POINTER TO KMV11 PORT REGISTER - SEL2
1416 012514 000000 KMVP04: 0 ;POINTER TO KMV11 PORT REGISTER - SEL4
1417 012516 000000 KMVP06: 0 ;POINTER TO KMV11 PORT REGISTER - SEL6
1418
1419 012520 000000 KMVP10: 0 ;POINTER TO KMV11 PORT REG -SEL10
1420 012522 000000 KMVP12: 0 ;POINTER TO PORT REG -SEL 14
1421 012524 000000 KMVP14: 0 ;POINTER TO PORT REG -SEL14
1422 012526 000000 KMVP16: 0 ;POINTER TO PORT REG 16
1423
1424 012530 000000 LOOP: 0 ;POINTER TO LOOP BACK CONNECTOR
1425
1426
1427 ;***** PRIMARY REG ADRS STORAGE FOR THIS UNIT *****
1428 ;THESE LOCATIONS WILL BE LOADED FOR THE CURRENT UNIT, IN INIT CODE
1429 012532 REGADR:
1430
1431 ;***** STACK USED FOR SUBROUTINE LINKAGE *****
1432 012532 .BLKW 100
1433 012732 SSTACK:
1434
1435
1436
1437
1438
1439
1440

```

1442
1443
1444
1445
1446
1447
1448
1449
1450
1451
1452
1453 012732
1454
1455
1456
1457
1458
1459
1466
1467
1468
1469
1470

```

.SBTTL GLOBAL TEXT SECTION
;*****
;* THE GLOBAL TEXT SECTION CONTAINS FORMAT STATEMENTS,
;* MESSAGES, AND ASCII INFORMATION THAT ARE USED IN
;* MORE THAN ONE TEST.
;*****
;*****
;* NAMES OF DEVICES SUPPORTED BY PROGRAM
;*****
; DEVTYP <M7500 OR M7501 MODULE>

;
; FORMAT STATEMENTS USED IN PRINT CALLS
;

```

1472
1473
1474
1475
1476
1477
1478
1479
1480
1481
1482
1483
1484
1485

.SBTTL GLOBAL SUBROUTINES

; MACRO'S NEEDED TO CALL SUBROUTINES

.MACRO CLRMAR
ROMCLK
004000
.ENDM CLRMAR


```

1487 ;ROUTINE TO WAIT FOR EVENT OR TIMEOUT
1488
1489
1490
1491 ;CALLING SEQUENCE: JSR PC, WAIT1
1492 ; JSR PC, WAIT2
1493
1494
1495 ;INPUTS PARAMETERS: DELCT1, DELCT2
1496
1497
1498 ; INC DELCT1 UNTIL 0
1499 ; DEC DELCT2 UNTIL 0 DELCT2 = NUMB OF WAIT1 PASSES
1500
1501
1502
1503
1504
1505
1506
1507 012760 005237 002324 WAIT2: INC DELCT1
1508 012764 001375 BNE WAIT2
1509
1510 012766 BREAK
1511
1512 012770 005337 002326 DEC DELCT2
1513 012774 001371 BNE WAIT2
1514
1515 012776 000207 RTS PC
1516
1517
1518
1519
1520
1521
1522 013000 005237 002324 WAIT1: INC DELCT1
1523 013004 001375 BNE WAIT1
1524
1525 013006 000207 RTS PC

```

```

1527           ;MACRO TO WAIT A FEW MS
1528
1529
1530           ;CALLING SEQUENCE:      WAITA  X           0<<<177777
1531           ;                       WAITB  X,Y         0<X OR Y<177777
1532
1533
1534
1535           .MACRO  WAITA  X
1536           MOV    @X,DELCT1           ;LOAD COUNT
1537           JSR    PC,WAIT1            ;WAIT
1538           .ENDM
1539
1540
1541
1542
1543
1544
1545
1546           .MACRO  WAITB  X,Y
1547           MOV    @X,DELCT1
1548           MOV    @Y,DELCT2
1549           JSR    PC,WAIT2
1550           .ENDM
1551
1552
1553
1554

```

```

1556          ;ROUTINE TO DROP UNIT AFTER 5 ERROR
1557
1558
1559          ;JSR   PC,CHKMAX
1560
1561
1562
1563
1564
1565
1566
1567
1568 013010      CHKMAX: INLOOP          ;LOOPING ON ERROR?
1569 013012      BCOMPLETE          1$    ;IF YES, EXIT
1570
1571
1572 013014      RFLAGS   R0          ;GET OPERATOR FLAG
1573 013016      032700  000040      BIT     @IDU,R0      ;IS DROPPING INHIBITED?
1574 013022      001026          BNE     1$             ;IF YES EXIT
1575
1576
1577 013024      005237  002300      INC     ERRCNT          ;UPDATE ERROR COUNT
1578 013030      023737  002300  002276  CMP     ERRCNT,MAXERR ;TOO MANY ERROR?
1579 013036      003420          BLE     1$             ;IF NOT JUMP
1580
1581
1582 013040      PRINTF  @NERRS,MAXERR,UUT ;TOO MANY ERROR!
1583 013070      DODU   UUT           ;DROP UNIT
1584
1585 013076      DOCLN          ;END THE SUBPASS
1586
1587 013100      000207          1$:   RTS     PC
1588
1589
1590
1591
1592
1593 013102      045     116     045  NERRS: .NLIST  BEX
1594          .ASCIZ  /N#AMORE THAN #D3#A  ERRORS ON UNIT #D2/
1595          .LIST   BEX
1596          .EVEN
1597
1598

```

```

1600 ;ROUTINE TO CHECK REGISTER BSELO AND TO REPORT ERROR
1601
1602
1603
1604
1605
1606
1607 ;CALLING SEQUENCE: JSR PC,TSTERR
1608
1609
1610
1611 ;OUTPUT PARAMETERS: RETURN TO PC IF TEST IS OK
1612 ; PC+2 IF TIMEOUT DURING TEST
1613 ; PC+4 IF NO KMV11 ANSWER
1614 ; PC+6 IF DATA CMP ERROR
1615
1616
1617
1618
1619
1620
1621 013152 004537 013722 TSTERR: JSR R5,CBSELO ;LOOK IF BSELO=C
1622 013156 000000 .WORD 0
1623 013160 000411 BR 1$ ;TEST IS OK ,RTS PC
1624
1625
1626 013162 122737 000200 012434 CMPB #200,BSELO ;LOOK IF BSELO=200
1627 013170 001406 BEQ 2$ ;TIMEOUT DURING TEST,RTS PC+2
1628
1629
1630 013172 122737 000100 012434 CMPB #100,BSELO ;LOOK IF BSELO=100
1631 013200 001405 BEQ 3$ ;DATA CMP ERROR,RTS PC+6
1632
1633
1634
1635 013202 000407 BR 4$ ;NO KMV11 ANSWER ,RTS PC+4
1636
1637
1638
1639 013204 000207 1$: RTS PC ;TEST OK
1640
1641
1642 013206 062716 000002 2$: ADD #2,(SP)
1643 013212 000207 RTS PC ;TIMEOUT ERROR
1644
1645
1646 013214 062716 000006 3$: ADD #6,(SP)
1647 013220 000207 RTS PC ;DATA CMP ERROR
1648
1649
1650 013222 062716 000004 4$: ADD #4,(SP)
1651 013226 000207 RTS PC ;NO KMV11 ANSWER

```

1653
1654
1655
1656
1657
1658
1659
1660
1661
1662
1663
1664
1665
1666
1667
1668
1669
1670
1671
1672
1673
1674
1675
1676
1677
1678
1679
1680
1681
1682
1683
1684
1685
1686
1687
1688
1689
1690
1691
1692
1693
1694
1695
1696
1697
1698
1699
1700
1701
1702
1703
1704
1705
1706
1707
1708
1709

```

        .SBTTL  NUMBER GENERATOR

        DESCRIPTION:

            ROUTINE TO GENERATE DATA PATTERNS,
            THE TYPE OF PATTERN IS SELECTED BY R3, AND THE
            PATTERN GENERATED IS RETURNED IN LOCATION "DATA"
            AND LOCATION "GOOD"

        CALLING SEQUENCE:

            JSR    PC,GENER

        INPUT PARAMETERS:

        R3 CONTAINS THE PATTERN NUMBER

        R3=0        ALL ZEROES
        1            ALL ONES
        2            010101 ETC BIT PATTERN
        3            101010 ETC BIT PATTERN
        4            ROTATING 1 IN A ZERO WORD
        5            ROTATING 0 IN AN ALL ONE WORD
        6            PSEUDO RANDOM NUMBER
        7            INCREMENTING DATA PATTERN, GOOD
                   CONTAINS THE VALUE TO BE UPDATED

        IMPLICIT INPUT PARAMETERS:

            NONE

        OUTPUT PARAMETERS:

            THE NUMBER GENERATED IS HELD IN
            DATA AND GOOD.

        IMPLICIT OUTPUT PARAMETERS:

            NONE

        COMPLETION CODES:

            NONE

        POSSIBLE ERROR CODES:

            NONE
    
```

```

1710
1711
1712 013230 042703 177770
1713 013234 004737 013530
1714 013240 006303
1715 013242 000173 013246
1716 013246 013266
1717 013250 013272
1718 013252 013300
1719 013254 013306
1720 013256 013314
1721 013260 013324
1722 013262 013362
1723 013264 013502
1724 013266 005000
1725 013270 000507
1726 013272 005000
1727 013274 005100
1728 013276 000504
1729 013300 012700 052525
1730 013304 000501
1731 013306 012700 125252
1732 013312 000476
1733 013314 000241
1734 013316 004737 013336
1735 013322 000472
1736 013324 000241
1737 013326 004737 013336
1738 013332 005100
1739 013334 000465
1740 013336 006037 013360
1741 013342 001003
1742 013344 012737 100000 013360
1743 013352 013700 013360
1744 013356 000207
1745 013360 000001
1746 013362 012737 000005 002402
1747 013370 004737 013402
1748 013374 013700 002406
1749 013400 000443
1750 013402 013702 002406
1751 013406 001002
1752 013410 013702 002400
1753 013414 032737 000777 002402
1754 013422 001003
1755 013424 012737 000001 002402
1756 013432 013703 002402
1757 013436 013702 002406
1758 013442 033702 002404
1759 013446 001405
1760 013450 005102
1761 013452 033702 002404
1762 013456 001401
1763 013460 000402
1764 013462 000241
1765 013464 000401
1766 013466 000261

;
;
GENER: BIC #177770,R3
JSR PC,SAVREG
ASL R3
JMP @GENSEL(R3)
GENSEL: GEN0 ;ALL ZERO WORD
GEN1 ;ALL ONE WORD
GEN52 ;52 PATTERN
GEN25 ;25 PATTERN
GENR1 ;ROTATE '1' EACH CALL
GENRO ;ROTATE '0' EACH CALL
GENRAN ;RANDOM NUMBER
GENINC ;INCREMENTING COUNT
GENO: CLR R0 ;0>R0
BR GENEX
GEN1: CLR R0 ;NOT0>R0
COM R0
BR GENEX
GEN52: MOV #52525,R0 ;5252>R0
BR GENEX
GEN25: MOV #125252,R0 ;125252>R0
BR GENEX
GENR1: CLC
JSR PC,GENROT ;SHIFT 1 > R0
BR GENEX
GENRO: CLC
JSR PC,GENROT ;
COM R0 ;SHIFT 0 > R0
BR GENEX
GENROT: FOR GENISH ;ROTATE 1 PATTERN
BNE GENER1 ;= 0?
MOV #100000,GENISH ;YES, SET MSB
GENER1: MOV GENISH,R0 ;PUT 1 IN R0
RTS PC ;AND EXIT
GENISH: 1
GENRAN: MOV #5,RAN_L ;SET SELECT VALUE TO 5
JSR PC,RANGEN ;GENERATE RANDOM NUMBER IN R0
MOV RANDN,R0
BR GENEX
RANGEN: MOV RANDN,R2
BNE RAN1 ;IS RANDOM = 0
MOV RANST,R2 ;YES, PUT RANDOM START VALUE IN
RAN1: BIT #777,RANSEL ;NO;IS RANSEL SELECT VALUE = 0
BNE RAN2 ;NO
MOV #1,RANSEL ;YES: SET RANSEL = 1
RAN2: MOV RANSEL,R3
MOV RANDN,R2
BIT RANMTA,R2 ;GET R2 <0 AND 1>
BEQ RANCLC
COM R2
BIT RANMTA,R2
BEQ RANCLC
BR RANSEC
RANCLC: CLC
BR RAN4
RANSEC: SEC

```

1767	013470	006037	002406	RAN4:	ROR	RANDN	:ROTATE C TO B15
1768	013474	005303			DEC	R3	;IS THIS NUMBER REQUIRED?
1769	013476	001357			BNE	RAN2+4	;NO, GET ANOTHER
1770	013500	000207		RANEX:	RTS	PC	;YES, EXIT
1771	013502	013700	002330	GENINC:	MOV	GOOD,R0	;INCREMENTS LOC. 'GOOD'
1772	013506	005200			INC	R0	
1773	013510	010037	002330	GENEX:	MOV	R0,GOOD	
1774	013514	004737	013610		JSR	PC,RSTREG	
1775	013520	013737	002330 012436		MOV	GOOD,DATA	
1776	013526	000207			RTS	PC	
1777							


```

1836 013550 012637 002410      MOV      (SP)+,SAVPC1
1837 013554 010546             MOV      R5,(SP)
1838 013556 010446             MOV      R4,-(SP)
1839 013560 010346             MOV      R3,(SP)
1840 013562 010246             MOV      R2,(SP)
1841 013564 010146             MOV      R1,-(SP)
1842 013566 010046             MOV      R0,-(SP)
1843 013570 013746 002410      MOV      SAVPC1,(SP)
1844 013574 013746 002310      MOV      SAVPC,-(SP)      ;PUT PC READY FOR
1845 013600                               SETPRI  SAVSTA
1846 013606 000207             RTS      PC              ;RETURN
1847
1848
1849

```

1851
1852
1853
1854
1855
1856
1857
1858
1859
1860
1861
1862
1863
1864
1865
1866
1867
1868
1869
1870
1871
1872
1873
1874
1875
1876
1877
1878
1879
1880
1881
1882
1883
1884
1885
1886
1887
1888
1889
1890
1891
1892
1893
1894
1895
1896
1897
1898
1899
1900
1901
1902
1903
1904
1905
1906
1907

013610
013616
013624 012637 002310
013630 012637 002410
013634 012600
013636 012601

```

:      .SBTTL  RESTORE REGISTERS
:
:
:      DESCRIPTION:
:
:          RESTORE TO RESTORE THE GENERAL PURPOSE
:          REGISTERS. THE STACK IS LEFT IN THE SAME STATE AS IT
:          WAS WHEN SAVREG WAS CALLED.
:
:      CAUTION:  REGISTER R0 IS NOT SAVED
:
:
:      CALLING SEQUENCE:
:
:          JSR    PC,RSTREG
:
:      INPUT PARAMETERS:
:
:          NONE
:
:      IMPLICIT INPUT PARAMETERS:
:
:          NONE
:
:      OUTPUT PARAMETERS:
:
:          R1 THRU R5 RESTORED
:
:      IMPLICIT OUTPUT PARAMETERS:
:
:          NONE
:
:      COMPLETION CODES:
:
:          NONE
:
:      POSSIBLE ERROR CODES:
:
:          NONE
:
:      RSTREG: GETPRI  SAVSTA
:              SETPRI  MAXPRI
:              MOV     (SP)+,SAVPC
:              MOV     (SP)+,SAVPC1
:              MOV     (SP)+,R0
:              MOV     (SP)+,R1
    
```

KMV11 A/B LOGIC DIAG MACRO M1200 05-APR-84 11:23 PAGE 33 1
RESTORE REGISTERS

SEQ 43

1908	013640	012602		MOV	(SP)+,R2	
1909	013642	012603		MOV	(SP)+,R3	
1910	013644	012604		MOV	(SP)+,R4	
1911	013646	012605		MOV	(SP)+,R5	
1912	013650	013746	002410	MOV	SAVPC1,-(SP)	
1913	013654	013746	002310	MOV	SAVPC,-(SP)	;PUT PC READY FOR
1914	013660			SETPRI	SAVSTA	
1915	013666	000207		RTS	PC	

```

1917 ;CHECK CONTENT OF ONE OF THE 8 REGISTERS
1918
1919 ; CALLING SEQUENCE
1920 ; JSR R5,CKSELN ; N = REGISTER NUMBER
1921 ; .WORD A A=EXPECTED CONTENT OF REGISTER N
1922
1923 ;OUTPUT PARAMETER:
1924 ; BRANCH IN PC+2 IF ERROR DETECTED
1925 ; BRANCH IN PC IF NO ERROR DETECTED
1926
1927
1928
1929
1930
1931 013670 012537 002330 CKSELO: MOV (R5)+,GOOD ;WRITE GOOD
1932 013674 017737 176610 002354 MOV @KMVCSR,SELO ;READ SEL 0
1933 013702 023737 002354 002330 CMP SELO,GOOD ;CMP ?
1934 013710 001001 BNE 1$
1935 013712 000402 BR 2$
1936 013714 062705 000002 1$: ADD @2,R5
1937 013720 000205 2$: RTS R5
1938
1939
1940
1941
1942
1943
1944
1945 013722 005037 002330 CBSELO: CLR GOOD
1946 013726 012537 002330 MOV (R5)+,GOOD
1947 013732 117737 176552 012434 MOVB @KMVCSR,BSELO
1948 013740 123737 012434 002330 CMPB BSELO,GOOD
1949 013746 001001 BNE 1$
1950 013750 000402 BR 2$
1951 013752 062705 000002 1$: ADD @2,R5
1952 013756 000205 2$: RTS R5

```

```

1954          ;ROUTINE TO CHECK ALL REGISTER FROM SEL0 TO SEL16
1955
1956
1957          ;CALLING SEQUENCE:
1958          ;      JSR R5,CKALL
1959          ;      .WORD A          A = EXPECTED VALUE FOR SEL0
1960          ;      .WORD B          B      "      "      SEL2
1961          ;      .WORD C          C      "      "      SEL4
1962          ;      .WORD D          D      "      "      SEL6
1963          ;      .WORD E          E      "      "      SEL10
1964          ;      .WORD F          F      "      "      SEL12
1965          ;      .WORD G          G      "      "      SEL14
1966          ;      .WORD H          H      "      "      SEL16
1967
1968
1969          ;OUTPUT PARAMETER:
1970          ;      BRANCH IN PC+2 IF ERROR
1971          ;      BRANCH IN PC IF NO ERROR
1972
1973
1974
1975 013760 012537 002332      CKALL:  MOV      (R5)+,GOOD0
1976 013764 012537 002336      MOV      (R5)+,GOOD2
1977 013770 012537 002340      MOV      (R5)+,GOOD4
1978 013774 012537 002342      MOV      (R5)+,GOOD6
1979 014000 012537 002344      MOV      (R5)+,GOOD10
1980 014004 012537 002346      MOV      (R5)+,GOOD12
1981 014010 012537 002350      MOV      (R5)+,GOOD14
1982 014014 012537 002352      MOV      (R5)+,GOOD16
1983
1984 014020 017737 176464 002354      MOV      @KMVCSR,SEL0          ;READ SEL0
1985 014026 000240      NOP
1986 014030 000240      NOP
1987 014032 000240      NOP
1988 014034 017737 176452 002360      MOV      @KMVP02,SEL2          ;READ SEL2
1989 014042 000240      NOP
1990 014044 000240      NOP
1991 014046 000240      NOP
1992 014050 017737 176440 002362      MOV      @KMVP04,SEL4          ;READ SEL4
1993 014056 000240      NOP
1994 014060 000240      NOP
1995 014062 000240      NOP
1996 014064 017737 176426 002364      MOV      @KMVP06,SEL6          ;READ SEL6
1997 014072 000240      NOP
1998 014074 000240      NOP
1999 014076 000240      NOP
2000 014100 017737 176414 002366      MOV      @KMVP10,SEL10         ;READ SEL10
2001 014106 000240      NOP
2002 014110 000240      NOP
2003 014112 000240      NOP
2004 014114 017737 176402 002370      MOV      @KMVP12,SEL12         ;READ SEL12
2005 014122 000240      NOP
2006 014124 000240      NOP
2007 014126 000240      NOP
2008 014130 017737 176370 002372      MOV      @KMVP14,SEL14         ;READ SEL14
2009 014136 000240      NOP
2010 014140 000240      NOP

```

2011	014142	000240			NOP		
2012	014144	017737	176356	002374	MOV	@KMVP16,SEL16	;READ SEL16
2013							
2014							
2015	014152	023737	002354	002332	CMP	SEL0,GOOD0	
2016	014160	001035			BNE	1\$	
2017	014162	023737	002360	002336	CMP	SEL2,GOOD2	
2018	014170	001031			BNE	1\$	
2019	014172	023737	002362	002340	CMP	SEL4,GOOD4	
2020	014200	001025			BNE	1\$	
2021	014202	023737	002364	002342	CMP	SEL6,GOOD6	
2022	014210	001021			BNE	1\$	
2023	014212	023737	002366	002344	CMP	SEL10,GOOD10	
2024	014220	001015			BNE	1\$	
2025	014222	023737	002370	002346	CMP	SEL12,GOOD12	
2026	014230	001011			BNE	1\$	
2027	014232	023737	002372	002350	CMP	SEL14,GOOD14	
2028	014240	001005			BNE	1\$	
2029	014242	023737	002374	002352	CMP	SEL16,GOOD16	
2030	014250	001001			BNE	1\$	
2031							
2032	014252	000402			BR	2\$	
2033	014254	062705	000002		ADD	#2,R5	
2034	014260	000205			RTS	R5	

```

2036                               ;ROUTINE TO CHECK SEL2 TO SEL16
2037
2038
2039
2040
2041
2042 014262 012537 002336          CKREG: MOV      (R5)+,GOOD2
2043 014266 012537 002340          MOV      (R5)+,GOOD4
2044 014272 012537 002342          MOV      (R5)+,GOOD6
2045 014276 012537 002344          MOV      (R5)+,GOOD10
2046 014302 012537 002346          MOV      (R5)+,GOOD12
2047 014306 012537 002350          MOV      (R5)+,GOOD14
2048 014312 012537 002352          MOV      (R5)+,GOOD16
2049
2050
2051 014316 017737 176170 002360    MOV      @KMVP02,SEL2
2052 014324 000240                  NOP
2053 014326 000240                  NOP
2054 014330 000240                  NOP
2055 014332 000240                  NOP
2056 014334 017737 176154 002362    MOV      @KMVP04,SEL4
2057 014342 000240                  NOP
2058 014344 000240                  NOP
2059 014346 000240                  NOP
2060 014350 000240                  NOP
2061 014352 017737 176140 002364    MOV      @KMVP06,SEL6
2062 014354 000240                  NOP
2063 014356 000240                  NOP
2064 014358 000240                  NOP
2065 014360 000240                  NOP
2066 014370 017737 176124 002366    MOV      @KMVP10,SEL10
2067 014376 000240                  NOP
2068 014400 000240                  NOP
2069 014402 000240                  NOP
2070 014404 000240                  NOP
2071 014406 017737 176110 002370    MOV      @KMVP12,SEL12
2072 014414 000240                  NOP
2073 014416 000240                  NOP
2074 014420 000240                  NOP
2075 014422 000240                  NOP
2076 014424 017737 176074 002372    MOV      @KMVP14,SEL14
2077 014432 000240                  NOP
2078 014434 000240                  NOP
2079 014436 000240                  NOP
2080 014440 000240                  NOP
2081 014442 017737 176060 002374    MOV      @KMVP16,SEL16
2082
2083
2084
2085
2086 014450 023737 002360 002336    CMP      SEL2,GOOD2
2087 014456 001031                  BNE     1$
2088 014460 023737 002362 002340    CMP      SEL4,GOOD4
2089 014466 001025                  BNE     1$
2090 014470 023737 002364 002342    CMP      SEL6,GOOD6
2091 014476 001021                  BNE     1$
2092 014500 023737 002366 002344    CMP      SEL10,GOOD10

```

2093	014506	001015			BNE	1\$
2094	014510	023737	002370	002346	CMP	SEL12,GOOD12
2095	014516	001011			BNE	1\$
2096	014520	023737	002372	002350	CMP	SEL14,GOOD14
2097	014526	001005			BNE	1\$
2098	014530	023737	002374	002352	CMP	SEL16,GOOD16
2099	014536	001001			BNE	1\$
2100	014540	000402			BR	2\$
2101						
2102	014542	062705	000002		1\$: ADD	02,R5
2103	014546	000205			2\$: RTS	R5


```

2105 ;ROUTINE TO CLEAR KMV11 MODULE
2106
2107
2108 ;CALLING SEQUENCE:
2109 ; JSR PC,CLRKMV
2110
2111 ;ROUTINE DESCRIPTION: CLEAR ALL CSR'S REGISTERS AND CHECK IF = 0
2112
2113
2114
2115 014550 005077 175734 CLRKMV: CLR 6# CSR
2116 014554 012777 054000 175726 MOV #MF.1,10,@KMVCSR ;SET MAINTENANCE MODE
2117 014562 WAITA 0
2118
2119 014574 012702 000010 MOV #10,R2
2120 014600 013701 012510 MOV KMVCSR,R1 ;LOAD ADDRESS
2121 014604 005021 1$: CLR (R1)+ ;CLEAR
2122 014606 000240 NOP
2123 014610 000240 NOP
2124 014612 000240 NOP
2125 014614 005302 DEC R2 ;ALL DONE
2126 014616 001372 BNE 1$ ;NO
2127 014620 004537 013760 JSR R5,CKALL ;CHECK ALL REG = 0
2128 014624 000000 .WORD 0
2129 014626 000000 .WORD 0
2130 014630 000000 .WORD 0
2131 014632 000000 .WORD 0
2132 014634 000000 .WORD 0
2133 014636 000000 .WORD 0
2134 014640 000000 .WORD 0
2135 014642 000000 .WORD 0
2136 014644 000404 BR 2$ ;OK BRANCH A) END
2137 014646 ERRHRD 2,EM0002,PRALL ;CSR'S REGISTERS CAN'T BE CLEARED
2138 014656 000207 2$: RTS PC
2139

```

```

2141 ;ROUTINE TO SET MAINTENANCE MODE 0 ON KMV11
2142
2143
2144
2145
2146 ;CALLING SEQUENCE:
2147 ; JSR PC,MAINMO
2148
2149
2150
2151
2152 ;MAINT0 = MASTER CLEAR=1 +MAINT1=1 +MODE = 1 ;DCT11 = HOLD
2153
2154
2155
2156 ;TEST DESCRIPTION:SET MAINTENANCE MODE 0 AND CHECK THAT MASTER CLEAR
2157 ; IS RESET BY DCT11 MICRO PROCESSOR
2158 ;
2159 ; GIVE AN ERROR IF NOT RESET
2160
2161
2162
2163
2164 014660 012777 054000 175622 MAINMO: MOV #MAINT0,@KMVCSR ;LOAD MAINT0
2165 014666 012737 177000 002324 MOV #177000,DELCT1
2166 014674 012737 000001 002326 MOV #1,DELCT2
2167 014702 004737 012760 JSR PC,WAIT2 ;WAIT
2168 014706 004537 013670 JSR R5,CKSELO ;CHECK SELO=0 BUT MODE BIT + MAINT1 BIT
2169 014712 014000 .WORD 14000
2170 014714 000404 BR 1$
2171 014716 ERRHRD 3,EM0001,PRSELO
2172 014726 000207 1$: RTS PC

```

```

2174 ;ROUTINE TO SET MAINT MODE 1 AND CHECK DCT11 CLEAR SEL0 AFTER HAVING DECODED
2175
2176
2177
2178 ;CALLING SEQUENCE:
2179 ; JSR PC,MAINM1
2180
2181
2182
2183 ;GIVE AN ERROR IF MASTER CLEAR IS NOT CLEAR BY DCT11
2184 ;
2185 ;MAINT1= MASTER CLEAR=1 + MAINT 1 =0 + MODE = 1 ; T11=NOT IN HOLD
2186
2187
2188
2189
2190
2191
2192 014730 005077 175554 MAINM1: CLR @KMVCSR
2193 014734 000240 NOP
2194 014736 000240 NOP
2195 014740 012777 044000 175542 MOV @MAINT1,@KMVCSR ;LOAD ADDRESS
2196 014746 012737 177700 002324 MOV @177700,DELCT1
2197 014754 012737 000001 002326 MOV @1,DELCT2
2198 014762 004737 012760 JSR PC,WAIT2
2199 014766 004537 013670 JSR R5,CKSELO ;CHECK SELO=0 BUT MODE BIT =1
2200 014772 004000 .WORD 4000
2201 014774 000404 BR 1$ ;OK BRANCH
2202 014776
2203 015006 000207 1$: RTS PC
2204
2205
2206
2207
2208

```

```

2210           ;ROUTINE TO SET TEST NUMBER ON BSELO
2211
2212
2213
2214
2215           ;CALLING SEQUENCE:
2216           ;       JSR R5,TSTNUB
2217           ;       .WORD  A
2218
2219
2220
2221
2222
2223
2224 015010 012537 012456 TSTNUB: MOV (R5)+,NUB
2225 015014 053777 012456 175466 BIS NUB,&KMVCSR ;LOAD TEST NUMBER
2226 015022 012737 170000 002324 MOV #170000,DELCT1
2227 015030 012737 000001 002326 MOV #1,DELCT2
2228 015036 004737 012760 JSR PC,WAIT2 ;WAIT
2229 015042 000205 RTS R5

```

```

2231
2232
2233 ;ROUTINE TO WRITE OR READ ONE OF THE KMV11 REGISTERS
2234
2235
2236
2237 ;CALLING SEQUENCE:
2238 ;JSR R5,WRITE
2239 ;.WORD A ;A=ADDRESS TO WRITE
2240 ;.WORD B ;B=DATA TO WRITE
2241 ;
2242 ;
2243 ;
2244 ;JSR R5,READ
2245 ;.WORD A ;A=ADDRESS TO READ
2246 ;
2247 ;
2248 ;
2249 ;MICRO DIAG NB 47 DESCRIPTION:
2250 ;WRITE: PUT ADDRESS TO WRITE IN SEL2
2251 ; ; PUT DATA TO WRITE IN SEL4
2252 ; ; SET BIT 0 OF SEL6(WRITE BIT)
2253 ; ; SET TEST NB 44
2254 ; ; KMV11 CLEAR BSELO WHEN DONE
2255 ;
2256 ;
2257 ;READ: PUT ADDRESS TO READ IN SEL2
2258 ; ; CLEAR BIT 0 IN SEL6
2259 ; ; SET TEST 47
2260 ; ; KMV11 READ ADDRESS IN SEL2 AND CLEAR BSELO WHEN DONE
2261 ; ; THE READ DATA IS LOAD IN LOCATION "BAD" AND "DATA"
2262 ;
2263 ;
2264 ;
2265 ;
2266 015044 012577 175442 WRITE: MOV (R5)+, &KMVP02 ;WRITE ADDRESS
2267 015050 012577 175440 MOV (R5)+, &KMVP04 ; " DATA
2268 015054 012777 000001 175434 MOV #1, &KMVP06 ;BIT WRITE
2269
2270 015062 004537 015010 JSR R5, TSTNUB ;SEND TEST NB 44
2271 015066 000047 .WORD 47
2272
2273 015070 000205 RTS R5 ;RETURN
2274
2275
2276
2277
2278
2279
2280 015072 012577 175414 READ: MOV (R5)+, &KMVP02 ;SET ADDRESS TO READ
2281 015076 005077 175412 CLR &KMVP04
2282 015102 005077 175410 CLR &KMVP06
2283
2284 015106 004537 015010 JSR R5, TSTNUB ;SEND TEST NB 44
2285 015112 000047 .WORD 47
2286
2287 015114 000240 NOP

```

KMV11 A/B LOGIC DIAG
RESTORE REGISTERS

MACRO M1200 05-APR 84 11:25 PAGE 41-1

(1)

SEQ 54

```
2288 015116 000240      NOP
2289
2290
2291 015120 004737 013152      JSR      PC,TSTERR      ;CHECK BSFL 0
2292 015124 000410      BR      1$             ;OK
2293 015126 000402      BR      2$
2294 015130 000401      BR      2$
2295 015132 000400      BR      2$
2296
2297 015134          2$:      ERR:HRD  5,EM0024      ;NO KMV ANSWER
2298 015144 000205      RTS      R5
2299
2300 015146 017737 175342 012432 1$:      MOV      @KMVP04,BAD      ;READ DATA IN BAD
2301 015154 013737 012432 012436      MOV      BAD,DATA        ;READ DATA IN "DATA" LOCATION
2302
2303 015162 000205      RTS      R5
2304
2305
2306
2307
```

D5

KMV11 A'D LOGIC DIAG
RESTORE REGISTERS

MACRO M1200 05-APR-84 11:23 PAGE 42

SFQ 55

```
2309 .MACRO ROMCLK
2310 .LIST
2311 JSR R5,,ROMCLK ;CLOCK INSTRUCTION
2312 .NLIST
2313 .ENDM
2314
2315 .MACRO ED$CALL XY
2316 .LIST
2317 ;***** TEST'XY' *****
2318 .NLIST
2319 .ENDM
2320
2321
2322
2323 .MACRO BADHEAD
2324 .RADIX 10
2325 ED$CALL \T$TESTNUM+1
2326 .RADIX 8
2327 .ENDM
2328
2329
2330
```

```

2332          .SBTTL GLOBAL ERROR REPORT SECTION
2333
2334          ;////////////////////////////////////////////////////
2335          ;/ THE GLOBAL ERROR REPORT SECTION CONTAINS ERROR MESSAGES
2336          ;/ THAT ARE USED IN MORE THAN ONE TEST.
2337          ;////////////////////////////////////////////////////
2338
2339          .NLIST BEX
2340
2341
2342
2343 015164      045      116      045 TFM36: .ASCIZ /#N#AREGISTER ADDRESS ERROR,ADDR = #06#A,UNIT = #02/
2344
2345 015247      040      102      125 TIM: .ASCIZ / BUS TIMEOUT /
2346
2347 015265      115      101      123 EM0001: .ASCIZ /MASTER CLEAR FAIL TO RESET: DCT11 CAN'T CLEAR MASTER CLEAR /
2348
2349 015361      040      113      115 EM0002: .ASCIZ / KMV11 REGISTERS CAN'T BE CLEARED /
2350
2351 015424      040      104      101 EM0003: .ASCIZ / DATA COMPARE ERROR ON KMV11 REGISTER (SEL2 TO SEL16)/
2352
2353 015512      040      104      101 EM0004: .ASCIZ / DATA COMPARE ERROR ON BSELO WHEN ACCESSED BY QBUS/
2354
2355 015575      040      122      105 EM0005: .ASCIZ / REGISTER SEL2 CAN'T BE ACCESSED CORRECTLY BY MICRO PROGRAM/
2356
2357 015671      105      122      122 EM0006: .ASCIZ /ERROR WHEN TESTING SEL4,DCT11 CAN'T ACCESS SEL4 CORRECTLY/
2358
2359 015764      105      122      122 EM0007: .ASCIZ /ERROR WHEN TESTING SEL6,DCT11 CAN'T ACCESS SEL6 CORRECTLY/
2360
2361 016056      105      122      122 EM0010: .ASCIZ /ERROR WHEN TESTING SEL10,DCT11 CAN'T ACCESS SEL10 CORRECTLY/
2362
2363 016152      105      122      122 EM0011: .ASCIZ /ERROR WHEN TESTING SEL12,DCT11 CAN'T ACCESS SEL12 CORRECTLY/
2364
2365 016246      105      122      122 EM0012: .ASCIZ /ERROR WHEN TESTING SEL14,DCT11 CAN'T ACCESS SEL14 CORRECTLY/
2366
2367 016342      105      122      122 EM0013: .ASCIZ /ERROR WHEN TESTING SEL16,DCT11 CAN'T ACCESS SEL16 CORRECTLY/
2368
2369 016436      040      104      101 EM0015: .ASCIZ / DATA COMPARE ERROR IN RAM MEMORY TEST /
2370
2371 016506      040      124      111 EM0016: .ASCIZ / TIMEOUT DURING DMA TRANSFER /
2372
2373 016544      040      104      101 EM0020: .ASCIZ / DATA COMPARE ERROR AFTER DMA TRANSFER INTO KMV11 /
2374
2375 016630      040      104      101 EM0021: .ASCIZ / DATA COMPARE ERROR AFTER DMA TRANSFER IN BOTH DIRECTION /
2376
2377 016722      111      116      124 EM0022: .ASCIZ /INTERUPT OCCUR AT WRONG LEVEL /
2378
2379 016762      116      117      040 EM0023: .ASCIZ /NO INTERUPT OCCUR /
2380
2381 017005      116      117      040 EM0024: .ASCIZ /NO ANSWER FROM KMV11 MODULE , MICRO TEST NOT EXECUTED /
2382
2383 017075      124      111      115 EM0025: .ASCIZ /TIMEOUT DURING KMV11 MICRO TEST /
2384
2385 017136      111      116      124 EM0026: .ASCIZ /INTERUPT ON DCT11 WITH ILLEGAL VECTOR WHEN ACCESSING BSEL2 /
2386
2387 017232      116      117      040 EM0027: .ASCIZ /NO KMV11 ANSWER ,DCT11 RECEIVE NO INTERUPT /
2388

```


2389	017307	111	114	114	EM0028: .ASCIZ /ILLEGAL INTERRUPT OCCURED /
2390					
2391	017341	104	101	124	EM0030: .ASCIZ /DATA COMPARE ERROR DURING DMA TRANSFER OUT KMV11 /
2392					
2393	017423	105	122	122	EM0031: .ASCIZ /ERROR DURING BYTE ACCES ON KMV11 REGISTERS /
2394					
2395	017477	111	116	124	EM0032: .ASCIZ /INTERUPT ON DCT11 WITH ILLEGAL VECTOR WHEN ACCESSING BSELO /
2396					
2397	017573	122	101	115	EM0033: .ASCIZ /RAM MEMORY ERROR WHEN TRANSFERING BUFFER IN DMA /
2398					
2399	017654	120	122	117	EM0034: .ASCIZ /PROM REVISION IS NOT COMPATISBLE WITH DIAGNOSTIC REVISION /
2400					
2401	017746	040	103	110	EM0134: .ASCIZ / CHECK PROM AND DIAGNOSTIC REVISION /
2402					
2403	020013	040	040	120	EM0035: .ASCIZ / PROM CHECKSUM ERROR /
2404					
2405					
2406					

2408	020042	045	116	045	MSELO: .ASCIZ /%N%A SEL0 = %06%A SHOULD BE = %06%N/
2409					
2410	020107	045	116	045	MREG0: .ASCIZ /%N%A SEL0 = %06%A SHOULD BE = %06/
2411	020152	045	116	045	MREG2: .ASCIZ /%N%A SEL2 = %06%A SHOULD BE = %06/
2412	020215	045	116	045	MREG4: .ASCIZ /%N%A SEL4 = %06%A SHOULD BE = %06/
2413	020260	045	116	045	MREG6: .ASCIZ /%N%A SEL6 = %06%A SHOULD BE = %06/
2414	020323	045	116	045	MREG10: .ASCIZ /%N%A SEL10 = %06%A SHOULD BE = %06/
2415	020366	045	116	045	MREG12: .ASCIZ /%N%A SEL12 = %06%A SHOULD BE = %06/
2416	020431	045	116	045	MREG14: .ASCIZ /%N%A SEL14 = %06%A SHOULD BE = %06/
2417	020474	045	116	045	MREG16: .ASCIZ /%N%A SEL16 = %06%A SHOULD BE = %06/
2418					
2419					
2420	020537	045	116	045	MSEL2: .ASCIZ /%N%A SEL2 = %06%A SHOULD BE = %06/
2421					
2422	020602	045	116	045	MSEL4: .ASCIZ /%N%A SEL4 = %06%A SHOULD BE = %06/
2423					
2424	020645	045	116	045	MSEL10: .ASCIZ /%N%A SEL10 = %06%A SHOULD BE = %06/
2425					
2426	020707	045	116	045	MRAM1: .ASCIZ /%N%A RAM ADDRESS = %06%A, EXTENDED ADDRESS = %06/
2427	020771	045	116	045	MRAM2: .ASCIZ /%N%A BDDAT = %06%A SHOULD CONTENT = %06/
2428					
2429	021051	045	116	045	MINT: .ASCIZ /%N%A GOOD = %06%A BAD = %06/
2430					
2431	021103	045	116	045	MSELO: .ASCIZ /%N%A BSELO = %06%A SHOULD BE = %06/
2432					
2433	021145	045	116	045	MINTR: .ASCIZ /%N%A DCT11 ILLEGAL INTERRUPT WHEN ADDRESS = %06%A IS WRITTEN/
2434					
2435	021240	045	116	045	MDMA1: .ASCIZ /%N%A DMA ERROR AT ADDRESS = %06%A EXTADDRESS = %06/
2436	021323	045	116	045	MDMA2: .ASCIZ /%N%A BDDAT = %06%A SHOULD BE = %06/
2437					
2438	021371	045	116	045	MBYTE: .ASCIZ /%N%A AT ADDRESS ADDR = %06%A, GOOD = %06%A, BAD = %06/
2439					
2440	021453	045	116	045	MDMAR1: .ASCIZ /%N%A RAM MEMORY LOCATION = %06%A IS MODIFIED DURING /
2441	021542	045	116	045	MDMAR2: .ASCIZ /%N%A DMA TRANSFER IN BOTH DIRECTION /
2442	021610	045	116	045	MDMAR3: .ASCIZ /%N%A READ DATA = %06%A SHOULD BE = %06/
2443					
2444	021666	045	116	045	MCHECK: .ASCIZ /%N%A CHECKSUM IS = %06%A SHOULD BE ZERO /
2445					
2446	021737	045	116	045	MDMAF: .ASCIZ /%N%A ADDR = %06%A ,GDDAT = %06%A ,BDDAT = %06/
2447					
2448					
2449					

```

2451
2452          .EVEN
2453
2454
2455
2456          ;-----
2457          ; MACRO'S NEEDED TO REPORT ERRORS
2458          ;-----
2459
2460 022022          BGNMSG  PRSELO          ;REPORT CONTENT OF SELO
2461 022022          PRINTB  #MSELO,SELO,GOOD
2462 022052 004737 013010 JSR      PC,CHKMAX          ;CHECK IF MAX ERROR?
2463 022056          ENDMSG
2464
2465
2466 022060          BGNMSG  PRRAM          ;RAM ERROR REPORT
2467 022060          PRINTB  #MRAM1,ADDR,EXADDR
2468 022110          PRINTB  #MRAM2,BDDAT,GOOD
2469 022140 004737 013010 JSR      PC,CHKMAX          ;CHECK IF MAX ERROR?
2470 022144          ENDMSG
2471
2472
2473
2474 022146          BGNMSG  PRBYTE          ;BYTE ACCES REPORT
2475 022146          PRINTB  #MBYTE,ADDR,GOOD,BAD
2476 022202 004737 013010 JSR      PC,CHKMAX          ;CHECK IF MAX ERROR?
2477 022206          ENDMSG
2478
2479
2480 022210          BGNMSG  PDMARA          ;DMA IN RAM ERROR REPORT
2481 022210          PRINTB  #MDMAR1,ADDR
2482 022234          PRINTB  #MDMAR2
2483 022254          PRINTB  #MDMAR3,BDDAT,GOOD
2484 022304          BREAK
2485 022306 004737 013010 JSR      PC,CHKMAX          ;CHECK IF MAX ERROR?
2486 022312          ENDMSG
2487
2488
2489 022314          BGNMSG  PCHECK          ;CHECKSUM ERROR REPORT
2490 022314          PRINTB  #MCHECK,BAD
2491 022340 004737 013010 JSR      PC,CHKMAX          ;CHECK IF MAX ERROR?
2492 022344          ENDMSG
2493
2494
2495
2496
2497 022346          BGNMSG  PADFLT          ;ADDRESS TEST
2498 022346          PRINTB  #TFM36,ADDR,UNIT
2499 022376 004737 013010 JSR      PC,CHKMAX
2500 022402          ENDMSG
2501
2502
2503
2504
2505

```

```

2507 022404          BGNMSG  PRALL                ;CSR'S CONTENT REPORT
2508 022404          PRINTB  @MREG0,SEL0,GOOD0
2509 022434          PRINTB  @MREG2,SEL2,GOOD2
2510 022464          PRINTB  @MREG4,SEL4,GOOD4
2511 022514          PRINTB  @MREG6,SEL6,GOOD6
2512 022544          PRINTB  @MREG10,SEL10,GOOD10
2513 022574          PRINTB  @MREG12,SEL12,GOOD12
2514 022624          PRINTB  @MREG14,SEL14,GOOD14
2515 022654          PRINTB  @MREG16,SEL16,GOOD16
2516 022704          BREAK
2517 022706 004737 013010 JSR      PC,CHKMAX          ;CHECK IF MAX ERROR?
2518 022712          ENDMSG
2519
2520
2521
2522
2523
2524
2525
2526
2527 022714          BGNMSG  PRREG                ;CSR'S REPORT BUT SELO
2528 022714          PRINTB  @MREG2,SEL2,GOOD2
2529 022744          PRINTB  @MREG4,SEL4,GOOD4
2530 022774          PRINTB  @MREG6,SEL6,GOOD6
2531 023024          PRINTB  @MREG10,SEL10,GOOD10
2532 023054          PRINTB  @MREG12,SEL12,GOOD12
2533 023104          PRINTB  @MREG14,SEL14,GOOD14
2534 023134          PRINTB  @MREG16,SEL16,GOOD16
2535 023164          BREAK
2536 023166 004737 013010 JSR      PC,CHKMAX          ;CHECK IF MAX ERROR?
2537 023172          ENDMSG
2538
2539
2540
2541
2542
2543
2544
2545 023174          BGNMSG  PBSELO                ;BSELO REPORT
2546 023174          PRINTB  @MBSELO,BSELO,GOOD
2547 023224 004737 013010 JSR      PC,CHKMAX          ;CHECK IF MAX ERROR?
2548 023230          ENDMSG
2549
2550
2551
2552
2553
2554 023232          BGNMSG  PINTR                ;INTERUPT REPORT
2555 023232          PRINTB  @MINTR,ADDR
2556 023256 004737 013010 JSR      PC,CHKMAX          ;CHECK IF MAX ERROR?
2557 023262          ENDMSG
2558
2559
2560

```

```

2562
2563 023264          BGNMSG  PRDMA          ;DMA ERROR REPORT
2564 023264          PRINTB  #MDMA1,ADDR,EXADDR
2565 023214          PRINTB  #MDMA2,BDDAT,GOOD
2566 023344 004737 013010 JSR      PC,CHKMAX
2567 023350          BREAK
2568 023352          ENDMSG
2569
2570
2571 023354          BGNMSG  PDMAF          ;DMA SHORT REPORT
2572 023354          PRINTB  #MDMAF,ADDR,GDDAT,BDDAT
2573 023410          ENDMSG
2574
2575
2576
2577

```

2579
2580
2581
2582
2583
2584
2585
2586
2587 023412
2588
2594
2595 023412
2596
2603
2604 023416
2605
2606

.SBTTL REPORT CODING SECTION

; THE REPORT CODING SECTION CONTAINS THE
; "PRINTS" CALLS THAT GENERATE STATISTICAL REPORTS.

BGNRPT

EXIT RPT

ENDRPT

```

2608          .SBTTL  INITIALIZE SECTION
2609
2610          ;////////////////////////////////////
2611          ;// THE INITIALIZE SECTION CONTAINS THE CODING THAT IS PERFORMED
2612          ;// AT THE BEGINNING OF EACH PASS.
2613          ;////////////////////////////////////
2614
2615 023420          BGNINIT
2616
2617
2652
2653          .EVEN
2654
2655 023420          SETVEC  #140,#170000,#340          ;ODT ROM ADDRESS          ;JB REV A-0
2656
2657
2658          ;INITIALIZE SUBROUTINE STACK
2659          MOV      #SSTACK,R5
2660 023446 012705 012732          ;STORE BASE LEVEL PROGRAM STACK POINTER
2661          MOV      SP,PSTACK
2662 023452 010637 002304          TST      FTIME
2663 023456 005737 002316          BNE      1$
2664 023462 001011
2665 023464 013737 000004 002312          MOV      @#4,SAVE4
2666 023472 013737 000006 002314          MOV      @#6,SAVE6
2667 023500 012737 000001 002316          MOV      #1,FTIME
2668 023506 013737 002312 000004 1$: MOV      SAVE4,@#4
2669 023514 013737 002314 000006          MOV      SAVE6,@#6
2670
2671 023522          READEF  #EF.START          ;START COMMAND?
2672 023530          BCOMPLETE      SETUP          ;IF YES BRANCH
2673
2674 023532          READEF  #EF.CONTINUE          ;CONTINUE COMMAND?
2675 023540          BCOMPLETE      END
2676
2677
2678 023542          READEF  #EF.NEW          ;NEW PASS?
2679 023550          BNCOMPLETE      NEXT          ;IF NOT EXIT SETUP
2680
2681 023552 012737 177777 012472          SETUP: MOV      #-1,UUT          ;INITIALISE UNIT NUMBER
2682
2683 023560 005237 012472          NEXT:  INC      UUT          ;POINT NEXT UNIT
2684 023564 023737 012472 002270          CMP      UUT,L$UIT          ;ALL DONE?
2685 023572 001521          BEQ      ABORT          ;IF YES END OF PASS
2686
2687 023574 013701 012472          MOV      UUT,R1
2688 023600          PRINTF  #RUNNING,R1
2689          .EVEN
2690
2691 023622          GPWARD  UUT,R1          ;GET P TABLE
2692 023632          BNCOMPLETE      NEXT          ;IF NOT AVAILABLE GET NEXT
2693
2694
2695 023634          GETPRM:
2696
2697 023634 011137 012510          MOV      (R1),KMVCSR          ;GET ADDRESS OF KMV11
2698

```

```

2699 023640 011137 012512      MOV      (R1),KMVP02
2700 023644 062737 000002 012512      ADD      #2,KMVP02
2701                                     ;GET POINTER TO KMV11 PORT REG - SEL 4
2702 023652 011137 012514      MOV      (R1),KMVP04
2703 023656 062737 000004 012514      ADD      #4,KMVP04
2704                                     ;GET POINTER TO KMV11 PORT REG - SEL 6
2705 023664 011137 012516      MOV      (R1),KMVP06
2706 023670 062737 000006 012516      ADD      #6,KMVP06
2707                                     ;GET POINTER TO KMV11 REG 10
2708 023676 011137 012520      MOV      (R1),KMVP10
2709 023702 062737 000010 012520      ADD      #10,KMVP10
2710                                     ;GET POINTER TO KMV11 REG 12
2711 023710 011137 012522      MOV      (R1),KMVP12
2712 023714 062737 000012 012522      ADD      #12,KMVP12
2713                                     ;GET POINTER TO KMV11 REG 14
2714 023722 011137 012524      MOV      (R1),KMVP14
2715 023726 062737 000014 012524      ADD      #14,KMVP14
2716                                     ;GET POINTER TO KMV11 REG 16
2717 023734 012137 012526      MOV      (R1)+,KMVP16
2718 023740 062737 000016 012526      ADD      #16,KMVP16
2719                                     ;GET POINTER TO VECTOR 0
2720 023746 011137 012474      MOV      (R1),KMVV00
2721                                     ;GET POINTER TO VECTOR 2
2722 023752 011137 012502      MOV      (R1),KMVV02
2723 023756 062737 000002 012502      ADD      #2,KMVV02
2724                                     ;GET POINTER TO VECTOR 4
2725 023764 011137 012500      MOV      (R1),KMVV04
2726 023770 062737 000004 012500      ADD      #4,KMVV04
2727                                     ;GET POINTER TO VECTOR 6
2728 023776 012137 012504      MOV      (R1)+,KMVV06
2729 024002 062737 000006 012504      ADD      #6,KMVV06
2730                                     ;GET POINTER TO TX PRIORITY LEVEL
2731 024010 012137 012476      MOV      (R1)+,KMVLVL
2732 024014 062737 000006 012506      ADD      #6,KMVLVL
2733                                     ;GET LOOPBACK PARAMETERS:
2734 024022 011137 012530      MOV      (R1),LOOP
2735
2736 024026 005037 002300      CLR      ERRCNT
2737 024032                                EXIT      INIT
2738
2739
2740
2741 024036                                ABORT:    DOCLN
2742 024040                                EXIT      INIT
2743
2744
2745 024044      045      116      045  RUNNING:  .NLIST  BEX
2746
2747
2748
2749
2750
2751 024102                                END:      ENDINIT
2752
2753
2754
2755

```

```

;CLEAN UP AND ABORT PASS
;EXIT

```

```

.NLIST  BEX
.ASCIZ  /%N% RUNNING ON UNIT #D2%A /
.LIST   BEX
.EVEN

```



```

2757          .SBTTL  AUTODROP SECTION
2758
2759          ;**
2760          ; THIS CODE IS EXECUTED IMMEDIATELY AFTER THE INITIALIZE CODE IF
2761          ; THE "ADR" FLAG WAS SET.  THE UNIT(S) UNDER TEST ARE CHECKED TO
2762          ; SEE IF THEY WILL RESPOND.  THOSE THAT DON'T ARE IMMEDIATELY
2763          ; DROPPED FROM TESTING.
2764          ;--
2765          .EVEN
2766 024104          BGNAUTO
2767
2774
2775
2776
2777          ;CHECK IF EXISTING DEVICE
2778
2779
2780 024104 013701 012510          MOV      KMVCSR,R1          ;R1 CONTAINS BASE KMV11 ADDRESS
2781 024110 012705 000007          MOV      #7,R5          ;7 REGISTERS TO BE TESTED
2782 024114 012737 024146 000004          MOV      #2$,4          ;SET OUT TIMEOUT TRAP
2783          ;          ;LEVEL 7
2784 024122 012737 000300 000006          MOV      #340,6          ;JB REV A-0
2785 024130 005711          ;          ;LEVEL 6
2786 024132 000240          ;          ;REFERENCE DEVICE REGISTERS
2787 024134 062701 000002          ;          ;JB REV A-0
2788 024140 005305          ;
2789 024142 001372          ;
2790 024144 000405          ;
2791
2792 024146 062706 000004          2$:      ADD      #4,SP
2793 024152          ;          DODU      LOGDEV
2794
2795 024160 013737 002312 000004          3$:      MOV      SAVE4,4
2796 024166 013737 002314 000006          ;          MOV      SAVE6,6
2797
2798
2799
2800
2801 024174          ENDAUTO
2802
2803
2804
2805

```

2807
2808
2809
2810
2811
2812
2813
2814 024176
2815
2816
2836
2837
2838
2839 024176
2840
2841 024200
2842
2843
2844
2845
2846

```
.SBTTL CLEANUP CODING SECTION
;/////////////////////////////////////////////////////////////////
;// THE CLEANUP CODING SECTION CONTAINS THE CODING THAT IS PERFORMED
;// AT THE END OF EACH PASS.
;/////////////////////////////////////////////////////////////////
                RGCLN
                BRESET
                ENDCLN
```

```
2848 .SBTTL DROP UNIT SECTION
2849
2850 ;////////////////////////////////////////////////////////////////////
2851 ;// THE DROP UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
2852 ;// TO NO LONGER BE TESTED.
2853 ;////////////////////////////////////////////////////////////////////
2854
2855 024202          BGNDU
2856
2857
2858
2859
2860
2861          .EVEN
2862
2863 024202          PRINTF  @DROPD,RO          ;UNIT DROPPED
2864
2865 024224          EXIT    DU
2866
2867
2868
2869
2870
2871 024230          045    116    045  DROPD:  .MLIST  BEX
2872                                     .ASCIZ  /NA UNIT D2A DROPPED/
2873                                     .LIST   BEX
2874                                     .EVEN
2875
2876 024260          ENDDU
2877
2878
2879
2880
2881
2882
2883
2884
2885
2886
2887
2888
2889
2890
2891
2892
2893
2894
2895
2896
2897
2898
2899
2900
```

Df,

2902
2903
2904
2905
2906
2907
2908
2909
2910
2911
2920
2921 024262
2922 024262
2923
2924
2925
2926
2927
2928

.SBTTL ADD UNIT SECTION

```

;////////////////////////////////////
;/ THE ADD-UNIT SECTION CONTAINS THE CODING THAT CAUSES A DEVICE
;/ TO BE (A) TESTED FOR THE FIRST TIME, OR (B) RESUMED IN TESTING. IF
;/ "EF.AUNIT" IS SET, THE UNIT WILL BE TESTED AS A NEW UNIT.
;////////////////////////////////////

```

BGNAU
ENDAU

{ P,

```
2930
2931          .SBTTL  HARDWARE TESTS
2932
2933
2934
2935          ;START OF CODE BLOCK WHICH IS USED AS DATA
2936 024264 ROMMAP:;...
2937          ; TEST TO ...
2938          ;--
2939
2946
2952
2953          ;      BGNTST
2954
2960
2961          ;      EXII  TST
2962
2974
2975          .EVEN
2976          ;      ENDTST
2977
2983
```

2985 024264

2986

2987

2988 024264

2989

2990 024264

2991 024264 013701 012510

2992 024270 012705 000007

2993 024274 012737 024332 000004

2994

2995 024302 012737 000300 000006

2996 024310 005711

2997 024312 000240

2998 024314

2999 024320 062701 000002

3000 024324 005305

3001 024326 001370

3002 024330 000413

3003

3004 024332 062706 000004

3005 024336 010137 002420

3006 024342 013737 012472 002272

3007 024350

3008

3009 024360 013737 002312 000004

3010 024366 013737 002314 000006

3011 024374

3012

3013 024400

3014

3015

```

BADHEAD
;***** TEST1 *****
; *VERIFY THAT REFERENCING QBUS DEVICE REGISTERS
; *DOES NOT CAUSE A TIME OUT TRAP
BADHEAD
;***** TEST1 *****

BGNTST
MOV    KMVCSR,R1    ;R1 CONTAINS KMV11 ADDRESSES
MOV    #7,R5        ;7 REGISTERS TO BE TESTED
MOV    #2#,4        ;SET OUT TIMEOUT TRAP
;
MOV    #340,6       ;LEVEL 7 ;JB REV A-0
MOV    #300,6       ;LEVEL 6 ;JB REV A-0
1$:    TST    (R1)   ;REFERENCE DEVICE REGISTERS
      NOP
      ESCAPE TST
      ADD    #2,R1   ;NEXT REGISTER
      DEC    R5      ;DEC REGISTER COUNT
      BNE   1$      ;BR IF NOT LAST REGISTER
      BR    3$

2$:    ADD    #4,SP
      MOV    R1,ADDR ;REPORT ADDRESS LOCATION
      MOV    UUT,UNIT ;REPORT UNIT NUMBER
      ERRHRD O,TIM,PADFLT ;BUS TIMEOUT,ADDRESS PROBLEM ON THIS UNIT

3$:    MOV    SAVE4,4
      MOV    SAVE6,6
      ESCAPE TST

ENDTST
.EVEN

```

```

3017 024402      BADHEAD
3018             ;***** TEST2 *****
3019 024402      BADHEAD
3020             ;***** TEST2 *****
3021
3022
3023
3024
3025 024402      BGNTST
3026 024402      BGNSUB
3027
3028 024404      RESTST:
3029 024404      005077 166100      CLR      @KMVCSR
3030 024410      012777 054000 166072  MOV      @MAINTO,@KMVCSR      ;SET MASTER CLEAR TO EXIT
3031             ;SELF TEST IF RUNNING
3032 024416      WAITA      0
3033
3034
3035
3036 024430      012702 000010      MOV      #10,R2      ;LOAD NUMBER OF REGISTER
3037 024434      013701 012510      MOV      KMVCSR,R1
3038 024440      005021      3$:      CLR      (R1)+      ;CLR KMV11 REGISTERS
3039 024442      000240      NOP
3040 024444      000240      NOP
3041 024446      005302      DEC      R2
3042 024450      001373      BNE     3$      ;ALL DONE?
3043
3044 024452      004537 013760      JSR      R5,CKALL      ;CHECK ALL REGISTERS = 0
3045 024456      000000      .WORD  0
3046 024460      000000      .WORD  0
3047 024462      000000      .WORD  0
3048 024464      000000      .WORD  0
3049 024466      000000      .WORD  0
3050 024470      000000      .WORD  0
3051 024472      000000      .WORD  0
3052 024474      000000      .WORD  0
3053 024476      000406      BR       2$
3054 024500      ERRHRD 1,EM0002,PRALL      ;OK BRANCH
3055 024510      ESCAPE  SUB      ;REGISTERS FAIL TO RESET
3056
3057 024514      000240      2$:      NOP
3058 024516      ENDSUB
3059
3060
3061 024520      BGNSUB
3062 024522      004737 014550      JSR      PC,CLRKMV      ;CLEAR REGISTERS
3063
3064 024526      012777 054000 165754  MOV      @MAINTO,@KMVCSR      ;SET MASTER CLEAR,MODE BIT AND MAINT
3065
3066 024534      WAITA      0
3067
3068 024546      004537 013670      JSR      R5,CKSELO      ;CHECK MASTER CLR IS RESET BY DCT11
3069 024552      014000      .WORD  14000
3070
3071 024554      000406      BR       1$      ;YES

```

HF,

KMV11 A/B LOGIC DIAG
HARDWARE TESTS

MACRO M1200 05-APR-84 11:23 PAGE 56-1

SEQ 72

3072 024556
3073 024566
3074
3075 024572
3076 024572
3077 024574
3078
3079
3080
3081

ERRHRD 6,EM0001,PRSELO
ESCAPE SUB

;MASTER CLR FAIL TO RESET

1\$;
ENDSUB
ENDTST


```

3083 024576      BADHEAD
3084             ;***** TEST3 *****
3085 024576      ;CHECK QBUS ACCESS ON KMV11 REGISTERS (FROM SEL2 TO SEL16)
                 BADHEAD
                 ;***** TEST3 *****

3086
3087
3088
3089 024576      STARS 1
3090             ;SET MAINT MODE =0 ;DCT11 DECODE AND GOES IN HOLD
3091             ;PROCESSOR SEND ROTATING PATTERN TO EACH REGISTERS AND CHECK
3092 024576      STARS 1
3093
3094
3095
3096
3097
3098 024576      BGNTST
3099 024576      004737 014550      TSTREG: JSR      PC,CLRKMV      ;CLEAR REGISTERS
3100 024602      004737 014660      JSR      PC,MAINMO     ;SET MAINT MODE 0
3101 024606      012737 000007      MOV      #7,COUNT     ;NUMBER OF REG
3102 024614      012704 024652      MOV      #CHECK,R4
3103 024620      062704 000004      ADD      #4,R4        ;POINT GOOD VALUE OF SEL2
3104 024624      013701 012512      MOV      KMVP02,R1    ;LOAD SEL2 ADDRESS
3105
3106 024630      005003      TSELA: CLR      R3        ;SELECT FIRST PATTERN
3107
3108 024632      BREAK
3109
3110 024634      004737 013230      TSELB: JSR      PC,GENER ;GENER PATTERN
3111
3112
3113 024640      013711 012436      1$:  MOV      DATA,(R1) ;LOAD PATTERN IN REG
3114 024644      013714 012436      MOV      DATA,(R4)    ;LOAD GOOD VALUE
3115 024650      000240      NOP
3116
3117
3118 024652      004537 014262      CHECK: JSR      R5,CKREG ;CHECK ALL REGISTER BUT SEL0
3119 024656      000000      .WORD 0
3120 024660      000000      .WORD 0
3121 024662      000000      .WORD 0
3122 024664      000000      .WORD 0
3123 024666      000000      .WORD 0
3124 024670      000000      .WORD 0
3125 024672      000000      .WORD 0
3126 024674      000406      BR       1$           ;IF GOOD BR
3127 024676      ERRHRD 7,EM0003,PRREG
3128 024706      ESCAPE  TST
3129
3130 024712      005203      1$:  INC      R3        ;NEW PATTERN
3131 024714      022703 000007      CMP      #7,R3        ;ALL DONE
3132 024720      001345      BNE     TSELB        ;NO BR
3133
3134 024722      005021      CLR      (R1)+       ;SELECT NEW REG
3135 024724      005024      CLR      (R4)+       ;POINT NEW GOOD VALUE
3136 024726      005337 002414      DEC      COUNT      ;ALL REG TESTED
3137 024732      001356      BNE     TSELA        ;NO BR

```

KMV11 A B LOGIC DIAG
HARDWARE TESTS

MACRO M1200 05-APR-84 11:23 PAGE 57 1

,tr,

SEQ 74

3138 024734

ENDTST

```

3140 024736      BADHEAD
3141             ;***** TEST4 *****
3142 024736      ;CHECK QBUS ACCES ON SELO REGISTER
                 BADHEAD
                 ;***** TEST4 *****

3143
3144
3145
3146 024736      STARS 1
3147             ;SET MAINT MODE 0      ;DCT11 HOLD
3148             ;SEND ROTATING PATTERN IN SELO (EXCEPT BIT 11,12,14) AND CHECK
3149 024736      STARS 1
3150
3151
3152
3153
3154 024736      BGNTST
3155 024736      004737 014550      JSR      PC,CLRKMV      ;CLEAR REG
3156 024742      004737 014660      JSR      PC,MAINMO     ;LOAD MAINT MODE 0
3157 024746      005003              CLR      R3           ;FIRST PATTERN
3158 024750      012704 025016      MOV      #CHECK1,R4    ;POINT SEL 0
3159 024754      062704 000004      ADD      #4,R4
3160 024760      012737 000015 002414 TCSRNB: MOV      #15,COUNT    ;SELECT NB 0 PATTERN
3161
3162 024766      BREAK
3163
3164 024770      004737 013230      TCSR:  JSR      PC,GENER     ;GENERATE A PATTERN
3165 024774      042737 054000 012436 BIC      #54000,DATA    ;MASK  MCLR,MODE,MAINT1
3166 025002      013714 012436      MOV      DATA,(R4)
3167 025006      013777 012436 165474 MOV      DATA,#KMVCSR  ;WRITE PATTERN
3168 025014      000240
3169 025016      004537 013760      CHECK1: JSR      R5,CKALL    ;CHECK
3170 025022      000000      .WORD  0
3171 025024      000000      .WORD  0
3172 025026      000000      .WORD  0
3173 025030      000000      .WORD  0
3174 025032      000000      .WORD  0
3175 025034      000000      .WORD  0
3176 025036      000000      .WORD  0
3177 025040      000000      .WORD  0
3178 025042      000411      BR       1$
3179 025044      ERRHRD 8,EM0004,PRALL
3180 025054      ESCAPE  TST
3181
3182 025060      005337 002414      DEC      COUNT        ;DONE ENOUGH
3183 025064      001341      BNE     TCSR
3184
3185
3186 025066      005203      1$:   INC      R3           ;NEW PATTERN
3187 025070      022703 000007      CMP      #7,R3        ;ALL DONE
3188 025074      001331      BNE     TCSRNB       ;NO BR
3189 025076      ENDTST

```

```

3191 025100          BADHEAD
3192                ;***** TESTS *****
3193 025100          BADHEAD
3194                ;***** TESTS *****
3195
3196
3197
3198
3199
3200
3201 025100          STARS 1
3202                ;SET MAINT MODE 0 ;DCT11=HOLD
3203                ;WRITE PATTERN IN EACH BYTE ON KMV11 REGISTERS AND CHECK
3204                ;QBUS SEND VARIOUS PATTERN IN ALL BYTE ADDRESS
3205 025100          STARS 1
3206
3207
3208
3209
3210
3211 025100          BGNTST
3212 025100 004737 014550      JSR      PC,CLRKMV
3213 025104 004737 014660      TBYTE: JSR      PC,MAINMO      ;SET MAINT MODE0
3214
3215 025110 013701 012510      MOV      KMVCSR,R1      ;LOAD KMV CSR ADDRESS
3216 025114 012704 000015      MOV      #15,R4        ;LOAD NUMBER OF REGISTERS
3217
3218 025120 012737 000377 002330 1$: MOV      #377,GOOD      ;SELECT A PATTERN
3219 025126 142737 000130 002330 BICB    #130,GOOD
3220 025134 153711 002330      BISB    GOOD,(R1)      ;WRITE 1ST BYTE
3221 025140 005037 012432      CLR     BAD
3222
3223 025144          WAITA    177700
3224
3225 025156          BREAK
3226
3227 025160 111137 012432      MOVB    (R1),BAD      ;READ REG
3228 025164 142737 000130 012432 BICB    #130,BAD      ;MASK UNUSED BITS
3229
3230 025172 123737 002330 012432 CMPB    GOOD,BAD      ;COMPARE
3231 025200 001410          BEQ     3$          ;IF = BRANCH
3232
3233
3234
3235 025202 010137 002420      MOV     R1,ADDR      ;PREPARE ERROR REPORT
3236 025206          ERRMRD  9,EM0031,PRBYTE ;DATA CMP ERROR WHEN ACCESSING A BYTE
3237 025216          ESCAPE  TST
3238
3239
3240
3241 025222 005201          3$: INC     R1          ;SELECT NEW REGISTER
3242 025224 005304          DEC     R4          ;DONE ALL?
3243 025226 001334          BNE    1$
3244
3245

```

KMV.1 A'B LOGIC DIAG
HARDWARE TESTS

MACRO M1200 05-APR-84 11:23 PAGE 59 1

146

SEQ 77

3246 025230
3247

ENDTST

```

3249 025232          BADHEAD
                      ;***** TEST6 *****
3250                ;DATA TRANSFER ON REGISTER SEL 2
3251 025232          BADHEAD
                      ;***** TEST6 *****

3252
3253
3254 025232          STARS 1
3255                ;SET MAINT1 ;DCT11 DECODE ,CLEAR SELO AND WAIT FOR TEST NUMBER
3256                ;THE HOST WRITE A PATTERN IN SEL2
3257                ;THE HOST WRITE A TEST NUMBER IN BSELO
3258                ;
3259                ;IF DCT11 READ CORRECT VALUE ,IT CLEAR BSELO
3260                ;IF ERROR          SET 100 IN BSELO IF DATA CMP ERROR
3261                ;                   BSELO *TST NUMBER IF NO KMV11 ANSWER
3262                ;
3263                ;
3264                ;BSELO=1 = MICRO DIAG TEST 1 ;DCT11 MUST READ 052525 IN SEL2
3265                ;BSELO=2 = MICRO DIAG TEST 2 ;DCT11 MUST READ 125252 IN SEL2
3266 025232          STARS 1
3267
3268
3269
3270
3271
3272 025232          BGNTST
3273 025232 004737 014550      JSR      PC,CLRKMV          ;CLEAR REG
3274 025236 004737 014730      JSR      PC,MAINM1         ;SET MAINT MODE 1
3275
3276 025242          BGNSUB
3277 025244 012777 052525 165240  MOV     @DATA1,@KMVP02      ;SEND 052525
3278 025252 004537 015010      JSR      R5,TSTNUB         ;SEND TEST NUMB 1
3279 025256 000001              .WORD    1
3280 025260 004537 013722      JSR      R5,CBSELO         ;CHECK BSELO = 0
3281 025264 000000              .WORD    0
3282 025266 000425              BR      1$                ;TEST OK BR AT END
3283 025270 004537 013722      JSP     R5,CBSELO         ;CHECK BSELO=100
3284 025274 000100              .WORD    100
3285 025276 000401              BR      2$
3286 025300 000410              BR      3$
3287
3288
3289
3290 025302          2$:      ERRHRD  10,EM0005          ;DATA CMP ERROR
3291 025312 004737 013010      JSR      PC,CHKMAX         ;CHECK IF TOO MANY ERROR
3292 025316          ESCAPE  SUB
3293
3294 025322          3$:      ERRHRD  11,EM0024          ;NO KMV11 ANSWER
3295 025332 004737 013010      JSR      PC,CHKMAX         ;CHECK IF TOO MANY ERROR
3296 025336          ESCAPE  SUB
3297 025342 000240          1$:      NOP
3298 025344          ENDSUB
3299
3300
3301 025346          BGNSUB
3302 025350 004737 014730      JSR      PC,MAINM1         ;SET MAINT MODE 1
3303 025354 012777 125252 165130  MOV     @DATA2,@KMVP02      ;SEND 125252
    
```

```

3304 025362 004537 015010      JSR      R5,ISTNU8      ;SEND TEST NUM 2
3305 025366 000002          .WORD    2
3306 025370 004537 013722      JSR      R5,CBSELO      ;CHECK DCT11 HAS ANSWERED
3307 025374 000000          .WORD    0              ;BY CLEARING SELO
3308 025376 000425          BR       1$             ;OK BR
3309 025400 004537 013722      JSR      R5,CBSELO      ;CHECK IF =100
3310 025404 000100          .WORD    100
3311 025406 000401          BR       2$
3312 025410 000410          BR       3$
3313
3314
3315
3316 025412          2$:      ERRHRD 12,EM0005      ;DATA CMP ERROR ON SEL2
3317 025422 004737 013010      JSR      PC,CHKMAX      ;CHECK IF TOO MANY ERROR
3318 025426          ESCAPE  SUB
3319
3320 025432          3$:      ERRHRD 13,EM0024      ;NO KMV11 ANSWER
3321 025442 004737 013010      JSR      PC,CHKMAX      ;CHECK IF TOO MANY ERROR
3322 025446          ESCAPE  SUB
3323
3324 025452 000240          1$:      NOP
3325 025454          ENDSUB
3326 025456          ENDTST

```

```

3328 025460      BADHEAD
3329            ;***** TEST7 *****
3330 025460      BADHEAD
3331            ;***** TEST7 *****
3332
3333
3334 025460      STARS 1
3335            ;SET MAINT1 ;DCT11 DECODE AND CLEAR SEL0
3336            ;
3337            ;THE HOST SEND ROTATING PATTERN IN SEL4, AND SET TEST NUMBER 3 IN BSEL0
3338            ;
3339            ;DCT11 READ SEL4 , WRITE CONTENT OF SEL4 INTO SEL2 , CLEAR SEL0 WHEN DONE, AND
3340            ;WAIT FOR NEW PATTERN
3341            ;
3342            ;
3343            ;
3344            ;      AFTER TEST      BSEL0=100 IF ERROR DURING TEST
3345            ;                      BSEL0=0   IF TEST HAS BEEN EXECUTED (IN THAT CASE
3346            ;                      CHECK IF CONTENT OF SEL2 IS CORRECT)
3347            ;
3348            ;BSEL 0 = 3 ;MICRO DIAG NB 3 ;DCT11 TAKE CONTENT OF SEL4 AND PUT IT IN SEL 2.
3349 025460      STARS 1
3350
3351
3352 025460      BGNTST
3353 025460      BGNSUB
3354 025462 004737 014550      JSR      PC,CLRKMV      ;CLEAR REG
3355 025466 004737 014730      JSR      PC,MAINM1     ;SET MAINT MODE 1
3356 025472 005003              CLR      R3             ;SELECT FIRST PATTERN
3357
3358 025474 012737 000005 002414  TGENE1: MOV      05,COUNT      ;NB OF PATTERN
3359 025502              BREAK
3360
3361 025504 004737 013230              GENE1: JSR      PC,GENER      ;GENER 1ST PATTERN
3362 025510 013777 012436 164776      MOV      DATA,0KMVP04  ;LOAD SEL4
3363 025516 004537 015010              JSR      R5,TSTNUB     ;SET TEST NUMB 3
3364 025522 000003              .WORD    3
3365 025524 004537 013722              JSR      R5,CBSELO     ;LOOK IF ANSWER
3366 025530 000000              .WORD    0
3367 025532 000404              BR       1#           ;OK BR
3368 025534              ERRHRD 14,EM0024,PBSELO ;BSEL0 NOT CLEARED ,NO ANSWER
3369 025544 000240              1#:
3370 025546      ENDSUE
3371
3372
3373 025550      BGNSUB
3374 025552 012704 025572              MOV      0TSEL4,R4     ;POINT GOOD VALUE
3375 025556 013764 012436 000006      MOV      DATA,6(R4)
3376 025564 013764 012436 000004      MOV      DATA,4(R4)  ;WRITE GOOD VALUE FOR SEL2 AND SEL4
3377
3378 025572 004537 014262      TSEL4: JSR      R5,CKREG  ;CHECK SEL2 * SEL4
3379 025576 000000              .WORD    0
3380 025600 000000              .WORD    0
3381 025602 000000              .WORD    0
3382 025604 000000              .WORD    0

```


D7

```
3383 025606 000000 .WORD 0
3384 025610 000000 .WORD 0
3385 025612 000000 .WORD 0
3386 025614 000406 BR 2$
3387 025616 ERRHRD 15,EM0006,PRREG
3388 025626 ESCAPE SUB
3389
3390
3391 025632 005337 002414 2$: DEC COUNT ;DONE ENOUGH?
3392 025636 001322 BNE GENE1
3393
3394 025640 005203 INC R3 ;NEW PATTERN
3395 025642 022703 000007 CMP #7,R3 ;ALL DONE
3396 025646 001312 BNE TGENE1 ;NO BR
3397 025650 ENDSUB
3398 025652 ENDTST
```

```

3400 025654      BADHEAD
                 ;***** TEST8 *****
3401             ; CHECK DATA TRANSFER ON REGISTER SEL6
3402 025654      BADHEAD
                 ;***** TEST8 *****

3403
3404
3405 025654      STARS 1
3406             ;SET MAINT1 ;DCT11 DECODE AND CLEAR SEL0
3407             ;
3408             ;THE HOST SENDS A ROTATING PATTERN IN SEL6,AND SET TEST NUMBER 4 IN BSEL0
3409             ;
3410             ;DCT11 READ SEL6 , WRITE CONTENT OF SEL6 IN SEL2 , CLEAR SEL0 WHEN DONE , AND
3411             ;WAIT FOR NEW PATTERN
3412             ;
3413             ;
3414             ;
3415             ;      AFTER TEST      BSEL0=100 IF ERROR DURING TEST
3416             ;                      BSEL0=0   IF TEST HAS BEEN EXECUTED (IN THAT CASE
3417             ;                      CHECK IF CONTENT OF SEL4 IS CORRECT)
3418             ;
3419             ;BSEL 0 = 4 ;MICRO DIAG NB 4 ;DCT11 TAKE CONTENT OF SEL6 AND PUT IT IN SEL 2.
3420 025654      STARS 1
3421
3422
3423
3424 025654
3425 025654      BGNTST
3426 025656      004737 014550      JSR      PC,CLRKMV      ;CLEAR REG
3427 025662      004737 014730      JSR      PC,MAINM1     ;SET MAINT MODE 1
3428 025666      012703 000001      MOV      #1,R3         ;SELECT 1ST PATTERN
3429 025672      012737 000005      002414  TGENE2: MOV      #5,COUNT     ; " NUMBER OF PATTERN
3430 025700      BREAK
3431
3432
3433 025702      004737 013230      164602  GENE2: JSR      PC,GENER      ;GENERATE 1ST PATTERN
3434 025706      013777 012436      MOV      DATA,#KMVP06 ;LOAD SEL6
3435 025714      004537 015010      JSR      R5,TSTNUB     ;SET TEST NUMB 4
3436 025720      000004      .WORD   4
3437 025722      004537 013722      JSR      R5,CBSEL0     ;LOOK IF ANSWER
3438 025726      000000      .WORD   0
3439 025730      000404      BR      1$            ;OK BR
3440 025732      ERRHRD 16,EM0024,PBSEL0 ;NO KMV11 ANSWER,BSEL0 NOT = 0
3441 025742      000240      1$:
3442 025744      ENDSUB
3443
3444
3445 025746      BGNSUB
3446 025750      012704 025770      MOV      #TSEL6,R4     ;POINT GOOD VALUE
3447 025754      013764 012436      000010  MOV      DATA,10(R4)
3448 025762      013764 012436      000004  MOV      DATA,4(R4)   ;WRITE GOOD VALUE FOR SEL2 AND SEL6
3449
3450 025770      004537 014262      TSEL6: JSR      R5,CKREG   ;CHECK SEL2 = SEL6
3451 025774      000000      .WORD   0
3452 025776      000000      .WORD   0
3453 026000      000000      .WORD   0
3454 026002      000000      .WORD   0

```

F7

3455	026004	000000			.WORD	0	
3456	026006	000000			.WORD	0	
3457	026010	000000			.WORD	0	
3458	026012	000406			BR	2\$	
3459	026014				ERRHRD	17,EM0007,PRREG	
3460	026024				ESCAPE	SUB	
3461	026030	005337	002414	2\$:	DEC	COUNT	
3462	026034	001322			BNE	GENE2	
3463							
3464	026036	005203			INC	R3	;NEW PATTERN
3465	026040	022703	000006		CMP	#6,R3	;ALL DONE
3466	026044	001312			BNE	TGENE2	;NO BR
3467	026046						
3468	026050				ENDSUB		
					ENDTST		

```

3470 026052      BADHEAD
3471             ;***** TEST9 *****
3472 026052      ;TEST TO CHECK DATA TRANSFER ON REGISTER SEL10
                 BADHEAD
                 ;***** TEST9 *****

3473
3474
3475 026052      STARS 1
3476             ;SET MAINT1 ;DCT11 DECODE AND CLEAR SELO
3477             ;
3478             ;THE HOST SENDS A ROTATING PATTERN IN SEL10,AND SET TEST NUMBER 5 IN BSELO
3479             ;
3480             ;DCT11 READ SEL10 , WRITE CONTENT OF SEL10 IN SEL2 , CLEAR SELO WHEN DONE, AND
3481             ;WAIT FOR NEW PATTERN
3482             ;
3483             ;
3484             ;
3485             ;      AFTER TEST      BSELO=100 IF ERROR DURING TEST
3486             ;                      BSELO=0   IF TEST HAS BEEN EXECUTED (IN THAT CASE
3487             ;                      CHECK IF CONTENT OF SEL6 IS CORRECT)
3488             ;
3489             ;BSEL 0 = 5 ;MICRO DIAG NB 5 ;DCT11 TAKE CONTENT OF SEL10 AND PUT IT IN SEL 2.
3490 026052      STARS 1
3491
3492
3493
3494 026052      BGNTST
3495 026052      BGNSUB
3496 026054      004737 014550      JSR      PC,CLRKMV      ;CLEAR REG
3497 026060      004737 014730      JSR      PC,MAINM1     ;SET MAINT MODE 1
3498 026064      012703 000001      MOV      #1,R3        ;SELECT FIRST PATTERN
3499
3500 026070      012737 000005 002414  TGENE3: MOV      #5,COUNT
3501 026076      BREAK
3502
3503
3504 026100      004737 013230      GENE3:  JSR      PC,GENER      ;GENERATE A 1ST PATTERN
3505 026104      042737 040000 012436  BIC      #4C000,DATA    ;MASK BIT 14
3506 026112      013777 012436 164400  MOV      DATA,#KMVP10 ;LOAD SEL10
3507 026120      004537 015010      JSR      R5,TSTNUB     ;SET TEST NUMB 5
3508 026124      000005      .WORD    5
3509 026126      004537 013722      JSR      R5,CBSELO    ;LOOK IF ANSWER
3510 026132      000000      .WORD    0
3511 026134      000406      BR       1#          ;OK BR
3512 026136      ERRHRD 20,EM0024,PBSELO ;NO KMV11 ANSWER
3513 026146      ESCAPE  SUB
3514 026152      000240      1#:
3515 026154      ENDSUB
3516
3517
3518 026156      BGNSUB
3519 026160      012704 026200      MOV      #TSEL10,R4   ;POINT GOOD VALUE
3520 026164      013764 012436 000012  MOV      DATA,12(R4) ;WRITE GOOD VALUE FOR SEL2 AND SEL10
3521 026172      013764 012436 000004  MOV      DATA,4(R4)
3522
3523 026200      004537 014262      TSEL10: JSR      R5,CKREG ;CHECK SEL2 = SEL10
3524 026204      000000      .WORD    0

```

H7

```

3525 026206 000000      .WORD 0
3526 026210 000000      .WORD 0
3527 026212 000000      .WORD 0
3528 026214 000000      .WORD 0
3529 026216 000000      .WORD 0
3530 026220 000000      .WORD 0
3531 026222 000406      BR      2$
3532 026224      ERRHRD 21,EM0010,PRREG      ;DATA CMP ERROR IN SEL10
3533 026234      ESCAPE  SUB
3534
3535 026240 005337 002414      2$:  DEC      COUNT
3536 026244 001315      BNE      GENE3
3537
3538 026246 005203      INC      R3      ;NEW PATTERN
3539 026250 022703 000006      CMP      #6,R3   ;ALL DONE
3540 026254 001305      BNE      TGENE3  ;NO BR
3541 026256
3542 026260      ENDSUB
      ENDTST

```

```

3544 026262      BADHEAD
3545             ;***** TEST10 *****
3546 026262      ;TEST TO CHECK DATA TRANSFER ON REGISTER SEL12
                 BADHEAD
                 ;***** TEST10 *****
3547
3548
3549 026262      STARS 1
3550             ;SET MAINT1 ;DCT11 DECODE AND CLEAR SELO
3551             ;
3552             ;THE HOST SENDS A ROTATING PATTERN IN SEL12,AND SET TEST NUMBER 6 IN BSELO
3553             ;
3554             ;DCT11 READ SEL12 , WRITE CONTENT OF SEL12 IN SEL 2 , CLEAR SELO WHEN DONE , AND
3555             ;WAIT FOR NEW PATTERN
3556             ;
3557             ;
3558             ;
3559             ;      AFTER TEST      BSELO=100 IF ERROR DURING TEST
3560             ;                      BSELO=0   IF TEST HAS BEEN EXECUTED (IN THAT CASE
3561             ;                      CHECK IF CONTENT OF SEL10 IS CORRECT)
3562             ;
3563             ;BSEL 0 = 6 ;MICRO DIAG NB 6 ;DCT11 TAKE CONTENT OF SEL12 AND PUT IT IN SEL 2.
3564 026262      STARS 1
3565
3566
3567
3568 026262      BGNTST
3569 026262      BGNSUB
3570 026264      004737 014550      JSR      PC,CLRKMV      ;CLEAR REG
3571 026270      004737 014730      JSR      PC,HAINM1     ;SET MAINT MODE 1
3572 026274      012703 000001      MOV      #1,R3
3573
3574 026300      012737 000005 002414  TGENE4: MOV      #5,COUNT
3575 026306      BREAK
3576
3577
3578 026310      004737 013230      GENE4:  JSR      PC,GENER      ;GENERATE A 1ST PATTERN
3579 026314      013777 012436 164200  MOV      DATA,#KMVP12    ;LOAD SEL12
3580 026322      004537 015010      JSR      R5,TSTNUM      ;SET TEST NUMB 6
3581 026326      000006      .WORD    6
3582 026330      004537 013722      JSR      R5,CBSELO      ;LOOK IF ANSWER
3583 026334      000000      .WORD    0
3584 026336      000406      BR       1#             ;OK BR
3585 026340      ERRHRD 22,EM0024,PBSELO ;NO KMV11 ANSWER
3586 026350      ESCAPE SUB
3587 026354      000240      1#:
3588 026356      ENDSUB
3589
3590
3591 026360      BGNSUB
3592 026362      012704 026402      MOV      #TSEL12,R4     ;POINT GOOD VALUE
3593 026366      013764 012436 000014  MOV      DATA,14(R4)
3594 026374      013764 012436 000004  MOV      DATA,4(R4)   ;WRITE GOOD VALUE FOR SEL2 AND SEL12
3595
3596 026402      004537 014262      TSEL12: JSR      R5,CKREG   ;CHECK SEL2 = SEL12
3597 026406      000000      .WORD    0
3598 026410      000000      .WORD    0

```

```
3599 026412 000000 .WORD 0
3600 026414 000000 .WORD 0
3601 026416 000000 .WORD 0
3602 026420 000000 .WORD 0
3603 026422 000000 .WORD 0
3604 026424 000406 BR 2$
3605 026426 ERRHRD 23,EM0011,PRREG ;DATA CMP ERROR IN SET 12
3606 026436 ESCAPE SUB
3607
3608
3609 026442 005337 002414 2$: DEC COUNT
3610 026446 001320 BNE GENE4
3611
3612 026450 005203 INC R3 ;NEW PATTERN
3613 026452 022703 000006 CMP #6,R3 ;ALL DONE
3614 026456 001310 BNE TGENE4 ;NO BR
3615 026460 ENDSUB
3616 026462 ENDTST
```

17

```

3618 026464      BADHEAD
3619             ;***** TEST11 *****
3620 026464      ; CHECK DATA TRANSFER ON REGISTER SEL14
                 BADHEAD
                 ;***** TEST11 *****
3621
3622
3623 026464      STARS 1
3624             ;SET MAINT1 ;DCT11 DECODE AND CLEAR SELO
3625             ;
3626             ;THE HOST SEND ROTATING PATTERN IN SEL14,AND SET TEST NUMBER 6 IN BSELO
3627             ;
3628             ;DCT11 READ SEL14 , WRITE CONTENT OF SEL14 IN SEL 2 , CLEAR SELO WHEN DONE, AND
3629             ;WAIT FOR NEW PATTERN
3630             ;
3631             ;
3632             ;
3633             ; AFTER TEST          BSELO=100 IF ERROR DURING TEST
3634             ;                    BSELO=0   IF TEST HAS BEEN EXECUTED (IN THAT CASE
3635             ;                    CHECK IF CONTENT OF SEL12 IS CORRECT)
3636             ;
3637             ;BSEL 0 = 6 ;MICRO DIAG NB 6 ;DCT11 TAKE CONTENT OF SEL14 AND PUT IT IN SEL 12.
3638 026464      STARS 1
3639
3640
3641 026464      BGNTST
3642 026464      BGNSUB
3643 026466      004737 014550      JSR      PC,CLRKMV      ;CLEAR REG
3644 026472      004737 014730      JSR      PC,MAINM1     ;SET MAINT MODE 1
3645 026476      012703 000001      MOV      #1,R3        ;SELECT FIRST PATTERN
3646
3647 026502      012737 000005 002414 TGENE5: MOV      #5,COUNT      ;SELECT NB OF PATTERN
3648 026510      BREAK
3649
3650
3651 026512      004737 013230      GENE5: JSR      PC,GENER      ;GENERATE A 1ST PATTERN
3652 026516      013777 012436 164000 MOV      DATA,#KMVP14  ;LOAD SEL14
3653 026524      004537 015010      JSR      R5,TSTNUB     ;SET TEST NUMB 7
3654 026530      000007      .WORD 7
3655 026532      004537 013722      JSR      R5,CBSELO     ;LOOK IF ANSWER
3656 026536      000000      .WORD 0
3657 026540      000406      BR      1$           ;OK BR
3658 026542      ERRHRD 24,EM0024,PBSELO ;NO KMV11 ANSWER
3659 026552      ESCAPE SUB
3660
3661 026556      000240      1$: NOP
3662 026560      ENDSUB
3663
3664
3665 026562      BGNSUB
3666 026564      012704 026604      MOV      #TSEL14,R4    ;POINT GOOD VALUE
3667 026570      013764 012436 000016 MOV      DATA,16(R4)
3668 026576      013764 012436 000004 MOV      DATA,4(R4)   ;WRITE GOOD VALUE FOR SEL2 AND SEL4
3669
3670 026604      004537 014262      TSEL14: JSR      R5,CKREG ;CHECK SEL2 = SEL14
3671 026610      000000      .WORD 0
3672 026612      000000      .WORD 0

```



```
3673 026614 000000 .WORD 0
3674 026616 000000 .WORD 0
3675 026620 000000 .WORD 0
3676 026622 000000 .WORD 0
3677 026624 000000 .WORD 0
3678 026626 000406 BR 2$
3679 026630 ERRHRD 25,EM0012,PRREG ;DATA CMP ERROR IN SEL 14
3680 026640 ESCAPE SUB
3681
3682
3683 026644 005337 002414 2$: DEC COUNT ;DONE ENOUGH?
3684 026650 001320 BNE GENE5
3685
3686 026652 005203 INC R3 ;NEW PATTERN
3687 026654 022703 000006 CMP #6,R3 ;ALL DONE
3688 026660 001310 BNE TGENE5 ;NO BR
3689 026662 ENDSUB
3690 026664 ENDTST
```

```

3692 026666      BADHEAD
3693             ;***** TEST12 *****
3694 026666      ; CHECK DATA TRANSFER ON REGISTER SEL16
                 BADHEAD
                 ;***** TEST12 *****

3695
3696
3697 026666      STARS 1
3698             ;SET MAINT1 ;DCT11 DECODE AND CLEAR SELO
3699             ;
3700             ;THE HOST SENDS A ROTATING PATTERN IN SEL16,AND SET TEST NUMBER 7 IN BSELO
3701             ;
3702             ;DCT11 READ SEL16 , WRITE CONTENT OF SEL16 IN SEL 2 , CLEAR SELO WHEN DONE, AND
3703             ;WAIT FOR NEW PATTERN
3704             ;
3705             ;
3706             ;
3707             ;      AFTER TEST      BSELO=100 IF ERROR DURING TEST
3708             ;                      BSELO=0   IF TEST HAS BEEN EXECUTED (IN THAT CASE
3709             ;                      CHECK IF CONTENT OF SEL14 IS CORRECT)
3710             ;
3711             ;BSEL 0 = 10 ;MICRO DIAG NB 10 ;DCT11 TAKE CONTENT OF SEL16 AND PUT IT IN SEL 2
3712
3713
3714 026666      BGNTST
3715 026666      BGNSUB
3716 026670      004737 014550      JSR      PC,CLRKMV      ;CLEAR REG
3717 026674      004737 014730      JSR      PC,MAINM1     ;SET MAINT MODE 1
3718 026700      012703 000001      MOV      #1,R3        ;SELECT FIRST PATTERN
3719
3720 026704      012737 000005 002414  TGENE6. MOV      #5 COUNT
3721 026712      BREAK
3722
3723
3724 026714      004737 013230      GENE6: JSR      PC,GENER      ;GENERATE 1ST PATTERN
3725 026720      013777 012436 163600  MOV      DATA,#KMVP16  ;LOAD SEL16
3726 026726      004537 015010      JSR      R5,TSTNUB     ;SET TEST NUMB 10
3727 026732      000010      .WORD 10
3728 026734      004537 013722      JSR      R5,CBSELO     ;LOOK IF ANSWER
3729 026740      000000      .WORD 0
3730 026742      000406      BR      1$           ;OK BR
3731 026744      ERRHRD 26,EM0024,PBSELO ;NO KMV11 ANSWER
3732 026754      ESCAPE SUB
3733
3734 026760      000240      1$: NOP
3735 026762      ENDSUB
3736
3737
3738 026764      BGNSUB
3739 026766      012704 027006      MOV      #TSEL16,R4   ;POINT GOOD VALUE
3740 026772      013764 012436 000020  MOV      DATA,20(R4)
3741 027000      013764 012436 000004  MOV      DATA,4(R4)  ;WRITE GOOD VALUE FOR SEL2 AND SEL16
3742
3743 027006      004537 014262      TSEL16: JSR      R5,CKREG ;CHECK SEL2 = SEL16
3744 027012      000000      .WORD 0
3745 027014      000000      .WORD 0
3746 027016      000000      .WORD 0

```

N7

```
3747 027020 000000          .WORD 0
3748 027022 000000          .WORD 0
3749 027024 000000          .WORD 0
3750 027026 000000          .WORD 0
3751 027030 000406          BR      2$
3752 027032          ERPHRD 27,EM0013,PRREG
3753 027042          ESLAPE SUB
3754
3755
3756 027046 005337 002414      2$:    DEC      COUNT      ;DONE ENOUGH?
3757 027052 001320          BNF      GENE6
3758
3759 027054 005203          INC      R3          ;NEW PATTERN
3760 027056 022703 000006      CMP      #6,R3      ;ALL DONE
3761 027062 001310          BNE      TGENE6     ;NO BR
3762 027064          ENDSUB
3763 027066          ENDTST
3764
3765
3766
```

```

3768 027070      BADHEAD
3769             ;***** TEST13 *****
3770 027070      ; CHECK DATA TRANSFER ON ALL REGISTERS
                 BADHEAD
                 ;***** TEST13 *****

3771
3772
3773
3774
3775
3776 027070      STARS 1
3777             ;SET MAINT1 DCT11 CLEAR BSELO
3778             ;SEND DIFFERENT PATTERN IN SEL2, SEND TEST 11
3779             ;DCT11 READ SEL2 AND WRITE A CALCULATED VALUE IN SEL4 TO SEL16
3780             ;
3781             ;           (SEL4)=SEL2*SEL2
3782             ;           (SEL6)=SEL4*SEL2
3783             ;           (SEL10)=SEL6*SEL2
3784             ;           (SEL12)=SEL10*SEL2
3785             ;           (SEL14)=SEL12*SEL2
3786             ;           (SEL16)=SEL14*SEL2
3787             ;DCT11 CLEAR BSELO WHEN DONE
3788             ;
3789             ;-MICRO DIAG NUMBER 11
3790             ;
3791
3792
3793 027070      STARS 1
3794
3795
3796
3797
3798 027070      BGN1ST
3799 027070      004737 014550      JSR      PC,CLRKMV      ;CLEAR REG
3800 027074      004737 014730      JSR      PC,MAINM1    ;SET MAINT1
3801
3802
3803 027100      012703 000004      MOV      #4,R3        ;PREPARE INCREMENTING PATTERN
3804 027104      012737 000007 002416  MOV      #7,NUMBER    ;SELECT NUMBER FOR DIFFERENT PATTERN
3805
3806
3807
3808 027112      004737 013230      RGALL: JSR      PC,GENER    ;PREPARE ONE RANDOM PATTERN
3809
3810 027116      013777 012436 163366  MOV      DATA,BKMVPO2 ;WRITE PATTERN IN SEL2
3811 027124      013737 012436 002336  MOV      DATA,GOOD2
3812 027132      004537 015010      JSR      R5,TSTNUB    ;SEND TEST NB11
3813 027136      000011
3814
3815
3816 027140      012737 177700 002324  MOV      #177700,DELCT1
3817 027146      004737 013000      JSR      PC,WAIT1
3818
3819
3820 027152      BREAK
3821
3822 027154      004537 013722      JSR      R5,CBSELO    ;LOOK IF TEST DONE

```

CM

3823	027160	000000				WORD	0	
3824	027162	000406				BR	1:	
3825	027164					ERRHRD	28,EM0024,PRSELO	;YES BRANCH
3826	027174					ESCAPE	TST	;NO KMV11 ANSWER
3827								
3828								
3829	027200	017737	163306	002360	1:	MOV	8KMVP02,SEL2	;READ SEL2 TO SEL16
3830	027206	017737	163302	002362		MOV	8KMVP04,SEL4	
3831	027214	017737	163276	002364		MOV	8KMVP06,SEL6	
3832	027222	017737	163272	002366		MOV	8KMVP10,SEL10	
3833	027230	017737	163266	002370		MOV	8KMVP12,SEL12	
3834	027236	017737	163262	002372		MOV	8KMVP14,SEL14	
3835	027244	017737	163256	002374		MOV	8KMVP16,SEL16	
3836								
3837								
3838	027252	013737	002336	002340		MOV	GOOD2,GOOD4	
3839	027260	063737	002336	002340		ADD	GOOD2,GOOD4	
3840								
3841	027266	013737	002340	002342		MOV	GOOD4,GOOD6	;WHAT IS GOOD6
3842	027274	063737	002336	002342		ADD	GOOD2,GOOD6	
3843								
3844	027302	013737	002342	002344		MOV	GOOD6,GOOD10	;WHAT IS GOOD10
3845	027310	063737	002336	002344		ADD	GOOD2,GOOD10	
3846								
3847	027316	013737	002344	002346		MOV	GOOD10,GOOD12	; " " GOOD12
3848	027324	063737	002336	002346		ADD	GOOD2,GOOD12	
3849								
3850	027332	013737	002346	002350		MOV	GOOD12,GOOD14	; " " GOOD14
3851	027340	063737	002336	002350		ADD	GOOD2,GOOD14	
3852								
3853	027346	013737	002350	002352		MOV	GOOD14,GOOD16	; " " GOOD16
3854	027354	063737	002336	002352		ADD	GOOD2,GOOD16	
3855								
3856								
3857	027362	023737	002336	002360		CMP	GOOD2,SEL2	
3858	027370	001031				BNE	2:	
3859	027372	023737	002340	002362		CMP	GOOD4,SEL4	
3860	027400	001025				BNE	2:	
3861	027402	023737	002342	002364		CMP	GOOD6,SEL6	
3862	027410	001021				BNE	2:	
3863	027412	023737	002344	002366		CMP	GOOD10,SEL10	
3864	027420	001015				BNE	2:	
3865	027422	023737	002346	002370		CMP	GOOD12,SEL12	
3866	027430	001011				BNE	2:	
3867	027432	023737	002350	002372		CMP	GOOD14,SEL14	
3868	027440	001005				BNE	2:	
3869	027442	023737	002352	002374		CMP	GOOD16,SEL16	
3870	027450	001001				BNE	2:	
3871	027452	000410				BR	3:	
3872								
3873								
3874	027454				2:	BREAK		
3875	027456					ERRHRD	29,EM0003,PRREG	
3876	027466					BREAK		
3877	027470					ESCAPE	TST	
3878								
3879								

D8

KMV11 A-B LOGIC DIAG MACRO M1200 05-APR 84 11:25 PAGE 67 2
HARDWARE TESTS

SEQ 94

3880	027474	005337	002416	55:	DEC	NUMBER
3881	027500				BREAK	
3882	027502	001203			BNE	RGALL
3883	027504			ENDTST		

!ALL PATTERN DONE?

3885 027506
 3886
 3887 027506
 3888
 3889
 3890
 3891
 3892 027506
 3893
 3894
 3895
 3896
 3897
 3898
 3899
 3900
 3901
 3902
 3903
 3904
 3905
 3906
 3907
 3908
 3909
 3910
 3911
 3912
 3913
 3914
 3915
 3916
 3917 027506
 3918
 3919
 3920
 3921
 3922 027506
 3923 027506 004737 014550
 3924 027512 004737 014730
 3925
 3926 027516 005003
 3927 027520 005037 002414
 3928 027524 004737 013230
 3929 027530 013777 012436 162754
 3930
 3931
 3932 027536 004537 015010
 3933 027542 000013
 3934
 3935 027544
 3936
 3937
 3938 027564 004737 013152
 3939 027570 000441

```

BADHEAD
;***** TEST14 *****
;KMV11 RAM MEMORY TEST; MEMORY PATTERN TEST
BADHEAD
;***** TEST14 *****

STARS 1
;SET MAINT MODE 1 ;DCT11 DECODE AND CLEAR SEL 0
;THE HOST WRITES IN SEL2 THE PATTERN TO BE WRITTEN IN ALL MEMORY
;AND SETS TEST NUMBER TO 13
;
;DCT11 WRITE ALL THE MEMORY WITH THIS VALUE,CHECK IF OK AND
;WHEN DONE CLEAR BSELO IF TEST OK
;
;IF ERROR SEL2 = EXPECTED VALUE OF LOCATION IN ERROR
;          SEL4 = READ VALUE OF LOCATION IN ERROR
;          SEL6 = ADDRESS IN ERROR
;
;
;BSELO = 13 , MICRO DIAGNOSTIC TEST NUMBER 13
;DCT11 SEND PATTERN IN RAM MEMORY AND CHECK
;
;          PATTERN DESCRIPTION:
;          . ALL ZERO
;          . ALL ONE
;          . 10101010 PATERN
;          . 01010101 PATERN
;          . ROTATING 1
;          . ROTATING 0
;
STARS 1

BGNTST
RAMPAT: JSR PC,CLRKMV ;CLEAR REG
        JSR PC,MAINM1 ;SET MAINT1
        CLR R3 ;SELECT 1ST PATTERN
        CLR COUNT
        JSR PC,GENER ;MAKE PATTERN
        MOV DATA,BKMVP02 ;WRITE PATTERN IN SEL2

        JSR R5,TSTNU8 ;SET TEST NB 13
        .WORD 13
        WAITB 0,1

        JSR PC,TSTERR ;CHECK BSELO*WHICH ERROR?
        BR 1$ ;TEST OK
  
```

```

3940 027572 000420          BR      2$
3941
3942 027574 000427          BR      3$
3943
3944
3945
3946
3947
3948 027576 017737 162714 002420      MOV     @KMVP06,ADDR      ;READ ADDRESS OF RAM
3949 027604 017737 162702 002422      MOV     @KMVP02,GDDAT    ;READ EXPECTED DATA (GDDAT)
3950 027612 017737 162676 002424      MOV     @KMVP04,BDDAT    ;READ BAD VALUE OF DATA (BDDAT)
3951
3952 027620          ERRHRD 30,EM0015,PRRAM    ;DATA CMP ERROR ON ONE RAM LOCATION
3953 027630          ESCAPE  TST
3954
3955
3956
3957
3958
3959 027634 005037 002330      2$:    CLR     GOOD
3960 027640          ERRHRD 31,EM0025,PBSELO    ;TIMEOUT ERROR
3961 027650          ESCAPE  TST
3962
3963
3964
3965
3966
3967 027654 005037 002330      3$:    CLR     GOOD
3968 027660          ERRHRD 32,EM0024,PBSELO    ;NO KMV11 ANSWER
3969 027670          ESCAPE  TST
3970
3971
3972
3973
3974
3975 027674 005237 002414      1$:    INC     COUNT
3976 027700 022737 000015 002414      CMP     @15,COUNT        ;SEND 1 WORDS IN THE SAME PATTERN
3977 027706 001306          BNE     4$                ;15 WORDS DONE BR
3978
3979 027710 005037 002414          CLR     COUNT
3980 027714 005203          INC     R3                ;TRY WITH A NEW PATTERN
3981 027716 022703 000006          CMP     @6,R3             ;ALL DONE ?
3982 027722 001300          BNE     4$                ;NO BR
3983 027724          ENDTST

```


3985 027726

BADHEAD
:***** TEST15 *****
:KMV11 RAM MEMORY TEST: MEMORY ADDRESS TEST
BADHEAD
:***** TEST15 *****

3986
3987 027726

3988
3989
3990
3991
3992 027726

STARS 1
;SET MAINT MODE 1 ;DCT11 DECODE AND CLEAR SEL 0
;
;THE HOST SETS TEST NB 14 IN BSEL10
;DCT11 WRITE ADDRESS VALUE IN EACH ADDRESS LOCATIONS FOR ALL
;THE KMV11 RAM.(EXAMPLE: 1000=1000,1002=1002.....).
;DCT11 CLEAR BSELO IF TEST IS OK
; BSELO= 100 IF DATA COMPARE ERROR DURING CHECK
;
;IF ERROR SEL2 = EXPECTED VALUE OF LOCATION IN ERROR
; SEL4 = READ VALUE OF LOCATION IN ERROR
; SEL6 = ADDRESS IN ERROR
;
;
;
;
;BSELO = 14 , MICRO DIAGNOSTIC TEST NUMBER 14
; DCT11 WRITE ADDRESS VALUE IN ADDRESS LOCATION AND CHECK

3993
3994
3995
3996
3997
3998
3999
4000
4001
4002
4003
4004
4005
4006
4007
4008
4009

4010 027726
4011
4012
4013
4014

STARS 1

4015 027726
4016 027726 004737 014550
4017 027732 004737 014730
4018
4019 027736 004537 015010
4020 027742 000014
4021
4022 027744
4023
4024
4025

BGNTST
RAMADD: JSR PC,CLRKMV ;CLEAR REG
JSR PC,MAINM1 ;SET MAINT1
;JSR R5,TSTNUB ;SET TEST NB 14
;WORD 14
WAITB 0,1

4026 027764 004737 013152
4027 027770 000441
4028 027772 000420
4029 027774 000427
4030
4031
4032

JSR PC,TSYERR ;CHECK BSELO
BR 1\$;TEST OK
BR 2\$;TIMEOUT ERROR
BR 3\$;NO KMV11 ANSWER

4033 027776 017737 162514 002420
4034 030004 017737 162502 002330
4035 030012 017737 162476 002424
4036
4037 030020
4038 030030
4039

MOV 8KMVP06,ADDR ;READ ADDRESS OF RAM
MOV 8KMVP02,GOOD ;READ EXPECTED DATA (GDDAT)
MOV 8KMVP04,BDDAT ;READ BAD VALUE OF DATA (BDDAT)
ERRHRD 33,EM0015,PRRAM ;DATA CMP ERROR ON ONE RAM LOCATION
ESCAPE TST

4040						
4041						
4042						
4043						
4044	030034	005037	002330	2\$:	CLR GOOD	
4045	030040				ERRHRD 34,EM0025,PBSELO	;TIMEOUT ERROR
4046	030050				ESCAPE TST	
4047						
4048						
4049						
4050						
4051	030054	005037	002330	3\$:	CLR GOOD	
4052	030060				ERRHRD 35,EM0024,PBSELO	;NO KMV11 ANSWER
4053	030070				ESCAPE TST	
4054	030074	000240		1\$:	NOP	
4055	030076			ENDTST		

```

4057 030100      BADHEAD
4058             ;***** TEST16 *****
4059 030100      ;KMV11 RAM MEMORY TEST: MEMORY ADDRESS COMPLEMENT TEST
                BADHEAD
                ;***** TEST16 *****

4060
4061
4062
4063
4064 030100      STARS 1
4065             ;SET MAINT MODE 1 ;DCT11 DECODE AND CLEAR SEL 0
4066             ;SET TEST NUMBER 15 ;DCT11 EXECUTE TEST
4067             ;DCT11 WRITE COMPLEMENT ADDRESS VALUE IN EACH ADDRESS LOCATION AND CHECK.
4068             ;
4069             ;DCT11 CLEAR BSELO IF TEST OK AND PUT 100 IN BSELO IF DATA COMPARE ERROR
4070             ;
4071             ;IF ERROR SEL2 = EXPECTED VALUE OF LOCATION IN ERROR
4072             ;           SEL4 = READ VALUE OF LOCATION IN ERROR
4073             ;           SEL6 = ADDRESS IN ERROR
4074             ;
4075             ;
4076             ;
4077             ;
4078             ;BSELO = 15 , MICRO DIAGNOSTIC TEST NUMBER 15
4079             ;           DCT11 WRITE COMPL. ADDRESS IN ADDRESS IN RAM MEMORY AND CHECK
4080 030100      STARS 1
4081
4082
4083
4084
4085 030100
4086 030100      004737 014550      BGNTST
4087 030104      004737 014730      RAMCAD: JSR    PC,CLRKMV      ;CLEAR REG
                JSR    PC,MAINM1  ;SET MAINT1
4088
4089 030110      004537 015010      JSR    R5,TSTNUB      ;SET TEST NB 15
4090 030114      000015              .WORD 15
4091
4092 030116      WAITB 0,1
4093
4094
4095
4096 030136      004737 013152      JSR    PC,TSTERR      ;CHECK BSELO,WHICH ERROR
4097 030142      000441              BR     1$             ;TEST OK
4098 030144      000420              BR     2$             ;TIMEOUT ERROR
4099 030146      000427              BR     3$             ;NO KMV11 ANSWER
4100
4101
4102 030150      017737 162342 002420      MOV    BKMP06,ADDR      ;READ ADDRESS OF RAM
4103 030156      017737 162330 002330      MOV    BKMP02,GOOD      ;READ EXPECTED DATA (GDDAT)
4104 030164      017737 162324 002424      MOV    BKMP04,BDDAT     ;READ BAD VALUE OF DATA (BDDAT)
4105
4106 030172      ERRHRD 36.EM0015,PRRAM      ;DATA CMP ERROR ON ONE RAM LOCATION
4107 030202      ESCAPE TST
4108
4109
4110
4111

```

```

4112 030206 005037 002330      2$: CLR      GOOD
4113 030212                ERRHRD 37,EM0025,PBSELO ;TIMEOUT ERROR
4114 030222                ESCAPE TST
4115
4116
4117
4118
4119
4120 030226 005037 002330      3$: CLR      GOOD
4121 030232                ERRHRD 38,EM0024,PBSELO ;NO KMV11 ANSWER
4122 030242                ESCAPE TST
4123
4124
4125
4126
4127 030246 000240      1$: NOP
4128 030250                ENDTST
4129
4130

```

```

4132 030252          BADHEAD
4133                ;***** TEST17 *****
4134 030252          ;CHECK PROM REVISION TO SEE IF COMPATIBLE WITH DIAGNOSTIC
                    BADHEAD
                    ;***** TEST17 *****
4135
4136
4137
4138
4139 030252          STARS 1
4140                ;READ LOCATION 2 OF THE PROM (ADDRESS 160002) WHICH CONTENTS PROM VERSION
4141                ;      NUMBER
4142                ;CHECK IF DIAGNOSTIC AND PROM ARE COMPATIBLE AND GIVE AN ERROR IF NOT
4143 030252          STARS 1
4144
4145
4146
4147
4148
4149 030252          BGNTST
4150 030252 004737 014550      JSR      PC,CLRKMV      ;CLEAR ALL REGISTERS
4151 030256 004737 014730      JSR      PC,MAINM1     ;SET MAINT MODE
4152
4153
4154 030262 004537 015072      REVPRO: JSR      R5,READ      ;READ LOCATION 160002
4155 030266 160002              .WORD      160002
4156
4157
4158 030270 023737 012464 012432  CMP      GDREV,BAD      ;LOOK IF COMPATIBLE
4159 030276 001406              BEQ      1$              ;YES
4160
4161 030300              ERRHRD 39,EM0034      ;REPORT THE ERROR
4162 030310              ESCAPE TST
4163 030314
4164 030314          1$:
                    ENDTST

```

```

4166
4167 030316      BADHEAD
                  ;***** TEST18 *****
4168              ;PROM CHECKSUM TEST
4169 030316      BADHEAD
                  ;***** TEST18 *****

4170
4171
4172
4173
4174 030316      STARS 1
4175              ;DIAGNOSIC READS ALL PROM'S LOCATIONS AND ADDS THEN TOGETHER
4176              ;RESULT MUST BE ZERO
4177              ;
4178              ;
4179              ;TEST 33 DESCRIPTION:
4180              ;DCT11 ADD ALL PROMS LOCATIONS ,IF RESULT IS ZERO=CLEAR BSELO
4181              ;
4182 030316      STARS 1
                  ;IF CHECKSUM ERROR *SET 100 IN BSELO
4183
4184
4185
4186
4187
4188
4189
4190
4191 030316      BGNTST
4192 030316      004737 014550      JSR      PC,CLRKMV      ;CLEAR REGISTERS
4193 030322      004737 014730      JSR      PC,MAINM1     ;SET MAINTENANCE MODE
4194
4195
4196 030326      004537 015010      PROMCK: JSR      R5,TSTNUB
4197 030332      000033              .WORD      33              ;SET TEST 33
4198
4199 030334              WAITB      0,1
4200
4201 030354      004737 013152      JSR      PC,TSTERR     ;TEST IF ERROR
4202 030360      000427              BR        1$           ;TEST OK
4203 030362      000412              BR        2$           ;TIMEOUT ERROR
4204 030364      000417              BR        3$           ;NO ANSWER FROM KMV11
4205
4206
4207 030366      017737 162120 012432  MOV      8,KMVP02,BAD   ;CHECKSUM ERRGR
4208 030374              ERRHRD    40,EM0035,PCHECK
4209 030404              ESCAPE     TST
4210
4211
4212 030410      2$:      ERRHRD    41,EM0025
4213 030420              ESCAPE     TST              ;TIMEOUT DURING TEST
4214
4215
4216 030424      3$:      ERRHRD    42,EM0024
4217 030434              ESCAPE     TST              ;NO KMV ANSWER
4218
4219
4220 030440      000240      1$:      NOP

```

4221
4222 030442
4223
4224
4225
4226
4227
4228
4229
4230

ENDTST

```

4232
4233 030444      BADHEAD
                  ;***** TEST19 *****
4234              ;TEST DMA TRANSFER IN KMV11
4235 030444      BADHEAD
                  ;***** TEST19 *****

4236
4237
4238
4239
4240 030444      STARS 1
4241              ;SET MAINT1 ;DCT11 DECODE AND CLEAR BSELO
4242              ;LOAD FIRST ADDRESS OF TX TABLE IN SEL12 , TABLE LENGTH IN SEL14,
4243              ;TX TABLE EXTENDED ADDRESS IN BSEL 10.
4244              ;
4245              ;SET TEST NUMBER (16 OR 17)IN BSELO
4246              ;DCT11 EXECUTE THE DMA TRANSFER OF THE TABLE IN KMV11 RAM AND CHECK.
4247              ;WHEN DONE CLEAR BSELO IF TEST OK
4248              ;SET 200 IN BSELO IF TIMEOUT DURING TEST
4249              ;SET 100 IN BSELO IF ERROR DURING TRANSFER
4250              ;IN THAT CASE          SEL2=EXPECTED VALUE
4251              ;                          SEL4=READ VALUE
4252              ;                          SEL6=ADDRESS LOCATION OF ERROR
4253              ;                          BSEL10=EXTENDED ADDRESS
4254              ;TEST DESCRIPTON: PDP GENERATE AN INCREMENTING PATTERN TABLE OF 1K WORDS
4255              ;SEND STARTING ADDRESS AND TABLE LENGTH TO KMV11
4256              ;KMV11 START DMA TRANSFER AND CHECK
4257              ;
4258
4259              ;TEST 16 = TABLE CONTENT INCREMENTING PATTERN FROM 0
4260              ;TEST 17 = EACH LOCATION CONTENT ADDRESS VALUE OF LOCATION
4261 030444      STARS 1
4262
4263
4264
4265
4266 030444      BGNIST
4267 030444      DMAIN: JSR      PC,CLRKMV          ;CLEAR REG
4268 030450      004737 014550          JSR      PC,MAINM1          ;SET MAINT 1
4269 030454      BGNSUB
4270 030456      012701 002426          MOV      #TTABLE,R1          ;POINT TX TABLE
4271 030462      005002                  CLR      R2                  ;CLR TABLE
4272 030464      010221          1$: MOV      R2,(R1)+          ;MAKE AN INCREMENTING PATTERN FROM 0
4273 030466      005202                  INC      R2
4274 030470      022702 002000          CMP      #2000,R2          ;TABLE LENGTH=1K WORDS
4275 030474      001373                  BNE     1$
4276
4277
4278
4279 030476      012777 002426 162016      MOV      #TTABLE,@KMVP12          ;SET TX TABLE ADDRESS
4280 030504      012777 002000 162012      MOV      #2000,@KMVP14          ;SET TABLE LENGTH
4281 030512      005077 162002                  CLR      @KMVP10          ;CLEAR EXTENDED ADDRESS
4282 030516      004537 015010          JSR      R5,TSTNUB          ;SEND TEST NB 16
4283 030522      000016                  .WORD   16
4284
4285
4286 030524      WAITB 0.1                  ;WAIT FOR TEST EXECUTION
    
```



```

4287
4288
4289
4290 030544 004737 013152      JSR      PC,TSTERR      ;CHECK BSFL0 ,WHICH ERROR
4291 030550 000444              BR        2$            ;TEST OK
4292 030552 000423              BR        3$            ;TIMEOUT ERROR
4293 030554 000432              BR        4$            ;NO KMV11 ANSWER
4294
4295
4296
4297
4298
4299 030556 017737 161730 002330  MOV      @KMVP02,GOOD    ;READ GOOD DATA
4300 030564 017737 161724 002424  MOV      @KMVP04,BDDAT   ;READ BAD DATA
4301 030572 017737 161720 002420  MOV      @KMVP06,ADDR    ;READ ERROR ADDRESS
4302 030600 117737 161714 012426  MOVB     @KMVP10,EXADDR  ;READ EXTENDED ADDRESS
4303 030606              ERRHRD   43,EM0020,PRDMA ;DATA CMP ERROR DURING DMA IN TX
4304 030616              ESCAPE   SUB
4305
4306
4307
4308
4309
4310 030622 005037 002330      3$:     CLR      GOOD
4311 030626              ERRHRD   44,EM0016,PBSFL0 ;TIMEOUT ERROR
4312 030636              ESCAPE   SUB
4313
4314
4315 030642 005037 002330      4$:     CLR      GOOD
4316 030646              ERRHRD   45,EM0024,PBSFL0 ;NO KMV ANSWER
4317 030656              ESCAPE   SUB
4318
4319
4320 030662 000240              2$:     NOP
4321 030664              ENDSUB
4322
4323
4324
4325 030666              BGNSUB
4326 030670 004737 014730      JSR      PC,MAINM1
4327 030674 012704 002426      MOV      @TTABLE,R4     ;POINT TTABLE
4328 030700 012702 002000      MOV      @2000,R2      ;TABLE LENGTH
4329 030704 010401              1$:     MOV      R4,R1
4330 030706 010124              MOV      R1,(R4)+     ;TABLE LOCATION CONTENT TABLE LOCATION ADDRESS
4331 030710 005302              DEC      R2
4332 030712 001374              BNE     1$
4333
4334
4335 030714 012777 002426 161600  MOV      @TTABLE,@KMVP12 ;SEND TABLE ADDRESS
4336 030722 012777 002000 161574  MOV      @2000,@KMVP1A  ; " " LENGTH
4337 030730 004537 015010      JSR      R5,TSTNVB     ;SET TEST NB 17
4338 030734 000017              .WORD   17
4339
4340
4341 030736              WAITB   0.1           ;WAIT FOR TEST EXECUTION
4342
4343

```

```

4344 030756 004737 013152      JSR      PC,ISTERR      ;CHECK BASEL0
4345 030762 000444              BR       2$             ;TEST OK
4346 030764 000423              BR       3$             ;TIMEOUT ERROR
4347 030766 000432              BR       4$             ;NO KMV ANSWER
4348
4349
4350
4351
4352 030770 017737 161516 002330      MOV      @KMVP02,GOOD    ;READ GOOD
4353 030776 017737 161512 002424      MOV      @KMVP04,BDDAT   ; " BAD
4354 031004 017737 161506 002420      MOV      @KMVP06,ADDR    ; " ERROR ADDRESS
4355 031012 117737 161502 012426      MOVB    @KMVP10,EXADDR   ; " EXTENDED ADDRESS
4356
4357 031020              ERRHRD  46,EM0020,PRDMA  ;DATA CMP ERROR
4358 031030              ESCAPE  SUB
4359
4360
4361
4362 031034 005037 002330      3$:     CLR      GOOD
4363 031040              ERRHRD  47,EM0016,PBSELO ;TIMEOUT ERROR
4364 031050              ESCAPE  SUB
4365
4366
4367
4368
4369 031054 005037 002330      4$:     CLR      GOOD
4370 031060              ERRHRD  48,EM0024,PBSELO ;NO KMV ANSWER
4371 031070              ESCAPE  SUB
4372
4373
4374
4375
4376 031074 000240      2$:     NOP
4377 031076              ENDSUB
4378 031100              ENDTST

```

```

4380 031102      BADHEAD
                  ;***** TEST20 *****
4381              ;TEST DMA TRANSFER OUT KMV11
4382 031102      BADHEAD
                  ;***** TEST20 *****
4383
4384
4385
4386
4387 031102      STARS 1
4388              ;SET MAINT1 ;DCT11 DECODE AND CLEAR BSELO
4389              ;LOAD FIRST ADDRESS OF RX TABLE IN SEL12 AND RX TABLE LENGTH IN SEL14
4390              ;EXTENDED ADDRESS IN BSEL10
4391
4392              ;SET TEST NUMBER 20,21 ;DCT11 EXECUTE TEST
4393              ;WHEN DONE CLEAR BSELO IF TEST OK
4394              ;SET 200 IN BSELO IF TIMEOUT DURING TEST
4395              ;
4396              ;
4397              ;
4398              ;TEST 20 DESCRIPTION: DCT11 SEND IN DMA AN INCREMENTING PATTERN (OF 1K WORDS)
4399              ;                               IN HOST MEMORY. THIS PATTERN STARS AT ADDRESS FOUND
4400              ;                               IN SEL12 (RX TABLE)
4401              ;                               WHEN DONE CLEAR BSELO
4402              ;                               HOST CHECK IF THE RECEIVE TABLE IS CORRECT
4403
4404
4405              ;TEST 21 DESCRIPTION. IDEM BUT TABLE CONTENT ADDRESS VALUE OF EACH LOCATION
4406 031102      STARS 1
4407
4408
4409
4410
4411 031102      BGN1ST
4412 031102      BGN5UB
4413 031104      004737 014550      DMAOUT: JSR      PC,CLARKMV      ;CLEAR REG
4414 031110      004737 014730      JSR      PC,MAINM1      ;SET MAINT 1
4415 031114      005037 002320      CLR      FLAG
4416 031120      012701 006426      MOV      @RTABLE,R1      ;POINT RX TABLE
4417 031124      012702 002000      MOV      @2000,R2      ;CLR RX TABLE
4418 031130      005021      1$: CLR      (R1)+
4419 031132      005302      DEC      R2
4420 031134      001375      BNE     1$
4421
4422
4423
4424 031136      012777 006426 161356      MOV      @RTABLE,@KMVP12      ;SET RX TABLE ADDRESS
4425 031144      012777 002000 161352      MOV      @2000,@KMVP14      ;SET TABLE LENGTH
4426 031152      105077 161342      CLRB    @KMVP10      ;CLEAR EXTENDED ADDRESS
4427 031156      004537 015010      JSR      R5,TSTNUB      ;SEND TEST NB 20
4428 031162      000020      .WORD   20
4429
4430
4431
4432 031164      WAITB 0.1      ;WAIT FOR TEST EXECUTION
4433
4434

```

```

4435 031204 004737 013152      JSR      PC,ISTERR      ;CHECK BSELO;WHICH FPRUR
4436 031210 000423              BR        2$            ;TEST OK
4437 031212 000402              BR        5$            ;TIMEOUT ERROR
4438 031214 000411              BR        6$            ;NO KMV ANSWER
4439 031216 000420              BR        2$
4440
4441
4442 031220 005037 002330      5$:     CLR        GOOD
4443 031224              ERRHRD    49,EM0016,PBSELO ;TIMEOUT ERROR
4444 031234              ESCAPE    SUB
4445
4446
4447
4448 031240 005037 002330      6$:     CLR        GOOD
4449 031244              ERRHRD    50,EM0024,PBSELO ;NO KMV ANSWER
4450 031254              ESCAPE    SUB
4451
4452
4453
4454
4455
4456 031260 012701 006426      2$:     MOV        @RTABLE,R1 ;CHECK RX TABLE
4457 031264 005037 002422              CLR        GDDAT        ;1ST WORD
4458
4459 031270 010137 002420      3$:     MOV        R1,ADDR
4460 031274 023711 002422              CMP        GDDAT,(R1)   ;COMPARE
4461 031300 001431              BEQ        4$            ;GOOD BR
4462
4463 031302 011137 002424              MOV        (R1),BDDAT
4464
4465 031306 005737 002320              TST        FLAG
4466 031312 001007              BNE        7$            ;LOOK IF 1ST MESSAGE OR EXTENDED ONE
4467 031314              ERRHRD    51,EM0030,PRDMA
4468
4469 031324 005237 002320              INC        FLAG
4470 031330 000415              BR        4$
4471
4472 031332              7$:     ERKHRD    51,0,PDMAF ;DATA CMP ERROR
4473 031342              BREAK
4474 031344 005237 002320              INC        FLAG
4475 031350 022737 000010 002320      CMP        @10,FLAG     ;REPORT 10 FIRST ERROR
4476 031356 001002              BNE        4$
4477 031360              ESCAPE    SUB
4478
4479
4480
4481
4482 031364 005237 002422      4$:     INC        GDDAT ;CHECK NEW LOCATION
4483 031370 062701 000002              ADD        @2,R1
4484 031374 022737 002000 002422      CMP        @2000,GDDAT ;ALL DONE
4485 031402 001332              BNE        3$
4486 031404              ENDSUB
4487
4488
4489
4490
4491

```

```

4492 031406          BGNSUB
4493 031410 005037 002320      CLR      FLAG
4494 031414 004737 014730      JSR      PC,MAINM1
4495 031420 012777 006426 161074  MOV      @RTABLE,&KMVP12      ;LOAD RX TABLE IN SEL12
4496 031426 005077 161066      CLR      &KMVP10
4497 031432 012777 002000 161064  MOV      @2000,&KMVP14      ;LOAD TABLE LENGTH
4498
4499
4500 031440 012702 002000      MOV      @2000,R2            ;TABLE LENGTH
4501 031444 012701 006426      MOV      @RTABLE,R1
4502 031450 005021          10$:  CLR      (R1)+              ;CLEAR RX TABLE
4503 031452 005302          DEC      R2
4504 031454 001375          BNE     10$
4505
4506
4507
4508
4509 031456 004537 015010      JSR      R5,TSTNUB          ;LOAD TEST NB21
4510 031462 000021          .WORD   21
4511
4512 031464          WAITB   0,1                ;WAIT FOR TEST EXECUTION
4513
4514
4515 031504 004737 013152      JSR      PC,TSTERR          ;CHECK BSELO;WHICH ERROR
4516 031510 000423          BR      2$                ;TEST OK
4517 031512 000402          BR      5$                ;TIMEOUT ERROR
4518 031514 000411          BR      6$                ;NO ANSWER
4519 031516 000420          BR      2$                ;DATA CMP ERROR
4520
4521
4522
4523 031520 005037 002330          5$:  CLR      GOOD
4524 031524          ERRHRD 52,EM0016,PBSELO      ;TIMEOUT ERROR
4525 031534          ESCAPE  SUB
4526
4527
4528
4529 031540 005037 002330          6$:  CLR      GOOD
4530 031544          ERRHRD 53,EM0024,PBSELO      ;NO KMV11 ANSWER
4531 031554          ESCAPE  SUB
4532
4533
4534
4535
4536
4537
4538 031560 012702 002000          2$:  MOV      @2000,R2
4539 031564 012737 006426 002420  MOV      @RTABLE,ADDR      ;VERIFY RX TABLE
4540 031572 012737 006426 002422  MOV      @RTABLE,GDDAT
4541
4542 031600 023737 002422 002420  3$:  CMP      GDDAT,ADDR        ;CMP TABLE
4543 031606 001432          BEQ     4$
4544 031610 017737 150604 002424  MOV      @ADDR,BDDAT      ;READ BAD DATA
4545
4546
4547 031616 005737 002320      TST     FLAG
4548 031622 001007          BNE     1$                ;LOOK IF 1ST REPORT

```

```

4549
4550
4551 031624          ERRHRD  54,EM0030,PRDMA      ;DATA CMP ERROR IN R% TABLE
4552 031634 005237 002320      INC      FLAG
4553 031640 000415          BR      4$
4554
4555 031642          1$:      ERRHRD  54,0,PDMAF      ;SHORT ERROR REPORT
4556 031652          BREAK
4557 031654 005237 002320      INC      FLAG
4558 031660 022737 000010 002320  CMP     #10,FLAG      ;REPORT 10 ERROR
4559 031666 001002          BNE     4$
4560 031670          ESCAPE  SUB
4561
4562
4563 031674 062737 000002 002422 4$:      ADD     #2,GDDAT      ;VERIFY NEXT LOCATION
4564 031702 062737 000002 002420      ADD     #2,ADDR
4565 031710 005302          DEC     R2
4566 031712 001332          BNE     3$      ;ALL DONE:
4567                                     ;NO BRANCH
4568 031714          ENDSUB
4569 031716          ENDTST
4570
    
```

```

4572 031720      BADHEAD
4573             ;***** TEST21 *****
4574 031720      ;TEST DMA TRANSFER IN BOTH DIRECTION
                   BADHEAD
                   ;***** TEST21 *****

4575
4576
4577
4578
4579
4580 031720      STARS 1
4581             ;SET MAINT1      ; DCT11 DECODE AND CLEAR BSEL0
4582             ;THE HOST SET ALL THE PARAMETERS IN CSR'S
4583             ;LOAD TX TABLE ADDRESS IN SEL12, TABLE LENGTH IN SEL14, EXTENDED ADDRESS IN BSEL10
4584             ;EXTENDED ADDRESS OF RX TABLE IN BSEL2 , ADDRESS OF RX TABLE IN SEL4 AND
4585             ;RAM STARTING ADDRESS FOR TRANSFER IN SEL6.
4586             ;
4587             ;
4588             ;LOAD TEST NUMBER 22 ; DCT11 EXECUTE TEST
4589             ; WHEN DONE CLEAR BSEL0 IF TEST OK OR SET 200 IN BSEL0 IF TIMEOUT DURING DMA.
4590             ;
4591             ;TEST DESCRIPTION:
4592             ; HOST COMPUTER GENERATES DIFFERENT 1K WORD TABLES ,GIVES ALL PARAMETERS IN
4593             ; THE CSR'S AND SET TEST 22 IN BSEL0
4594             ; DCT11 TAKES SEL6 AS THE STARTING ADDRESS FOR THE DIFFERENT TRANSFERS IN KMV11
4595             ; RAM MEMORY (DMA INTO KMV11) AND TRANSFER THIS TABLE IN DMA BACK TO HOST
4596             ; MEMORY (DMA OUT).
4597             ;
4598             ; DATA TRANSFER ARE MADE IN DIFFERENT AREAS IN RAM AND DCT11 CHECKS
4599             ; THAT THE UNUSED PART OF THE RAM IS NOT MODIFIED
4600             ;
4601             ; WHEN TRANSFER IN BOTH DIRECTION HAS BEEN DONE ,DCT11 CLEAR BSEL0 AND
4602             ; HOST COMPARES RX AND TX TABLE
4603             ;
4604             ;
4605             ;ERROR REPORT IN BSEL0:
4606             ;                               200=TIMEOUT DURING DMA
4607             ;                               100=UNUSED MEMORY MODIFIED DURING TRANSFER
4608             ;                               IN THAT CASE SEL2 =GOOD
4609             ;                               SEL4 =BAD
4610             ;                               SEL6 = ADDRESS
4611             ;
4612             ;
4613 031720      STARS 1
4614
4615
4616
4617
4618 031720      BGNTST
4619 031720      012737 065000 012462      MOV      *65000,MAXCNT      ;RAM MEMORY MAX LENGTH
4620 031726      005037 002320      CLR      FLAG
4621
4622 031732      012703 000002      MOV      *2,R3      ;SELECT 1ST PATTERN
4623 031736      004737 014550      DMATWO: JSR     PC,CLRKMV      ;CLEAR REG
4624 031742      005037 002414      CLR      COUNT      ;SELECT RAM STARTING ADDRESS FOR TX
4625 031746      BREAK
4626

```

```

4627 031750 004737 014730          TWODMA: JSR      PC,MAINM1          ;SET MAINT 1
4628
4629
4630
4631 031754 012702 002000          MOV      #2000,R2
4632 031760 012701 006426          MOV      #RTABLE,R1
4633 031764 005021          10$:    CLR      (R1)+          ;CLEAR RX TABLE
4634 031766 005302          DEC      R2
4635 031770 001375          BNE     10$
4636
4637
4638
4639
4640
4641
4642 031772 012702 002000          MOV      #2000,R2
4643 031776 012701 002426          MOV      #RTABLE,R1
4644 032002 004737 013230          1$:    JSR      PC,GENER          ;MAKE A PATTERN
4645
4646 032006 013721 012436          MOV      DATA,(R1)+          ;WRITE ONE TABLE LOCATION
4647 032012 005302          DEC      R2                   ;ALL LOCATION DONE?
4648 032014 001372          BNE     1$                    ;NO
4649
4650 032016 005077 160476          CLR      #KMVP10              ;CLEAR EXTENDED ADDRESS
4651 032022 013777 002414 160476          MOV      COUNT,#KMVP16        ;LOAD STATING ADDRESS IN RAM
4652
4653 032030 012777 002426 160464          MOV      #RTABLE,#KMVP12      ;SEND TX TABLE ADDRESS
4654 032036 012777 002000 160460          MOV      #2000,#KMVP14        ;SEND TABLE LENGTH
4655 032044 012777 006426 160442          MOV      #RTABLE,#KMVP04      ;SEND RX TABLE IN SEL4
4656 032052 005077 160434          CLR      #KMVP02              ;CLR RX TABLE EXT ADDRESS
4657 032056 004537 015010          JSR      R5,TSTNU8            ;LOAD TEST N# 22
4658 032062 000022          .WORD   22
4659
4660 032064 012737 070000 002324          MOV      #70000,DELCT1        ; SET DELAY COUNTER
4661 032072 117700 160412          11$:    MOVB    #KMVCSR,R0           ; GET BSELO
4662 032076 105700          TSTB    R0                    ; SEE IF TEST DONE OR CSR/DMA INTERFERENCE
4663 032100 001452          BEQ     3$                     ; CHECK XMT/RCV BUFFER
4664 032102 005237 002324          INC     DELCT1                 ; UPDATE TIMEOUT COUNTER
4665 032106 001371          BNE     11$                     ; BR IF NOT TIMED OUT
4666 032110 000407          BR      6$                     ; TIME-OUT
4667
4668 032112          BREAK
4669
4670
4671 032114 004737 013152          JSR      PC,TSTERR            ;CHECK BSELO;WHICH ERROR
4672 032120 000442          BR      3$                     ;TEST OK
4673 032122 000402          BR      6$                     ;TIME OUT
4674 032124 000411          BR      7$                     ;NO KMV11 ANSWER
4675 032126 000420          BR      20$                    ;PROBLEM IN THE UNUSED PART OF RAM:
4676          ;DMA TRANSFER MODIFY UNUSED RAM
4677          ; LOCATIONS.
4678
4679
4680
4681 032130 005037 002330          6$:    CLR      GOOD
4682 032134          ERRH#D 55,EM0016,PBSELO      ;TIMEOUT ERROR
4683 032144          ESCAPE TST
    
```



```

4684
4685
4686
4687 032150 005037 002330      7$:  CLR      GOOD
4688 032154                ERRHRD  56,EM0024,PBSEL 0      ;NO KMV11 ANSWER
4689 032164                ESCAPE   TST
4690
4691
4692
4693 032170 017737 160322 002420 20$:  MOV      @KMVP06,ADDR      ;READ ADD IN ERROR
4694 032176 017737 160310 002330      MOV      @KMVP02,GOOD      ;GOOD VALUE
4695 032204 017737 160304 002424      MOV      @KMVP04,BDDAT     ;READ WRONG VALUE
4696 032212                ERRHRD  57,EM0033,PDARA     ;DATA ERROR IN RAM DURING TRANSFER
4697 032222                ESCAPE   TST
4698
4699
4700
4701
4702 032226 005077 160256      3$:  CLR      @KMVCSR
4703 032232 000240                NOP
4704 032234 012777 044000 160246      MOV      @MAINT1,@KMVCSR   ;STOP TEST 2: IN KMV
4705 032242 012701 002426      MOV      @TABLE,R1        ;TX TABLE ADDRESS
4706 032246 012704 006426      MOV      @TABLE,R4        ;RX " "
4707 032252 012702 002000      MOV      @2000,R2        ;TABLE LENGHT
4708
4709
4710
4711 032256 021114      4$:  CMP      (R1),(R4)        ;CMP RX TABLE AND TX TABLE
4712 032260 001437                BEQ      5$                ;OK TEST NEXT LOCATION
4713
4714
4715 032260 011137 002422                MOV      (R1),GDDAT        ;PREPARE ERROR REPORT
4716 032260 011437 002424                MOV      (R4),BDDAT
4717 032272 010437 002420                MOV      R4,ADDR
4718 032276 005037 012426                CLR      EXADDR
4719
4720 032302 005737 002320                TST      FLAG
4721 032306 001007                BNE     2$
4722 032310                ERRHRD  58,EM0021,PRDMA     ;DATA CMP ERROR IN TABLE
4723 032320 005237 002320                INC     FLAG
4724 032324 000415                BR      5$
4725
4726
4727 032326      2$:  ERRHRD  58,0,PDMAF        ;REPORT 10 FIRST ERROR
4728 032336                BREAK
4729 032340 005237 002320                INC     FLAG
4730 032344 022737 000010 002320      CMP      @10,FLAG
4731 032352 001002                BNE     5$
4732 032354                ESCAPE   TST
4733
4734
4735
4736
4737 032360 005721      5$:  TST      (R1)+
4738 032362 005724                TST      (R4)+
4739 032364 005302                DEC     R2
4740 032366 001333                BNE     4$                ;ALL MEMORY TESTED?
                                ;NO BRANCH

```

```
4741
4742
4743 032370 062737 002000 002414      ADD    #2000,COUNT      ;USE OTHER PART OF RAM
4744 032376 023737 002414 012462      CMP    COUNT,MAXCNT    ;IS ALL RAM USED?
4745 032404 100002
4746 032406 000137 031750      BPL    30$
4747
4748
4749
4750 032412 005203          30$:   INC    R3          ;SELECT NEW KIND OF PATTERN
4751 032414 022703 000005      CMP    #5,R3          ;ALL DONE?
4752 032420 001402
4753 032422 000137 031750      BEQ    40$            ;NO BRANCH
4754 032426          40$:   JMP    TWODMA
4755 032426          ENDTST
4756
```

```

4758 032430      BADHEAD
4759             ;***** TEST22 *****
4760 032430      ;TEST INTERRUPT CAPABILITY OF KMV11 MODULE ON QBUS
                BADHEAD
                ;***** TEST22 *****

4761
4762
4763
4764 032430      STARS 1
4765             ;SET MAINT1 ; KMV11 DECODE AND CLEAR BSELO
4766             ;HOST PREPARES VECTOR AREA
4767             ;SEND TEST NUMBER (23 OR 24)
4768             ;DCT11 INTERRUPTS THE HOST BY SETTING BITS 5 OR 6 IN ADDRESS 140000 OF
4769             ;KMV11 MICRO BUS ;DCT11 CLEAR BSELO WHEN TEST COMPLETED.
4770             ;
4771             ;HOST TESTS IF THE INTERRUPT HAS BEEN RECEIVED WITH CORRECT VECTOR
4772             ;
4773             ;
4774             ;
4775             ;
4776             ;MICRO TEST 23 =INTERUPT ON LOW VECTOR
4777             ;MICRO TEST 24 =INTERUPT ON HIGH VECTOR
4778 032430      STARS 1
4779
4780
4781
4782
4783
4784
4785
4786 032430      BGNTST
4787 032430      004737 014550      JSR      PC,CLRKMV      ;CLR REG
4788 032434      004737 014730      JSR      PC,MAINM1
4789 032440      BGNSUB
4790 032442      005037 012430      CLR      INTFLG
4791 032446      013702 012476      MOV      KMVLVL,R2      ;READ KMV PRIORITY
4792 032452      012777 032536 160014  MOV      @INT1,@KMVV00  ;SET UP VECTOR 0
4793 032460      006202              ASR      R2
4794 032462      006202              ASR      R2
4795 032464      006202              ASR      R2
4796 032466      006202              ASR      R2
4797             ;
4798 032470      012777 000300 160004  MOV      @340,@KMVV02  ;SET KMV PRIORITY 7 FOR INTERRUPT ;JB REV A-0
                MOV      @300,@KMVV02  ;SET KMV PRIORITY 6 FOR INTERRUPT ;JB REV A-0
4799
4800
4801
4802             ;
4803 032476      012703 000300      MOV      @340,R3      ;TRY PRIORITY 7 FOR PROCESSOR ;JB REV A-0
                MOV      @300,R3      ;TRY PRIORITY 6 FOR PROCESSOR ;JB REV A-0
4804
4805
4806 032502      106403              SETPR1: MTPS      R3      ;LOAD PRIORITY
4807 032504      004537 015010      JSR      R5,TSTNUB  ;SEND TEST 23
4808 032510      000023              .WORD      23
4809
4810 032512      000240              NOP
4811 032514      000240              NOP
4812 032516      000240              NOP

```

```

4813 032520 000240          NOP
4814 032522 000240          NOP
4815 032524 000240          NOP
4816 032526 000240          NOP
4817
4818 032530          BREAK
4819 032532 000137 032546    JMP      VECT0
4820
4821
4822          ;*****INTERUPT ROUTINE *****
4823
4824 032536 052737 000001 012430 INT1:  BIS      #1,INTFLG          ;SET INT FLAG
4825 032544 000002          RTI
4826
4827
4828          ;*****
4829
4830
4831
4832 032546 004537 013722    VECT0:  JSR      R5,CBSELO          ;CHECK IF KMV11 ANSWER
4833 032552 000000          .WORD  0
4834 032554 000410          BR       2$
4835 032556          ERRHRD  59,EM0024          ;NO KMV11 ANSWER
4836 032566 004737 013010    JSR      PC,CHKMAX          ;CHECK IF TOO MANY ERROR
4837 032572          ESCAPE  SUB
4838
4839
4840 032576 005737 012430    2$:    TST      INTFLG          ;TEST IF INTERUPT ?
4841 032602 001454          BEQ      3$
4842
4843 032604 010237 002330    MOV      R2,GOOD          ;GOOD INTERUPT LEVEL
4844
4845
4846
4847 032610 062703 000040    ADD      #40,R3          ;WAS IT LEGAL
4848 032614 010337 012432    MOV      R3,BAD
4849 032620 023737 012432 002330    CMP      BAD,GOOD
4850 032626 001461          BEQ      4$          ;YES BRANCH
4851
4852 032630 106237 002330    ASRB    GOOD
4853 032634 106237 002330    ASRB    GOOD
4854 032640 106237 002330    ASRB    GOOD
4855 032644 106237 002330    ASRB    GOOD
4856 032650 106237 002330    ASRB    GOOD
4857 032654 042737 177770 002330    BIC      #177770,GOOD
4858
4859
4860 032662 106237 012432    ASRB    BAD
4861 032666 106237 012432    ASRB    BAD
4862 032672 106237 012432    ASRB    BAD
4863 032676 106237 012432    ASRB    BAD
4864 032702 106237 012432    ASRB    BAD
4865 032706 042737 177770 012432    BIC      #177770,BAD
4866 032714          ERRHRD  60,EM0022
4867 032724 004737 013010    JSR      PC,CHKMAX
4868 032730          ESCAPE  SUB
4869

```

```

4870
4871
4872 032734 122703 000140      3$:  CMPB   #140,R3      ;IS PROCESSOR AT LEVEL 3
4873 032740 001404              BEQ     5$
4874 032742 162703 000040      SUB     #40,R3        ;DECREASE PRIORITY
4875 032746 000137 032502      JMP     SETPR1        ;TRY WITH NEW ONE
4876
4877
4878
4879 032752              5$:  ERRHRD  61,EM0023      ;NO INTERRUPT OCCUR
4880 032762 004737 013010      JSR     PC,CHKMAX     ;CHECK IF TOO MANY ERROR
4881 032766              ESCAPE  SUB
4882
4883 032772              4$:
4884 032772              ENDSUB
4885
4886
4887 032774              BGNSUB
4888 032776 004737 014730      JSR     PC,MAINM1
4889 033002 005037 012430      CLR     INTFLG
4890 033006 013702 012476      MOV     KMVLVL,R2     ;SET PRIORITY LEVEL
4891
4892 033012 012777 000300 157464 ;      MOV     #340,@KMVV06 ;JB REV A-0
4893 033020 012777 033072 157452 ;      MOV     #300,@KMVV06 ;JB REV A-0
4894 033026 006202              ASR     #INT2,@KMVV04 ;SET UP VECTOR 4
4895 033030 006202              ASR     R2
4896 033032 006202              ASR     R2
4897 033034 006202              ASR     R2
4898
4899 033036 012703 000300      ;      MC:   #340,R3      ;START WITH PRIORITY 7 FOR PROCESSOR ;JB REV A-0
4900
4901
4902
4903
4904 033042 106403              INTPR2: MTPS   R3      ;LOAD PRIORITY
4905 033044 004537 015010      JSR     R5,TSTNUB
4906 033050 000024              .WORD   24          ;SET TEST NB 24
4907 033052 000240              NOP
4908 033054 000240              NOP
4909 033056 000240              NOP
4910 033060 000240              NOP
4911 033062 000240              NOP
4912
4913 033064              BREAK
4914 033066 000137 033102      JMP     VECT4
4915
4916
4917
4918
4919
4920 033072 052737 000001 012430 INT2:  BIS     #1,INTFLG      ;SET FLAG
4921 033100 000002              RTI
4922
4923
4924
4925
4926

```

4927									
4928	033102	004537	013722		VFCT4:	JSR	R5,CBSELO		;IS THERE KMV11 ANSWER ?
4929	033106	000000				,WORD	0		
4930	033110	000410				BR	2:		
4931	033112					ERRHRD	62,EM0024		;NO KMV11 ANSWER
4932	033122	004737	013010			JSR	PC,CHKMAX		;CHECK IF TOO MANY ERROR
4933	033126					ESCAPE	SUB		
4934									
4935									
4936									
4937	033132	032737	000001	012430	2:	BIT	#1,INTFIG		;TEST IF INTERRUPT OCCUR
4938	033140	001454				BEQ	3:		;NO INTERRUPT
4939									
4940	033142	010237	002330			MOV	R2,GOOD		;GOOD INTERRUPT LEVEL
4941									
4942									
4943	033146	062703	000040			ADD	#40,R3		;WAS IT LEGAL ?
4944	033152	010337	012432			MOV	R3,BAD		
4945									
4946	033156	023737	012432	002330		CMP	BAD,GOOD		
4947	033164	001461				BEQ	4:		;YES BRANCH
4948	033166	106237	002330			ASRB	GOOD		
4949	033172	106237	002330			ASRB	GOOD		
4950	033176	106237	002330			ASRB	GOOD		
4951	033202	106237	002330			ASRB	GOOD		
4952	033206	106237	002330			ASRB	GOOD		
4953	033212	042737	177770	002330		BIC	#177770,GOOD		;GET ACTUAL LEVEL
4954									
4955	033220	106237	012432			ASRB	BAD		
4956	033224	106237	012432			ASRB	BAD		
4957	033230	106237	012432			ASRB	BAD		
4958	033234	106237	012432			ASRB	BAD		
4959	033240	106237	012432			ASRB	BAD		
4960	033244	042737	177770	012432		BIC	#177770,BAD		
4961	033252					ERRHRD	63,EM0022		;INT OCCUR AT BAD LEVEL
4962	033262	004737	013010			JSR	PC,CHKMAX		
4963	033266					ESCAPE	SUB		
4964									
4965									
4966									
4967									
4968	033272	122703	000040		3:	CMPB	#40,R3		;IS PROCESSOR AT PRIORITY 3
4969	033276	001404				BEQ	5:		;YES,NO INTERRUPT OCCURED
4970	033300	162703	000040			SUB	#40,R3		;DECREASE PRIORITY LEVEL
4971	033304	000137	033042			JMP	INTR2		
4972									
4973									
4974	033310				5:	ERRHRD	64,EM0023		
4975	033320	004737	013010			JSR	PC,CHKMAX		;CHECK IF TOO MANY ERROR
4976	033324					ESCAPE	SUB		
4977	033330				4:				
4978	033330				ENOSUB				
4979	033332				ENDTST				

4981
4982 033334

BADHEAD
;***** TEST23 *****
;TEST INTERRUPT ON DCT11 MICROPROCESSOR
BADHEAD
;***** TEST23 *****

4983
4984 033334

4985
4986
4987
4988
4989
4990

4991 033334

STARS 1
;CHECKS THAT QBUS ACCESS ON BSEL0 AND BSEL10 CAUSE AN INTERRUPT ON DCT11
;CHECKS THAT ACCESSES ON ALL THE OTHER CSR'S DOES NOT CAUSE ANY INTERRUPTS.

4992
4993
4994
4995
4996
4997

; TEST DESCRIPTION:
;TEST NUMB 25: DCT11 INITIALIZE VECTOR 60 ON DCT11 BUS CORRESPONDING TO
BSEL0 INTERRUPT
; QBUS ACCESS ALL REGISTERS BUT BSEL0 AND CHECK THAT NO
INTERUPT OCCUR ON DCT11

5000
5001
5002
5003
5004

; CHECK THAT QBUS ACCESS ON BSEL0 GIVE AN INTERRUPT ON VECTOR 60

5005
5006
5007
5008
5009

;TEST NUMB 26: DCT11 INITIALIZE VECTOR 70 CORRESPONDING TO BSEL2
INTERUPT

5010
5011
5012
5013
5014

; QBUS ACCESS ALL REGISTERS BUT BSEL2 AND CHECK NO INTERUPT
OCCUR ON DCT11

5015
5016
5017
5018
5019

; CHECK THAT QBUS ACCES ON BSEL2 INTERUPT ON VECTOR 70

5020
5021
5022
5023
5024
5025

;ERROR REPORTING: BSEL0=0 IF INTERUPT OCCUR
BSEL0=100 IF ILLEGAL VECTOR
BSEL0=TEST NB IF NO INTERUPT
SEL2 = EXPECTED VECTOR

5026 033334

STARS 1

```

5028
5029
5030
5031
5032
5033
5034
5035
5036 033334          BGNTST
5037
5038
5039 033334          BGNSUB
5040 033336 004737 014550      JSR      PC,CLRKMV      ;CLEAR REG
5041 033342 004737 014730      JSR      PC,MAINM1     ;SET MAINT MODE
5042 033346 004537 015010      JSR      R5,TSTNUB    ;SET TEST NB 25
5043 033352 000025              .WORD    25
5044
5045
5046 033354          WAITB    0,1
5047
5048
5049
5050 033374 013701 012512      MOV      KMVP02,R1     ;LOAD CSR ADDR
5051 033400 012702 000012      MOV      #12,R2       ;ACCESS BSEL2 TO BSEL16
5052
5053 033404 152721 000207      1$:     BISB      #207,(R1)+ ;WRITE ALL REG BUT BSEL0
5054
5055 033410          WAITB    0,1      ;WAIT FOR TEST EXECUTION
5056
5057 033430 004537 013722      JSR      R5,CBSELO    ;LOOK IF INTERRUPT OCCUR
5058 033434 000000              .WORD    0
5059
5060 033436 000404              BR       3$           ;YES SEE WHICH ERROR
5061 033440 005302              DEC      R2           ;ALL REG DONE ?
5062 033442 001360              BNE     1$           ;NO BR
5063
5064
5065
5066
5067 033444 000137 033476      JMP      GOON1        ;OK NO ACCESS INTERRUPT THE DCT11 ;GO ON
5068
5069
5070
5071 033450 010137 002420      3$:     MOV      R1,ADDR     ;SEE WHICH ADDRESS CAUSE INTERRUPT
5072 033454 162737 000001 002420  SUB      #1,ADDR
5073 033462          ERRHRD  65,EM0026,PINTR ;WRONG INTERRUPT OCCURED ON DCT11
5074          ;WHILE ADDRESSING KMV11 REGISTERS
5075 033472          ESCAPE  SUB
5076
5077
5078
5079 033476 052777 004025 157004  GOON1:  BIS      #4025,6KMVCSR ;ACCESS BSEL0
5080
5081 033504          WAITB    0,1
5082
5083 033524 004537 013722      JSR      R5,CBSELO
5084 033530 000000              .WORD    0

```



```

5085 033532 000424          BR      5$          ;TEST OK ,INTRUPT OCCURED AT GOOD VECTOR
5086
5087 033534 004537 013722    JSR      R5,CBSELO
5088 033540 000100          .WORD   100
5089 033542 000410          BR      6$          ;INT ON ILLEGAL VECTOR
5090 033544          ERRHRD  66,EM0027    ;NO KMV11 ANSWER, DCT11 DOES NOT RECEIVE ANY
5091 033554 004737 013010    JSR      PC,CHKMAX    ;CHECK IF TOO MANY ERROR
5092 033560          ESCAPE  SUB          ;INTERUPT WHEN QBUS ADDRESS CSR'S
5093
5094
5095
5096
5097 033564          6$:    ERRHRD  67,EM0032    ;INT ON ILLEGAL VECTOR WHEN ACCESSING BSELO
5098 033574 004737 013010    JSR      PC,CHKMAX    ;CHECK IF TOO MANY ERROR
5099 033600          ESCAPE  SUB
5100
5101 033604 000240          5$:    NOP
5102 033606          ENDSUB
5103
5104
5105
5106
5107
5108 033610          BGNSUB
5109 033612 004737 014730    JSR      PC,MAINM1    ;SET MAINT MODE
5110 033616 004537 015010    JSR      R5,TSTNUB    ;SET TEST NB 26
5111 033622 000026          .WORD   26
5112
5113
5114 033624          WAITB  0,1
5115
5116 033644 052777 000026 156636  BIS      #26,#KMVCSR    ;WRITE SELO
5117
5118 033652 013701 012514    MOV      KMVP04,R1    ;LOAD CSR ADDR
5119 033656 012702 000010    MOV      #10,R2      ;ACCES BSEL3 TO BSEL11
5120
5121 033662 152721 000207    1$:    BISB   #207,(R1)+    ;WRITE ALL REG BUT BSEL2
5122
5123 033666          WAITB  0,1          ;WAIT FOR TEST EXECUTION
5124
5125 033706 004537 013722    JSR      R5,CBSELO    ;LOOK IF INTERUPT OCCUR
5126 033712 000000          .WORD   0
5127
5128 033714 000404          BR      3$          ;YES SEE WHICH ERROR
5129 033716 005302          DEC     R2           ;ALL REG DONE ?
5130 033720 001360          BNE     1$          ;NO BR
5131
5132
5133
5134
5135
5136 033722 000137 033760          JMP     G00N2        ;OK NO ACCESS INTERUPT THE DCT11 ;GO ON
5137
5138
5139 033726 017737 156562 012440 3$:    MOV     #KMVP04,VECT  ;READ RECEIVE VECTOR
5140 033734 010137 002420    MOV     R1,ADDR      ;SEE WHICH ADDRESS MAKE INTERUPT
5141 033740 005337 002420    DEC     ADDR
    
```

```

5142 033744          ERRHRD 68,EM0026,PINTR ;WRONG INTERUPT OCCUR WHILE ACCESSING REGISTERS
5143 033754          ESCAPE  SUB
5144
5145
5146 033760 000240          GOON2:  NOP
5147
5148 033762 052777 017777 156522      BIS      417777,4KMVP02 ;ACCESS BSEL2
5149
5150 033770          WAITB  0,1
5151
5152 034010 004537 013722      JSR      R5,CBSELO
5153 034014 000000          .WORD   0
5154 034016 000424          BR       5$ ;TEST OK ,INTRUPT OCCUR AT GOOD VECTOR
5155
5156 034020 004537 013722      JSR      R5,CBSELO
5157 034024 000100          .WORD   100
5158 034026 000410          BR       6$ ;INT ON ILLEGAL VECTOR
5159 034030          ERRHRD 69,EM0027 ;NO KMV11 ANSWER
5160 034040 004737 013010      JSR      PC,CHKMAX ;CHECK IF TOO MANY ERROR
5161 034044          ESCAPE  SUB
5162
5163
5164
5165
5166
5167 034050          6$:      ERRHRD 70,EM0026 ;INT ON ILLEGAL VECTOR
5168 034060 004737 013010      JSR      PC,CHKMAX ;CHECK IF TOO MANY ERROR
5169 034064          ESCAPE  SUB
5170
5171 034070 000240          5$:      NOP
5172 034072          ENDSUB
5173
5174
5175
5176 034074          ENDTST
5177

```

5179
5180
5181
5182
5183
5184
5185
5186
5187
5188
5189
5190
5191
5192
5193
5194
5195
5196
5197
5198
5199
5206
5207
5208
5209
5210
5211
5212
5213

.SBTTL HARDWARE PARAMETER CODING SECTION

```
;/;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;/
;/ THE HARDWARE PARAMETER CODING SECTION CONTAINS MACROS
;/ THAT ARE USED BY THE SUPERVISOR TO BUILD P-TABLES. THE
;/ MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
;/ INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
;/ MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
;/ WITH THE OPERATOR.
;/;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;/
```

BGNHRD

GPRMA ADDRES,0,0,60000,177776,YES
GPRMA VECTOR,2,0,0,674,YES
GPRMD PRIRTY,4,0,7000,4,7,YES
ENDHRD

ADDRESS: .ASCIZ /MICRO-CPU CSR ADDRESS : /

VECTOR: .ASCIZ /MICRO-CPU VECTOR ADDRESS : /

PRIRTY: .ASCIZ /MICRO-CPU PRIORITY LEVEL : /

.EVEN

5215
5216
5217
5218
5219
5220
5221
5222
5223
5224
5225
5226
5227 034254
5228
5237
5238
5239 034256
5240
5241
5248
5249

.SBTTL SOFTWARE PARAMETER CODING SECTION

```
;/;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;/
;/ THE SOFTWARE PARAMETER CODING SECTION CONTAINS MACROS
;/ THAT ARE USED BY THE SUPERVISOR TO BUILD P TABLES. THE
;/ MACROS ARE NOT EXECUTED AS MACHINE INSTRUCTIONS BUT ARE
;/ INTERPRETED BY THE SUPERVISOR AS DATA STRUCTURES. THE
;/ MACROS ALLOW THE SUPERVISOR TO ESTABLISH COMMUNICATIONS
;/ WITH THE OPERATOR.
;/;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;/
```

BGNSFT

ENDSFT

FLO

5251
5252 034256
5253 034256
5254
5261
5262 034376
034402
5263 034402
5264
5265

\$PATCH::
.BLKW 50

LASTAD
L\$LAST::
ENDMOD

```
5267  
5268  
5281  
5282 034402          BGNSETUP          1  
5283 034402          BGNPTAB  
5284 034406 177000   .WORD 177000  
5285 034410 000300   .WORD 300  
5286 034412 004000   .WORD 4000  
5287 034414 000001   .WORD 1  
5288 034416          ENDPTAB  
5289 034416          ENDSETUP  
5290  
5291  
5292  
5293  
5294  
5295          000001          .END
```

ABORT	024036	C\$DCLN=	000044	EF.RES=	000037 G	F\$RPT =	000012	G\$RADL=	000120
ADDR	002420	C\$DODU=	000051	EF.STA=	000040 G	F\$SEG =	000003	G\$RADO=	000020
ADDRES	034132	C\$DRPT=	000024	EM0001	015265	F\$SOFT=	000005	G\$XFER=	000004
ADR	* 000020 G	C\$DU =	000053	EM0002	015361	F\$SRV =	000010	G\$YES =	000010
ASSEMB=	000010	C\$EDIT=	000003	EM0003	015424	F\$SUB =	000002	HELP =	000000
BAD	012432	C\$ERDF=	000055	EM0004	015512	F\$SW =	000014	HOE =	100000 G
BUDAT	002424	C\$ERHR=	000056	EM0005	015575	F\$TEST=	000001	IBE =	010000 G
BIT0 =	000001 G	C\$ERRO=	000060	EM0006	015671	GDDAT	002422	IDU =	000040 G
BIT00 =	000001 G	C\$ERSF=	000054	EM0007	015764	GDREV	012464	IER =	020000 G
BIT01 =	000002 G	C\$ERSO=	000057	EM0010	016056	GENER	013230	INIFLG	012466
BIT02 =	000004 G	C\$ESCA=	000010	EM0011	016152	GENFR1	013352	INTFLC	012430
BIT03 =	000010 G	C\$ESEG=	000005	EM0012	016246	GENEX	013510	INTPR2	033042
BIT04 =	000020 G	C\$ESUB=	000003	EM0013	016342	GENE1	025504	INT1	032536
BIT05 =	000040 G	C\$EYST=	000001	EM0015	016436	GENE2	025702	INT2	033072
BIT06 =	000100 G	C\$EXIT=	000032	EM0016	016506	GENE3	026100	ISR =	000100 G
BIT07 =	000200 G	C\$GETB=	000026	EM0020	016544	GENE4	026310	IXE =	004000 G
BIT08 =	000400 G	C\$GETW=	000027	EM0021	016630	GENE5	026512	I\$AU =	000041
BIT09 =	001000 G	C\$GMAN=	000043	EM0022	016722	GENE6	026714	I\$AUTO=	000041
BIT1 =	000002 G	C\$GPHR=	000042	EM0023	016762	GENINC	013502	I\$CLN =	000041
BIT10 =	002000 G	C\$GPLD=	000030	EM0024	017005	GENISH	013360	I\$DU =	000041
BIT11 =	004000 G	C\$GPRI=	000040	EM0025	017075	GENRAN	013362	I\$HRD =	000041
BIT12 =	010000 G	C\$INIT=	000011	EM0026	017136	GENROT	013336	I\$INIT=	000041
BIT13 =	020000 G	C\$INLP=	000020	EM0027	017232	GENRO	013324	I\$MOD =	000041
BIT14 =	040000 G	C\$MANI=	000050	EM0028	017307	GENR1	013314	I\$MSG =	000041
BIT15 =	100000 G	C\$MEM =	000031	EM0030	017341	GENSEL	013246	I\$PROT=	000040
BIT2 =	000004 G	C\$MSG =	000023	EM0031	017423	GENO	013266	I\$PTAB=	000041
BIT3 =	000010 G	C\$OPEN=	000034	EM0032	017477	GEN1	013272	I\$PWR =	000041
BIT4 =	000020 G	C\$PNTB=	000014	EM0033	017573	GEN25	013306	I\$RPT =	000041
BIT5 =	000040 G	C\$PNTF=	000017	EM0034	017654	GEN52	013300	I\$SEG =	000041
BIT6 =	000100 G	C\$PNTS=	000016	EM0035	020013	GETPRM	023634	I\$SETU=	000041
BIT7 =	000200 G	C\$PNTX=	000015	EM0134	017746	GOOD	002330	I\$SFT =	000041
BIT8 =	000400 G	C\$QIO =	000377	END	024102	GOOD0	002332	I\$SRV =	000041
BIT9 =	001000 G	C\$RDBU=	000007	ERRBLK	002264 G	GOOD1	002334	I\$SUB =	000041
BOE =	000400 G	C\$REFG=	000047	ERRCNT	002300	GOOD10	002344	I\$TST =	000041
BSELO	012434	C\$RESE=	000033	ERRMSG	002262 G	GOOD12	002346	J\$JMP =	000167
BSEL1	002376	C\$REVI=	000003	ERRNBR	002260 G	GOOD14	002350	KIND	012442
CBSELO	013722	C\$RFLA=	000021	ERRTYP	002256 G	GOOD16	002352	KMTLVL	012506
CHANEL	012444	C\$RPT =	000025	EVL =	000004 G	GOOD2	002336	KMVCSR	012510
CHECK	024652	C\$SEFG=	000046	EXADDR	012426	GOOD4	002340	KMVLVL	012476
CHECK1	025016	C\$SPRI=	000041	E\$END =	002100	GOOD6	002342	KMVP02	012512
CHKMAX	013010	C\$SVEC=	000037	E\$LOAD=	000035	GOON1	033476	KMVP04	012514
CKALL	013760	C\$TPRI=	000013	FLAG	002320	GOON2	033760	KMVP06	012516
CKREG	014262	DATA	012436	FTIME	002316	G\$CNTD=	000200	KMVP10	012520
CKSELO	013670	DATA1 =	052525 G	F\$AU =	000015	G\$DELM=	000372	KMVP12	012522
CLRKMV	014550	DATA2 =	125252 G	F\$AUTO=	000020	G\$DISP=	000003	KMVP14	012524
COUNT	002414	DELCT1	002324	F\$BGN =	000040	G\$EXCP=	000400	KMVP16	012526
C\$AU =	000052	DELCT2	002326	F\$CLEA=	000007	G\$HILI=	000002	KMVV00	012474
C\$AUTO=	000061	DFPTBL	002212 G	F\$DU =	000016	G\$LOLI=	000001	KMVV02	012502
C\$BRK =	000022	DH1	002322	F\$END =	000041	G\$NO =	000000	KMVV04	012500
C\$BSEG=	000004	DIAGMC=	000000	F\$HARD=	000004	G\$OFFS=	000400	KMVV06	012504
C\$BSUB=	000002	DMAIN	030444	F\$HW =	000013	G\$OFST=	000376	KMV11A	002000 G
C\$CEFG=	000045	DMAOUT	031104	F\$INIT=	000006	G\$PRMA=	000001	LENGTH	012454
C\$CLCK=	000062	DMATWO	031736	F\$JMP =	000050	G\$PRMD=	000002	LOCK	002274
C\$CLEA=	000012	DROPD	024230	F\$MOD =	000000	G\$PRML=	000000	LOE =	040000 G
C\$CLOS=	000035	EF.CON=	000036 G	F\$MSG =	000011	G\$RADA=	000140	LOGDEV	002302
C\$CLP1=	000006	EF.NEW=	000035 G	F\$PROT=	000021	G\$RADB=	000000	LOKFLG	012470
C\$CVEC=	000036	EF.PWR=	000034 G	F\$PWR =	000017	G\$RADD=	000040	LODP	012530

LOT =	000010 G	L10002	022056	L10073	031714	O\$SETU*	000001	SAVSP	002306
L\$ACP	002110 G	L10003	022144	L10074	032426	PADFLT	022346 G	SAVSTA	002412
L\$APT	002036 G	L10004	022206	L10075	033332	PBSELO	023174 G	SELO	002354
L\$AU	024262 G	L10005	022312	L10076	032772	PCHECK	022314 G	SEL1	002356
L\$AUT	002070 G	L10006	022344	L10077	033330	PDMAF	023354 G	SEL10	002366
L\$AUTO	024104 G	L10007	022402	L10100	034074	PDMARA	022210 G	SEL12	002370
L\$CCP	002106 G	L10010	022712	L10101	033606	PINTR	023232 G	SEL14	002372
L\$CLEA	024176 G	L10011	023172	L10102	034072	PNT	* 001000 G	SEL16	002374
L\$CO	002032 G	L10012	023230	L10103	034132	PRALL	022404 G	SEL2	002360
L\$DEPO	002011 G	L10013	023262	L10104	034256	PRBYTE	022146 G	SEL4	002362
L\$DESC	002222 G	L10014	023352	L10105	034406	PRDMA	023264 G	SEL6	002364
L\$DESP	002076 G	L10015	023410	L10107	034416	PRI	- 002000 G	SETFR1	032502
L\$DEVP	002060 G	L10016	023416	MAINM0	014660	PRIPTY	034220	SETUP	023552
L\$DISP	002132 G	L10017	024102	MAINM1	014730	PRI00	* 000000 G	SSTACK	012732
L\$DLY	002116 G	L10020	024174	MAINT0*	054000 G	PRI01	* 000040 G	SVCGBL*	000000
L\$DTP	002040 G	L10021	024200	MAINT1*	044000 G	PRI02	* 000100 G	SVCINS*	177777
L\$DTYP	002034 G	L10022	024260	MAXCNT	012462	PRI03	* 000140 G	SVCSUB*	177777
L\$DU	024202 G	L10023	024262	MAXERR	002276	PRI04	* 000200 G	SVCTAG*	177777
L\$DUT	002072 G	L10024	024400	MAXPRI*	000300 G	PRI05	* 000240 G	SVCTST*	177777
L\$DVTY	012732 G	L10025	024574	MBSELO	021103	PRI06	* 000300 G	S\$L.SYM*	010000
L\$EF	002052 G	L10026	024516	MBYTE	021371	PRI07	* 000340 G	TBYTE	025104
L\$ENVI	002044 G	L10027	024572	MCHECK	021666	PROMCK	030326	TCSR	024770
L\$ERRT	002256 G	L10030	024734	MCLR	* 040000 G	PRRAM	022060 G	TCSRNB	024760
L\$ETP	002102 G	L10031	025076	MDMAF	021737	PRREG	022714 G	TFM36	015164
L\$EXP1	002046 G	L10032	025230	MDMAR1	021453	PRSELO	022022 G	TGENE1	025474
L\$EXP4	002064 G	L10033	025456	MDMAR2	021542	PSTACK	002304	TGENE2	025672
L\$EXP5	002066 G	L10034	025344	MDMAR3	021610	QV.FLG	012471	TGENE3	026070
L\$HARD	034100 G	L10035	025454	MDMA1	021240	RAMADD	027726	TGENE4	026300
L\$HIME	002120 G	L10036	025652	MDMA2	021323	RAMCAD	030100	TGENE5	026502
L\$HPCP	002016 G	L10037	025546	MINT	021051	RAMPAT	027506	TGENE6	026704
L\$HPTP	002022 G	L10040	025650	MINTR	021145	RANCLC	013462	TIM	015247
L\$HW	002212 G	L10041	026050	MIRAM1	020707	RANON	002406	TSELA	024630
L\$ICP	002104 G	L10042	025744	MIRAM2	020771	RANEX	013500	TSELB	024634
L\$INIT	023420 G	L10043	026046	MREG0	020107	RANGEN	013402	TSEL10	026200
L\$LADP	002026 G	L10044	026260	MREG10	020323	RANMTA	002404	TSEL12	026402
L\$LAST	034402 G	L10045	026154	MREG12	020366	RANSEC	013466	TSEL14	026604
L\$LOAD	002100 G	L10046	026256	MREG14	020431	RANSEL	002402	TSEL16	027006
L\$LUN	002074 G	L10047	026462	MREG16	020474	RANST	002400	TSEL4	025572
L\$MREV	002050 G	L10050	026356	MREG2	020152	RAN1	013414	TSEL6	025770
L\$NAME	002000 G	L10051	026460	MREG4	020215	RAN2	013432	TSPEED	012452
L\$PRIO	002042 G	L10052	026664	MREG6	020260	RAN4	013470	TSTERR	013152
L\$PROT	002122 G	L10053	026560	MSELO	020042	READ	015072	TSTNUB	015010
L\$PRY	002112 G	L10054	026662	MSEL10	020645	REGADR	012532	TSTREG	024576
L\$REPP	002062 G	L10055	027066	MSEL2	020537	RESTST	024404	TTABLE	002426
L\$REV	002010 G	L10056	026762	MSEL4	020602	REVPRO	030262	TWODMA	031750
L\$RPT	023412 G	L10057	027064	NERR5	013102	RGALL	027112	TXDATA	012446
L\$SOFT	034256 G	L10060	027504	NEXT	023560	ROMMAP	024264	T\$ARGC*	000002
L\$SPC	002056 G	L10061	027724	NUB	012456	RSTREG	013610	T\$CODE*	002032
L\$SPCP	002020 G	L10062	030076	NUMBER	002416	RTABLE	006426	T\$ERRN*	000106
L\$SPTP	002024 G	L10063	030250	O\$APTS*	000000	RUNNIN	024044	T\$EXCP*	000000
L\$STA	002030 G	L10064	030314	O\$AU	* 000000	RXCNT	012460	T\$FLAG*	000040
L\$SW	002266	L10065	030442	O\$BGNR*	000000	RXDATA	012450	T\$FREE*	034416
L\$TEST	002114 G	L10066	031100	O\$BGNS*	000000	SAVE4	002312	T\$GMAN*	000000
L\$TIML	002014 G	L10067	030664	O\$DU	* 000001	SAVE6	002314	T\$HILI*	000007
L\$UIT	002270	L10070	031076	O\$ERRT*	000000	SAVPC	002310	T\$LAST*	000001
L\$UNIT	002012 G	L10071	031716	O\$GNSW*	000001	SAVPC1	002410	T\$LOLI*	000004
L10001	002222	L10072	031404	O\$POIN*	000001	SAVREG	013530	T\$LSYM*	010000

T\$LTNO=	000027	T\$\$AUT=	010020	T11.1	026464	T21	031720 G	T9.1	026052
T\$NEST=	177777	T\$\$CLE=	010021	T11.2	026562	T22	032430 G	T9.2	026156
T\$NS0 =	000000	T\$\$DAT=	010107	T12	026666 G	T22.1	032440	UAM	000200 G
T\$NS1 =	000005	T\$\$DU =	010022	T12.1	026666	T22.2	032774	UNIT	002272
T\$NS2 =	000002	T\$\$HAR=	010103	T12.2	026764	T23	033334 G	UUT	012472
T\$PCNT=	000000	T\$\$HW =	010001	T13	027070 G	T23.1	033334	VECT	012440
T\$PTAB=	010106	T\$\$INI=	010017	T14	027506 G	T23.2	033610	VECTOR	034164
T\$PTHV=	000001	T\$\$MSG=	010015	T15	027726 G	T3	024576 G	VECTO	032546
T\$PTNU=	000001	T\$\$PC =	000001	T16	030100 G	T4	024736 G	VECT4	033102
T\$SAVL =	177777	T\$\$PRO=	010000	T17	030252 G	T5	025100 G	WAIT1	013000
T\$SEGL =	177777	T\$\$PTA=	010106	T18	030316 G	T6	025232 G	WAIT2	012760
T\$SIZE=	000006	T\$\$RPT=	010016	T19	030444 G	T6.1	025242	WRITE	015044
T\$SUBN=	000002	T\$\$SOF=	010104	T19.1	030454	T6.2	025346	X\$ALWA=	000000
T\$TAGL =	177777	T\$\$SUB=	010102	T19.2	030666	T7	025460 G	X\$FALS=	000040
T\$TAGN=	010110	T\$\$TES=	010100	T2	024402 G	T7.1	025460	X\$OFFS=	000400
T\$TEMP=	000000	T1	024264 G	T2.1	024402	T7.2	025550	X\$TRUE=	000020
T\$TEST=	000027	T10	026262 G	T2.2	024520	T8	025654 G	\$LSTIN=	000000
T\$TSTM=	177777	T10.1	026262	T20	031102 G	T8.1	025654	\$LSTTA=	000000
T\$TSTS=	000001	T10.2	026360	T20.1	031102	T8.2	025746	\$PATCH	034256 G
T\$\$AU =	010023	T11	026464 G	T20.2	031406	T9	026052 G		

. ABS. 034416 000
000000 001
ERRORS DETECTED: 0

VIRTUAL MEMORY USED: 29232 WORDS (115 PAGES)
DYNAMIC MEMORY: 19748 WORDS (75 PAGES)
ELAPSED TIME: 00:19:17
CNKMDA.BIC,CNKMDA.SEQ/CRF/-SP=SVC34.MLB/ML,CNKMDA.MAC

PROGRAM DOCUMENTB1	RESTORE REGISTERSB5	HARDWARE TESTSB9
PROGRAM DOCUMENTC1	RESTORE REGISTERSC5	HARDWARE TESTSC9
PROGRAM DOCUMENTD1	RESTORE REGISTERSD5	HARDWARE TESTSD9
PROGRAM DOCUMENTE1	GLOBAL ERROR REPORTE5	HARDWARE TESTSE9
PROGRAM DOCUMENTF1	GLOBAL ERROR REPORTF5	HARDWARE TESTSF9
PROGRAM DOCUMENTG1	GLOBAL ERROR REPORTG5	HARDWARE TESTSG9
PROGRAM DOCUMENTH1	GLOBAL ERROR REPORTH5	HARDWARE TESTSH9
PROGRAM DOCUMENTI1	GLOBAL ERROR REPORTI5	HARDWARE TESTSI9
PROGRAM DOCUMENTJ1	GLOBAL ERROR REPORTJ5	HARDWARE TESTSJ9
PROGRAM DOCUMENTK1	REPORT CODING SECTIONK5	HARDWARE TESTSK9
PROGRAM DOCUMENTL1	INITIALIZE SECTIONL5	HARDWARE TESTSL9
PROGRAM DOCUMENTM1	INITIALIZE SECTIONM5	HARDWARE TESTSM9
PROGRAM DOCUMENTN1	AUTODROP SECTIONN5	HARDWARE TESTSN9
PROGRAM DOCUMENTB2	CLEANUP CODING SECTIONB6	HARDWARE TESTSB10
PROGRAM DOCUMENTC2	DROP UNIT SECTIONC6	HARDWARE TESTSC10
PROGRAM DOCUMENTD2	ADD UNIT SECTIOND6	HARDWARE TESTSD10
PROGRAM DOCUMENTE2	ADD UNIT SECTIONE6	HARDWARE TESTSE10
PROGRAM DOCUMENTF2	HARDWARE TESTSF6	HARDWARE TESTSF10
PROGRAM DOCUMENTG2	HARDWARE TESTSG6	HARDWARE TESTSG10
PROGRAM DOCUMENTH2	HARDWARE TESTSH6	SOFTWARE PARAMETER C...H10
PROGRAM DOCUMENTI2	HARDWARE TESTSI6	SOFTWARE PARAMETER C...I10
PROGRAM HEADERJ2	HARDWARE TESTSJ6	SOFTWARE PARAMETER C...J10
DISPATCH TABLEK2	HARDWARE TESTSK6	SYMBOL TABLEK10
DEFAULT HARDWARE P-TL2	HARDWARE TESTSL6	SYMBOL TABLEL10
GLOBAL EQUATES SECTIONM2	HARDWARE TESTSM6	SYMBOL TABLEM10
GLOBAL DATA SECTIONN2	HARDWARE TESTSN6		
GLOBAL DATA SECTIONB3	HARDWARE TESTSB7		
GLOBAL DATA SECTIONC3	HARDWARE TESTSC7		
GLOBAL DATA SECTIOND3	HARDWARE TESTSD7		
GLOBAL DATA SECTIONE3	HARDWARE TESTSE7		
GLOBAL TEXT SECTIONF3	HARDWARE TESTSF7		
GLOBAL SUBROUTINESG3	HARDWARE TESTSG7		
GLOBAL SUBROUTINESH3	HARDWARE TESTSH7		
GLOBAL SUBROUTINESI3	HARDWARE TESTSI7		
GLOBAL SUBROUTINESJ3	HARDWARE TESTSJ7		
GLOBAL SUBROUTINESK3	HARDWARE TESTSK7		
NUMBER GENERATORL3	HARDWARE TESTSL7		
NUMBER GENERATORM3	HARDWARE TESTSM7		
NUMBER GENERATORN3	HARDWARE TESTSN7		
SAVE REGISTERSB4	HARDWARE TESTSB8		
SAVE REGISTERSC4	HARDWARE TESTSC8		
RESTORE REGISTERSD4	HARDWARE TESTSD8		
RESTORE REGISTERSE4	HARDWARE TESTSE8		
RESTORE REGISTERSF4	HARDWARE TESTSF8		
RESTORE REGISTERSG4	HARDWARE TESTSG8		
RESTORE REGISTERSH4	HARDWARE TESTSH8		
RESTORE REGISTERSI4	HARDWARE TESTSI8		
RESTORE REGISTERSJ4	HARDWARE TESTSJ8		
RESTORE REGISTERSK4	HARDWARE TESTSK8		
RESTORE REGISTERSL4	HARDWARE TESTSL8		
RESTORE REGISTERSM4	HARDWARE TESTSM8		
RESTORE REGISTERSN4	HARDWARE TESTSN8		